
SHARP SERVICE MANUAL

CODE: 00ZARM350UA1E



LASER PRINTER

AR-M350U/M450U MODEL AR-M350N/M450N

OPTIONS AR-P14

[1] INTRODUCTION

The AR-M350U/M450U and AR-M350N/M450N are minor change models based on the AR-M350/M450.

This service manual only provides information on these minor changes.

In addition to this service manual, the documents listed below are required to properly maintain these machines.

•AR-M350/M450	Service Manual : 00ZARM350/A1E	Parts Guide: 00ZARM450/P1E	Circuit Diagram: 00ZARM350/C1/
•AR-P350/P450	Service Manual : 00ZARP350/A2E	Parts Guide: 00ZAR350LPP1/	Circuit Diagram: 00ZARP350/C1/
•AR-NC5J	Service Manual : 00ZARNC5J/A1E		

Note: Depending on the option, additional service documentation may be required.

[2] LIST OF DIFFERENCES FROM AR-M350/M450

A.Product composition

	Model Name	Printer Option Model	NIC Standard Model	Note
Base Engine		AR-M350U	AR-M350N	
		AR-M450U	AR-M450N	
Print Speed		35ppm	35ppm	
		45ppm	45ppm	
Multi Function Controller	AR-M11	Not Available	Standard	
Multi Function Controller(for U-Model)	Not Available	Standard	Not Available	Not registered as a product
Print Server Card	AR-NC5J	Not Available	Standard	
Printer Extension Kit	AR-P14	Option	Not Available	*1


^{*1:} Installation of the AR-P14 on the AR-M350U/M450U will provide similar functionality to that of the AR-M350/M450.

Parts marked with "\\.\" are important for maintaining the safety of the set.

Be sure to replace these parts with specified ones for maintaining the safety and performance of the set.

[3] CONFIGURATION

1.System Configurations



2. Standard

Category	Model Name	Other options required for the installation/mounting. (Options must be ordered separately.)	Remarks
MFP model (35ppm)	AR-M350	B/W Scanner module/DSPF (AR-EF1)	
MFP model (45ppm)	AR-M450	Scanner Rack(AR-RK1)	
MFP model (35ppm)	AR-M350U	• Stand/MPD&2000 sheet paper drawer (AR-D13) or Three paper drawer stand	
MFP model (45ppm) (Without network printer function)	AR-M450U	(AR-D14) • Power supply unit (AR-DC1)	
MFP model (35ppm) (With NIC card (standard))	AR-M350N		
MFP model (45ppm)	AR-M450N		

3. List of combination of peripheral devices

A.AR-M350U/M450U

As shown in the table below, some other peripheral devices (B) may be needed for installation of a peripheral device (A) and some peripheral devices cannot be installed together.

			L									В											
	Related for scanner feature		B/W scanner module/DSPF	Scanner rack	Stand/3 x 500 sheet paper drawer	Stand/MPD & 2000 sheet	Duplex module/bypass tray	Duplex module	Saddle stitch finisher	Finisher	Mail-bin stacker	Exit tray	Upper exit tray extension	Punch unit	Multi-function controller board	Print server card	PS3 expansion kit	Network scanner expansion kit	Facsimile expansion kit	Fax memory (8 MB)	Power supply unit	Hard disk drive	Network printer kit
	B/W scanner module/DSPF	AR-EF1	_	0	0	*1									0						0		
	Scanner rack	AR-RK1	0	_	Ō	^ !									0						0		Ш
	Related for paper feed unit Stand/3 x 500 sheet paper drawer Stand/MPD & 2000 sheet	AR-D14			×	×															0		
	paper drawer					*1								.,							<u>*</u> 2		
	Duplex module/bypass tray	AR-DU4			0	*1	_		×					×							ở ở		
	Duplex module	AR-DU3	┢																				\vdash
	Output units																						
	Saddle stitch finisher	AR-FN7			0	*1	X	0	-	X		X	X								0		
	Finisher	AR-FN6			0	*1			X	_	X		X	X							0		
Α	Mail-bin stacker	AR-MS1			0	*1				X	_		×								0		
	Exit tray *4	AR-TE3					0	*1	X	X	X	-		X									
	Upper exit tray extension	AR-TE4								×	×		_										
	Punch unit	AR-PN1			0	*1	×	0	0	×		×		_							0		
	Related for extension of functions and others																						
	PS3 expansion kit	AR-PK1															_						
	Network scanner expansion kit	AR-NS2	0	0	0	1										0		_					
	Facsimile expansion kit	AR-FX5	0	0) ^{*1}													_				
	Fax memory (8 MB)	AR-MM9	0	0) ^{*1}													0	_	0		
	Power supply unit	AR-DC1			ζ) ^{*1}																	
	Hard disk drive	AR-HD3																				_	
	Multi-function controller *5	AR-M11	0	0)*1									_								×
	Print server card *6	AR-NC5J														_		O*1					O*1
	Network printer kit	AR-P14														0							_

O = Must be installed together. $O^{*1} = Any$ of the units must be installed together.

O*2= Must be installed for installation of the stand/3 x 500 sheet paper drawer or the stand/MPD & 2000 sheet paper drawer.

 $[\]mathbf{x}$ = Cannot be installed together.

^{*3 =} Standard

^{*4 =} AR-DU4 Standard
*5 = Attachment of the AR-P14 provides the similar functions.
*6 = Not Available

B.AR-M350N/M450N

As shown in the table below, some other peripheral devices (B) may be needed for installation of a peripheral device (A) and some peripheral devices cannot be installed together.

			I									В											ı
																							\exists
	Related for scanner feature		B/W scanner module/DSPF	Scanner rack	Stand/3 x 500 sheet paper drawer	Stand/MPD & 2000 sheet	Duplex module/bypass tray	Duplex module	Saddle stitch finisher	Finisher	Mail-bin stacker	Exit tray	Upper exit tray extension	Punch unit	Multi-function controller board	Print server card	PS3 expansion kit	Network scanner expansion kit	Facsimile expansion kit	Fax memory (8 MB)	Power supply unit	Hard disk drive	Network printer kit
	B/W scanner module/DSPF	AR-EF1	┖	0	Õ										0						0	_	_
	Scanner rack	AR-RK1	0	_	Õ										0						0		_
	Stand/3 x 500 sheet paper drawer	AR-D14			-	×															0		
	Stand/MPD & 2000 sheet paper drawer	AR-D13			×	_															0		
	Duplex module/bypass tray	AR-DU4			O,	+1	_		X					X							Č ²		
	Duplex module	AR-DU3			Ŏ,	+1		_													ð		
	Output units					*1				.,		.,											
	Saddle stitch finisher	AR-FN7 AR-FN6			O O	1	×	0		×		×	X								0	\dashv	\dashv
Α	Finisher	AR-MS1			0 0	1			×	_	×		×	×							0	\dashv	\dashv
А	Mail-bin stacker Exit tray *4	AR-TE3					0	*1		×	×		_	×							0	\dashv	\dashv
	Zat tray	AR-TE3					\Box		X		^ ×	_		^								\dashv	\dashv
	Upper exit tray extension	AR-PN1			O,	*1	×	0	0	×	^	×										\dashv	\dashv
	Punch unit Related for extension of functions and others	AITTIVI					^	U	O	^		^		_							0	1	
	PS3 expansion kit	AR-PK1															_						
	Network scanner expansion kit	AR-NS2	0	0	O	* ¹										0		_					
	Facsimile expansion kit	AR-FX5	0	0)*1													_				
	Fax memory (8 MB)	AR-MM9	0	0	С)* ¹													0	-	0	\neg	\neg
	Power supply unit	AR-DC1			O) ^{*1}															-		
	Hard disk drive	AR-HD3																				-	
	Multi-function controller *3	AR-M11	0	0	C	*1									_								
	Print server card *3	AR-NC5J														_					Ш		
	Network printer kit *6	AR-P14																					

O = Must be installed together. $O^{*1} = Any$ of the units must be installed together. $O^{*2} = Must$ be installed for installation of the stand/3 x 500 sheet paper drawer or the stand/MPD & 2000 sheet paper drawer.

^{★ =} Cannot be installed together.

^{*3 =} Standard

^{*4 =} AR-DU4 Standard *6 = Cannot be attached.

[4] SPECIFICATIONS

1. Basic Specification

A. Base Engine (AR-M350U/M350N/M450U/M450N)

(1) Form

AR-M350U/M350N/M450U/M450N Console type

(2) Engine speed

Paper size	AR-M350U/N	AR-M450U/N
A4, 8.5" x 11"	35ppm	45ppm
A5R/5.5" x 8.5"R	35ppm	45ppm
B5	35ppm	45ppm
B4/8.5" x 14	20ppm	22ppm
A3/11" x 17"	17ppm	20ppm

(3) Engine composition


Photoconductor type	OPC (diameter of photoconductor : ø30mm)
Record method	Electrophotograph (laser)
Development method	Dry-type dual-component magnetic brush
	development
Charge method	Charged saw-tooth method
Transfer method	Transfer roller
Cleaning method	Counter blade
Fusing method	Heat roller
Used toner disposal	Toner recycling system

(4) Engine resolution

Resolution	Write :600dpi
Smoothing	Write:1200dpi equivalent
Gradation	Write :2 levels

(5) Printable area

The print area of this product is shown below.



If a printer driver for Windows or Macintosh is used for printing, the printable area will be smaller. The actual printable area depends on the printer driver to be used.

(in mm)

Paper size	Α	В	С	D	Е
A3	297	420	4	289	4
B4	257	364	4	242	4
A4	210	297	4	202	4
B5	182	257	4	168	4
A5	148	210	4	140	4
Japanese postcard	100	148	4	92	4
Ledger	279	432	4	271	4
Legal	216	356	4	208	4
Foolscap	216	330	4	208	4
Letter	216	279	4	208	4
Executive	184	267	4	183	4
Invoice	140	216	4	132	4
Com-10(envelope)	105	241	4	97	4
C5(envelope)	162	229	4	154	4
Monarch(envelope)	98	191	4	90	4
DL(envelope)	110	220	4	102	4
ISO B5(envelope)	176	250	4	168	4

(6) Warm-up

Warm-up time	less than 80 seconds
Pre-heat requirement	Required
Jam recovery time	Target: about 30 seconds
	(Under standard condition of 60 seconds left
	after side cover opening, polygon motor halt)

(7) Power source

Voltage	100V system	200V system
	100-127V	220-240V
Frequency	50/60Hz	50/60Hz

(8) Power consumption

	AR-M350U/N	AR-M450U/N
Max. Power consump.	1440W	1440W

(9) Energy Star benchmark

	AR-M350U/N	AR-M450U/N
Low power mode	40W	75W
Transition time to Low power mode	60min	60min

(10) Noise

	AR-M350U/N	AR-M450U/N
At working	less than 6.8B	less than 6.8B
At waiting mode	less than 5.0B	less than 5.0B

Showing noise benchmark in each model as a whole system.

(11) Dimensions

External dimensions	428x552x469 (Only main unit) (mm)
(WxDxH)	16.9"x21.7"x18.5"
Occupied space	963x685 (mm) *1
dimensions	25.7"x22.3"
(WxD)	
Weight	AR-M350U/M450U:Approx.38.9kg
	(Only main unit)
	Approx.99kg *1
	AR-M350N/M450N:Approx.39.9kg
	(Only main unit)
	Approx.100kg *1

^{*1:} With B/W scanner module/DSPF, Scanner rack, Large capacity paper feed desk, Power supply unit and Upper exit tray extension

B. Document Feeding Equipment

(1) One-drawer tray (included in the base engine)

•	•	• ,	
Paper feed method	One-drawer tray		
Sizes to be fed	A4, B5, 8.5" x 11"		
Paper capacity	500 sheets (at 80g/m²)		
Media available for	Plain paper 60 - 105g/n	n², 16 - 28lbs	
paper feeding			
Paper type	Plain, recycled, pre-prir	nted, pre-punched,	
	color, letter head		
Paper size switching	To be switched by user		
	(paper size to be entered	ed from the operation	
	panel).		
Dehumidification	Not provided		
heater			
Balance detection	Provided (paper empty	and 3 steps)	
Default size setting	100V system 200V system		
	8.5" x 11"	A4	
Mounting/demounting	Provided	_	
of the tray			

C. Output Equipment

(1) Face-down Exit Tray (included in the base engine)

` '	, ,
Output position/	Face-down output at the upper side of main
method	unit
Output paper capacity	400 sheets (80g/m² sheet)
Output paper size	A3, B4, A4, A4R, B5, B5R, A5R
	11 " x 17", 8.5" x 14", 8.5" x 13", 8.5" x 11 ",
	8.5" x 11 "R, 5.5" x 8.5"R
	Executive, postal card, Monarch (98 x 191)
	Com-10 (105 x 241), DL (110 x 220),
	C5 (162 x 229), ISO B5 (176 x 250)
Spec of media for	Tracing paper : 52 ~ 59g/m² / 14 ~ 15lbs
paper output	Plain paper : 60 ~ 128g/m² / 16 ~ 34lbs
	Index paper: 176g/m ² / 47lbs
	Cover paper : 205g/m ² / 54 ~ 55lbs
	Transparency firm
Remaining paper	Not provided
detection	
Exit tray full detection	Provided

2. Specific Function

A. Printer Function

(1) Platform

IBM PC/AT (Include compatible machine)
Macintosh (680x0), Power Macintosh, iMac, G3Macintosh

^{*} For Macintosh OS, the PS3 expansion kit and NIC card are required.

(2) Support OS

(2) Support OS	
Custom PS	Windows 95/98/Me/XP
	Windows NT 4.0
	Windows 2000
Custom	Windows 95/98/Me/XP
PCL5e/6(XL)	Windows NT 4.0
SPDL	Windows 2000
PPD	Windows 95/98/Me/XP
	Windows NT 4.0
	Windows 2000
	Mac OS 8.5.1 - Mac OS 9

^{*} For Macintosh OS, the PS3 expansion kit and NIC card are required.

(3) PDL emulation

PCL6, PCL5e compatible,	
PostScript Level 2, PostScript 3 compatible	
(PS3 expansion kit is required.)	

(4) Print Function

a. General

		When an optional PS3 expansion kit is installed		
Function	PCL5e/ PCL6	PS	PPD (Windows)	PPD (Macintosh)
Copies	1 - 999	1 - 999	1 - 999	1 - 999
Orientation	Yes	Yes	Yes	Yes
Duplex print	Yes	Yes	Yes	Yes
Saddle stitch	Yes	Yes	No	N/A
Binding edge	Left/top/ right	Left/top/ right	Long/short	Long/short
N-up	2/4/6/8	2/4/6/8	2/4*3*4	2/4/6/9/16
N-up direction	Fixed	Fixed	Fixed	Selectable
N-up border line	Yes	Yes	Yes(always)	Yes

b. Paper input

		When an installed	optional PS3	expansion kit is
Function	PCL5e/	PS	PPD	PPD
	PCL6		(Windows)	(Macintosh)
Paper size	Yes	Yes	Yes	Yes
Custom paper size	1 size	1 size	3 sizes*3*5	N/A
Source selection	Yes	Yes	Yes	Yes
Different first page	Yes	Yes	N/A	Yes
Transparency inserts	Yes	Yes	N/A	Yes

c. Paper output

		When an optional PS3 expansion kit installed		xpansion kit is
Function	PCL5e/	PS	PPD	PPD
	PCL6		(Windows)	(Macintosh)
Output tray selection	Yes	Yes	Yes	Yes
Mail bin	Yes	Yes	Yes	Yes
Staple	Yes	Yes	Yes	Yes
Offset	Yes	Yes	Yes	Yes
Punch	Yes	Yes	Yes	Yes

d. Graphic

		When an optional PS3 expansion kit is installed		
Function	PCL5e/ PCL6	PS	PPD (Windows)	PPD (Macintosh)
Resolution	600/300 dpi	600 dpi	600 dpi	600 dpi
Halftone	N/A	Yes	Yes	N/A
Graphic mode	Yes	N/A	N/A	N/A
Smoothing	Yes	Yes	Yes	Yes
Toner save	Yes	Yes	Yes	Yes
Photo enhancement	Yes*8	Yes	N/A	N/A
Negative image	N/A	Yes	Yes	Yes
Mirror image	N/A	Horizontal/ vertical	Horizontal	Yes
Zoom	N/A	N/A	Yes	Yes
Fit to page	Yes	Yes	N/A	N/A

e. Font

		When an opti	onal PS3 ex	pansion kit is
Function	PCL5e/ PCL6	PS	PPD (Windows)	PPD (Macintosh)
Resident font	45 fonts	136 fonts	136 fonts*6	35 fonts
Download font	Bitmap TrueType, Graphic	Bitmap Type1 TrueType	Bitmap Type1 TrueType	N/A

f. Others

		When an opt installed	ional PS3 ex	pansion kit is
Function	PCL5e/ PCL6	PS	PPD (Windows)	PPD (Macintosh)
Watermark*7	Yes	Yes	Yes	Yes
Overlay	Yes	Yes	N/A	N/A
Job retention*1	Yes	Yes	N/A	Yes
Account control	Yes	Yes	N/A	Yes
Custom settings	Yes	Yes	N/A	N/A
Automatic configuration*2	Yes	Yes	N/A	Yes
Job end notification	Yes	Yes	N/A	N/A

- * 1 In the models without a hard disk drive, an optional hard disk drive must be installed .
- * 2 Functions when peripheral devices are installed.
- * 3 Not supported in the Windows NT 4.0 environment.
- * 4 $\,$ 2/4/6/9/16 is supported in the Windows 2000 environment.
- * 5 Only one size is supported in the Windows 2000 environment.
- * 6 Only 35 fonts are supported in the Windows NT 4.0 environment.
- * 7 This function is limited for PPD.
- * 8 PCL6 only

(5) Compatibility

PCL 5e	Target for PCL5e is to be compatible with HP LaserJet
compatibility	4000.
	Small margin difference, rendering difference by
	different font family, default and transfer function
	difference are not to be included in the compatibility.
	All the PJL commands are not necessarily included in
	the compatibility.
PCL6	Target for PCL6 is to be compatible with HP LaserJet
compatibility	4000.
	Small margin difference, rendering difference by
	different font family, default and transfer function
	difference are not to be included in the compatibility.
	All the PJL commands are not necessarily included in
	the compatibility.
PostScript	Roman PostScript is targeted to be compatible with
Compatibility	Adobe PostScript as performed in HP LaserJet 4000.
	Small margin difference, rendering difference by
	different font family, default and transfer function
	difference are not to be included in the compatibility.

B. Expanded RAM

Installation of an expanded RAM will avoid the following status.

- 1) Time out error reduction
- 2) Spool time reduction
- 3) Avoidance of VM error / memory full

Use commercially available RAM with the following specifications.

Note: If RAM used does not meet the follow specifications, the copier may not recognize the additional RAM or its capacity correctly.

<Spesification>

DIMM TYPE	168pin 3.3V Unbuffered SDRAM DIMM Non-ECC
DIMM capacity	64MByte, 128MByte, 256MByte
CAS LATENCY	CL=2
SDRAM CLOCK	For PC100, PC133
SPD	Supporting
Parity	Not support
ECC	Not support

<Operation-assured Memory> (As of March / 2001)

Manufacture	Capacity	Model name	RAM CHIP name	Note
Kingston	128MB	KVR133X64C3/	HYB39S64800BT	
Technology		128	-7.5	
	128MB	KVR133X64C3	D456821G-A75	
		-128	-9JF	
	256MB	KVR133X64C3 -256	HY57V28820AT-H	
Viking	64MB	VIK8641CL2	μPD456841G5	
Compornents			-A80-9JF	
	64MB	VIK8641CL2	D456841G5-A80 -9JF	
	128MB	VIK6642CL2	TC59SM708FT-80	
	128MB	VIK6642CL2	D4564841G5-A80 -9JF	
	256MB	VIK2642CL2	TC59SM708FT-80	
Memory Card Technology	64MB	DM864VS65804X -7G	GM72V66841XT75	
	128MB	DM1665VS65804 X-7G	HY57V64820HG	

C. Scanner function

*Scanner function, the NIC card and Network Scanner kit are required.

(1) Scanner function

Scanner mode	Scan to E-mail (Internet FAX)
	Scan to Server (Client PC)

(2) Support System

Embedded server	SMTP server
	FTP server
Protocol	TCP/IP

(3) Support Image

Format	TIFF, PDF, TIFF-F
	* Selectable for each page
Compression method	Uncompressed, G3(1-dimension) *1, G4 *2
	*1 G3 (1-dimension) = MH (Modified Huffman)
	*2 G4 = MMR (Modified MR)

(4) Transmission Mode

DSPF/OC	Available
transmission switching	(Switching during the reading is not feasible)

(5) Image Process

Half tone reproduction	Equivalent to 256 levels
Exposure adjustment	Light / Auto / Dark
Quality selection	Half-tone ON/OFF
Resolution*	Normal (200x200dpi)
	Fine (300x300dpi)
	Super fine (400x400dpi)
	Ultra fine (600x600dpi)
	Varies with the file type/transmission method

(6) Original Memory

Standard	Commonly use ERDH area of memory.
Memory expansion	Special : As per ERDH memory

(7) Specified Destination

Specified destination	Specifying by one-touch or group
One-touch*	Max. 500 destinations
	(in conjunction with the one-touch dial of FAX)
	Max. 100 destinations can be registered
	for FTP and Desktop.
Group*	To be registered in one-touch
Program	Available

(8) Specified Multiple Destinations

Specified destination	Specifying by one-touch or group
No. of registration	Max. 300 items
	(in conjunction with those of FAX)
Sequential	Available
broadcasting	(E-mail only. It is not available for FTP/Desktop.)
Simultaneous FAX	Available
transmission	(Specifying multiple destinations of FAX, E-mail or FTP and broadcasting by a single scan)

O : Available

(9) Functions

Transmitting	Rotating transmission	Available
functions		(to be matched with FAX
		specification)
	Long length original	Not Available
	transmission	
	Verification stamp function	Option
Report/list	Transmit/receive record	Available
functions	Transmit/receive result	Available
	Address/phone directory	Available
	list	
	Group list	Available
	ID/sender list	Available
	Program list	Available

D. Copy function

(1) Copy Speed

		AR-M350	U/N	AR-M450U/N				
	Actual	Reduction	Enlargement	Actual	Reduction	Enlargement		
A4, 8.5"x11"	35	35	35	45	45	45		
A4R, 8.5"x11"R	25	25	25	30	30	30		
A5R, 5.5"x8.5"R, Invoice-R	35	35	35	45	45	45		
B5	35	35	35	45	45	45		
B5R, Exective-R	25	25	25	30	30	30		
B4, 8.5"x14"	20	20	20	22	22	22		
A3, 11"x17"	17	17	17	20	20	20		
Extra, Envelope	17	17	17	20	20	20		
Japan P/C	n P/C In case of printing on post card, engine speed can vary with system configuration, because next paper is fed after machine completely outpu previous page.							

Figures in reduction/enlargement are represented by those at the ratio to show slowest speed

(2) First Copy Time

Conditions: A4 or 8.5"x11"P from front tray of PPC, without HDD and with polygon motor running.

	AR-M350U/N	AR-M450U/N
Document glass *1	Less than 5.3 seconds	Less than 4.6 seconds
DSPF	Less than 6.0 seconds	Less than 5.3 seconds

^{*1} During OC/high-speed mode

(3) Job Speed

	AR-M350U/N	AR-M450U/N
S → S *1	33 cpm (94%)	42 cpm (93%)
S → D *2	32 cpm (91%)	40 cpm (88%)
D → D *3	32 cpm (91%)	40 cpm (88%)

*1 S \rightarrow S : A4 / 8.5" x 11"P original 5 sheets copy 5sets *2 S \rightarrow D : A4 / 8.5" x 11"P original 10 sheets copy 5sets *3 D \rightarrow D : A4 / 8.5" x 11"P original 5 sheets (10 pages) copy 5sets

Note: First copy time has been factored into calculation resulting in reduced CPM.

(4) Continuous Copy

Max. multiple number	999 pages

(5) Copy Ratio

Copy ratio	AB series :
	25%, 70%, 81%, 86%, 100%, 115%, 122%, 141%, 400%
	Inch series :
	25%, 64%, 77%, 100%, 121%, 129%, 400%
Zoom	25 - 400%
	25 - 200% (Copy from DSPF)
Independent	Not provided
scaling	

(6) Exposure/Copy Quality Process

• •	
Exposure mode	Binary: Text(auto/manual), Text/photo, Photo
	256 levels: Not provided
Manual steps	9 steps
Smoothing	Standard
Toner save mode	Standard

(7) Copy Function

Function	APS	Standard Function		
i unction	AMS	Standard Function		
	Paper type select	Standard Function		
	raper type select			
	Auto tray switching	(By type setting) Standard Function		
	Rotation copy	Standard Function		
	Electronic sort	Standard Function		
	Rotation sort	Not provided		
	Reserved copy	Standard Function		
	Prior tray setting	Not provided		
	Recall/register of program	Standard Function		
	Proof copy	Not provided		
	Preheat function	Standard Function		
		(To be set up by key		
		operator)		
	Auto power shut-off function	Standard Function		
		(To be set up by the key		
		operator program)		
	Account control	Standard Function		
		(100 accounts)		
	Communication support (RIC)	Standard Function		
	Card counter support	Only		
	''	provided the connector		
	Coin vendor support	Only		
	ээн танаан зарран	provided the connector		
Special	Margin shift	Standard Function		
function	Edge erase / Center erase	Standard Function		
	Dual page copying	Standard Function		
	Covers	Not provided		
	Transparency insert	Not provided		
	Centering	Not provided		
	Multi shot (N in 1)	Standard Function		
	Width Shot (IV III 1)	(2 in 1 / 4 in 1)		
	Pamphlet copy	Standard Function		
	2-sided copy orientation change	Standard Function		
	Large capacity original mode	0 (Max. 140 pages)		
	B/W reverse	Not provided		
	Shading	Not provided		
	Mirror image	Not provided		
	Repeat	Not provided		
	Date stamp	Not provided		
	Stamp	Not provided		
	Page stamp	Not provided		
1	Zaurus print	Not provided		

[5] CONSUMABLE PARTS

1. Supply system table

Note: The consumable parts are the same as those of the AR-M350/M450 and the AR-P350/P450.

A.USA

NO	Name	Content		Life	Product name	Remark
1	Toner CA(Black)	Toner(Toner : Net Weight 814g)		27K	AR-450NT	*Life setup is based on A4 6%
					(*1 AR-450NT-J)	
2	Developer	Developer(Developer : Net Weight 450g)		100K	AR-450ND	
3	Drum	Drum	x1	50K	AR-450DR	
4	50K maintenance kit	Cleaner blade	x1	50K	AR-450KC1	
		Drum separation pawl	x4			
		Screen grid	x1			
		Toner reception seal	x1			
		Side malt F	x1			
		Side malt R	x1			
		Charging plate	x1			
5	100K maintenance kit	Transfer roller	x1	100K	AR-450KA1	
		Discharging plate	x1			
		Paper dust removing unit	x1			
		DV blade	x1			
		DV side seal F	x1			
		DV side seal R	x1			
6	Upper heat roller kit	Upper heat roller	x1	200K	AR-450UH	
		Fusing separation pawl (Upper)	x4			
7	Lower heat roller kit	Lower heat roller	x1	200K	AR-450LH	
		Fusing separation pawl (Lower)	x2			
8	Cleaner blade	Cleaner blade	x10	50K(x10)	AR-450CB	AR-450CB=(AR-450BL)x10
9	Cleaning roller	Cleaning roller	x10	200K(x10)	AR-450CR	AR-450CR=(AR-450RC)x10
		Bearing	x20			
10	Staple cartridge	Staple cartridge	х3	3000x3	AR-SC1	Common with cartridge for AR-FN4 & AR-FN6
11	Staple cartridge	Staple cartridge	x3	5000x3	AR-SC2	Common with cartridge for AR-FN7
	Staple cartriage	Staple cartriage	χð	5000X3	An-302	Common with cartilage for AR-FN7

^{*1:} For USA Government

Note1: Print on Master/individual carton:Toner/Developer in 2 languages (English/French), DR in 4 languages (English/French/German/Spanish).

Note2: Packed with machine: DR 50K/Developer UN/Process UN

Note3: The other maintenance parts which are not listed above are registered as service parts.

B.Europe

NO	Name	Content		Life	Product name	Remark
1	Toner CA(Black)	Toner(Toner : Net Weight 814g)		27K	AR-450T	*Life setup is based on A4 6%
2	Developer	Developer(Developer : Net Weight 450g)		100K	AR-450DV	
3	Drum	Drum	x1	50K	AR-450DM	
4	50K PM kit	Cleaner blade	x1	50K	AR-450KC	
		Drum separation pawl	x4			
		Screen grid	x1			
		Toner reception seal	x1			
		Side malt F	x1			
		Side malt R	x1			
		Charging plate	x1			
5	100K PM kit	Transfer roller	x1	100K	AR-450KA	
		Discharging plate	x1			
		Paper dust removing unit	x1			
		DV blade	x1			
		DV side seal F	x1			
		DV side seal R	x1			
6	200K PM kit	Upper heat roller	x1	200K	AR-450KB	
		Lower heat roller	x1			
		Fusing separation pawl (Upper)	x4			
		Fusing separation pawl (Lower)	x2			
		Cleaning roller	x1			
		Bearing	x2			
7	Staple cartridge	Staple cartridge	хЗ	3000x3	AR-SC1	Common with cartridge for AR-FN4 & AR-FN6
8	Staple cartridge	Staple cartridge	хЗ	5000x3	AR-SC2	Common with cartridge for AR-FN7

Note1: Print on Master/individual carton:4 languages (English/French/German/Spanish).

Note2: Packed with machine: DR 50K/Developer UN/Process UN

Note3: The other maintenance parts which are not listed above are registered as service parts.

2. Production number identification

A. Drum cartridge

The lot number, printed on the front side flange, is composed of 10 digits, each digit showing the following content:

1 2	3	4	5	6	7	8	9	10
-----	---	---	---	---	---	---	---	----

1 Number

For this model, this digit is 2.

2 Alphabet

Indicates the model conformity code. T for this model.

3 Number

Indicates the end digit of the production year.

4 Number or X, Y, Z

Indicates the production month.

X stands for October, Y November, and Z December.

5/6 Number

Indicates the production day on the month.

7 Number or X, Y, Z

Indicates the month of packing.

X stands for October, Y November, and Z December.

8/9 Number

Indicates the day of the month of packing.

10 Alphabet

Indicates the production factory. "A" for Nara Plant.

B. Toner cartridge

The lot number is composed of 7 digits, and each digit indicates as following.

The lot number shall is printed in the position shown below.

1	2	વ	1	5	6	7
	_	0	-	J	U	,

- 1 Version number (A sequentially revised)
- 2 Numeral figure

Indicates the end digit of the production year.

3 Alphabet

Indicates the production factory. (B for SOCC)


- 4 Destination code
- 5,6 Numeral figures


Indicates the production day.

7 Numeral figure or X, Y, Z

Indicates the production month.

 \boldsymbol{X} stands for October, \boldsymbol{Y} November, and \boldsymbol{Z} December.





C. Developer

The lot number is composed of 8 digit, and each digit indicates as following.

The lot number shall be printed on the bag.

1	2	3	4	5	6	7	8
---	---	---	---	---	---	---	---

1 Alphabet

Indicates the production factory.

2 Figure

Indicates the production year.

3/4 Figure

Indicates the production month.

5/6 Figure

Indicates the production day.


7 Hyphenation

8 Figure


Indicates the production lot.

3. Environmental conditions

A. Operating conditions



B. Storage conditions



[6] UNPACKING AND INSTALLATION


1. Installing procedure flowchart


There are many combinations between this machine and option units. For installing option units, observe the following procedures for efficiency.

To install the devices efficiently, follow the procedure below.

Some peripheral devices may have been installed as standard devices depending on the main unit model.

Part of descriptions and illustrations may be different.






* When installing an option, refer to the Service Manual for that option and or the AR-M350 / M450 Service Manual.

2. AR-P14 installing procedure

<Before installation>

- This installation procedure is provided for use with the AR-M350U/ M450U series.
- * To connect this machine to a network, a Print Server Card (NIC) AR-NC5J must be installed to the multi-function controller board in advance.



* To enable the printer expansion function, the product key must be acquired.

The application number, machine serial number, and product key number are important information.


Keep the above information for future reference.

- 1) Mount the printer expantion kit ROMs to the control PWB.
- <1>Turn off the main switch of the main unit of the printer

Turn the main switch located on the front side of the main unit to the "OFF" position.


If the machine is equipped with a facsimile unit, also turn off the FAX power switch.

Then remove the power plug from the outlet.



<2>Remove the cables connected to the control PWB unit.


Remove all the cables connected to the control PWB unit of the main unit of the printer.



<3>Remove the control PWB unit.

Remove the five screws that fix the control PWB unit to the main unit of the printer.

Then, hold the two grips and pull out the control PWB unit to remove it from the main unit.




<4>Mount the printer expansion kit ROMs(2 pcs.)to the control PWB.

Remove the ROMs(main and boot ROMs)from the control PWB and replace them with the two ROMs(main and boot ROMs)of the printer expansion kit.


The main and boot ROMs are indicated with "MAIN" and "BOOT" on the labels on the ROMs respectively.

When mounting the printer expansion kit ROMs, insert them to the same positions in the same direction as those before replacement and ensure that the inserted printer expansion kit ROMs are locked with the fittings of the sockets.




<5>Re-attach the control PWB.

Attach the control PWB to the main unit of the printer and fix it using five screws.



<6>Connect the cables to the control PWB.


Connect all the cables that have been removed in <2> to the original positions of the control PWB unit.



If another peripheral device must be installed, carry out the following steps at the end of the installation work.

2) Turn on the main switch of the main unit of the printer. Insert the power plug of the main unit of the printer to the outlet. Then, turn the main switch located on the front side of the main unit to the "ON" position.

If the machine is equipped with a facsimile unit, turn on the FAX power switch.



3) Prepare to enable the printer expansion function.

To enable the printer expansion function, use the keys on the operation panel to enter the product key.

For entry of the product key, see the key operator's guide of the operation manual for the main unit.

Carry out the network setting for the Print Server Card.

Use a key operator program to carry out the network setting for this machine. For this network setting, the customer's network environment must be checked. Consult the network administrator to carry out the setting.

In addition to the network setting for this machine, to use the machine in the network environment:

According to the customer's network environment, install the driver software from the CD-ROM supplied with this machine and use the utility software supplied with the Print Server Card to set the network printer for the server computer.

For installation in the server computer and network setting, see the operation manual supplied with the main unit.

This setting must be carried out by the network administrator or based on consultation with the network administrator.

4) To check the operation of the printer expansion function.

When the network settings and the driver settings are complete, perform a test print to check if printing can be performed successfully.

(When test printing is completed successfully, use the "list print" key operator program to print the network settings and keep the printout for future reference.)

Installation of AR-P14 is now complete.

[7] MAINTENANCE

1. Self print of set values

Use SIM 22-6 to print the set values (machine settings) and jam history.

These values must be printed before execution of maintenance or disassembly procedures.

2. Maintenance System Table

The maintenance system table is the same as that of the AR-M350/M450.

A. Scanner / DSPF

				IVIa	iintenance cycle : 50K
imes Check (Clean, replace, or adjust as necessary.)	O Clean	▲ Replace	△ Adjust	☆ Lubricate	☐ Move position

Unit name	Part name		When calling	50K	100K	150K	200K	250K	300K	350K	400K	Remark
Optical section	Mirror/Lens/Reflector/	Sensors	0	0	0	0	0	0	0	0	0	
	Table glass/OC		0	0	0	0	0	0	0	0	0	
	White reference glass		0	0	0	0	0	0	0	0	0	
	Rails			☆	☆	☆	☆	☆	☆	☆	☆	
	Drive belt/Drive wire/P	ulley		×	X	×	×	×	×	×	×	
DSPF	Paper feed section	Take-up roller	0	0	A	0	A	0	A	0	A	Note 2
		Separation pad	0	0	A	0	A	0	A	0	A	Note 2
		Paper feed roller	0	0	A	0	A	0	A	0	A	Note 2
	Transport section	PS roller	0	0	0	0	0	0	0	0	0	
		Exposure section (Dust-proof glass)	0	0	0	0	0	0	0	0	0	
	Paper exit section	Paper feed roller SPF	0	0	0	0	0	0	0	0	0	
	Other	Sensors			0		0		0		0	For cleaning, blow air.
	Finish stamp section	Stamp solenoid									A	
	[Option] (Japan only)	Stamp individual part	×	×	×	×	×	×	×	X	×	User replacement at 10K or 1 year.

Note 2: Replacement reference: Same as above or 2 years.

B. Engine section

For disassembly procedures, refer to the AR-P350/P450 Service Manual.

				Ma	aintenance cycle : 50k
X Check (Clean, replace, or adjust as necessary.)	O Clean	▲ Replace	△ Adjust		☐ Move position

Unit name	Part name	When calling	50K	100K	150K	200K	250K	300K	350K	400K	Remark
Drum peripheral	Drum		A	Installed when shipping							
	Cleaner blade		A	A	_	A	A	A	A	A	
	Toner reception seal		A								
	Side molt		A								
	Transfer roller	×	×	A	×	A	×	A	×	A	
	Discharge plate	×	×	A	×	A	×	A	×	A	
	TR bearing (F/R)			X		×		×		A	
	Transfer roller collar			X		×		×		A	
	After-transfer star ring			×		×		×		×	
	TR gear	×	X	X	×	A	X	×	×	A	
	Screen grid	(O)×	A	A	_	A	A	A	A	A	
	Drum separation pawl UN		A								
	Charger case (M/C)		0	0	0	0	0	0	0	0	
	Charging plate (saw teeth)	(O)×	•	•	•	•	A	A	A	•	
Developing section	Developer		×	A	×	A	×	A	X	A	Supplied when installing
	DV blade		×	A	×	A	×	A	X	A	
	DSD collar		0	0	0	0	0	0	0	0	
	DV side seal F		X	_	X	A	×	A	×	A	
	DV side seal R		X	_	X	_	×	A	X	_	
	Toner cartridge										Attached when installing./ EX Japan: 814g, user replacement for every 27K.
Fusing section	Upper heat roller		0	0	0	A	0	0	0	A	
	Lower heat roller		0	0	0	A	0	0	0	A	
	Upper separation pawl		A								
	Lower separation pawl		A	_	A	A	A	A	A	A	
	Thermistor		0	X	0	×	0	×	0	X	Clean and remove paper dust.
	Upper heat roller gear		×	X	X	A	X	×	×	A	
	Paper guides	0	0	0	0	0	0	0	0	0	
	Gears		☆	☆	☆	☆	☆	☆	☆	☆	
	Cleaning roller		X	X	X	A	X	X	×	A	
	CL roller collar					_				A	
Filters	Ozone filter			A		A		A		A	
Paper feed section	Paper feed roller	0	0	X	0	×	0	×	0	X	Note 1
	Torque limiter	×		X		X		×		X	Note 1
Transport section	PS follower roller	0	0	0	0	0	0	0	0	0	
Paper exit reverse section	Transport rollers	0	0	0	0	0	0	0	0	0	
	Transport paper guides	0	0	0	0	0	0	0	0	0	
	Paper dust remover		X	A	X	A	X	A	×	A	
Drive section	Specified position	☆	☆	☆	☆	☆	☆	☆	☆	☆	
	Belts	1	<u> </u>			ļ · ·		×			
Image quality		X	×	×	×	×	×	×	×	×	
Other	Sensors	, ,	, ,	X		×	,,	×	, ,	X	
	1	1	L			_ ^ `	1	- ` `		_ ^ `	

Note 1:Replacement reference: Use the counter value of each paper feed port as the replacement reference.

Paper feed roller/Torque limiter section: 80K or 2 years

C. Peripheral devices

Option name	Part r	iame	When calling	50K	100K	150K	200K	250K	300K	350K	400K	Remark
ADU + Manual feed	Paper feed separation section	Paper feed rollers	(O)×	0	×	0	×	0	×	0	×	Note 3
		Separation pad	(O)×	0	X	0	×	0	X	0	X	Note 3
		Torque limiter	(O)×		X		×		X		X	Note 3
	Transport section	Transport rollers	0	0	0	0	0	0	0	0	0	
		Transport paper guides	0	0	0	0	0	0	0	0	0	
	Drive section	Gears	☆		☆		☆		☆		☆	(Specified position)
		Belts							×			
	Other	Sensors	×		×		×		X		×	
Desk (Multi stage LCC)	Paper feed separation section	Paper feed rollers	(O)×	0	×	0	×	0	×	0	×	Note 3
Multi purpose		Torque limiter	(O)×		×		×		×		×	Note 3
	Transport section	Transport roller	0	0	0	0	0	0	0	0	0	
		Transport paper guides	0	0	0	0	0	0	0	0	0	
	Drive section	Gears	☆		☆		☆		☆		☆	(Specified position)
		Belts							X			
	Other	Sensors	×		X		×		X		X	
Finisher	Transport section	Transport rollers	0		0		0		0		0	
		De-curler roller	(O)×	X	0	×	0	X	0	×	0	
		Transport paper guides	0		0		0		0		0	
	Drive section	Gears	☆		☆		☆		☆		☆	(Specified position)
		Belts							X			
	Other	Sensors	×		X		×		X		X	
		Discharge brush	×		X		×		X		×	
	Staple un	l.										Replace UN at 100K staple.
	Staple cartridge											User replacement for every 3000pcs.
Mail-bin	Transport section	Transport roller	0		0		0		0		0	
stacker		Transport paper guides	0		0		0		0		0	
	Drive section	Gears	☆		☆		☆		☆		☆	(Specified position)
		Belts							X			
	Other	Sensors	×		×		×		×		×	
		Discharge brush	×		×		×		×		X	
Saddle finisher	Transport section	Transport roller	0		0		0		0		0	
		Transport paper guides	0		0		0		0		0	
	Drive section	Gears	☆		☆		☆		☆		☆	(Specified position)
		Belts							×			
	Other	Sensors	×		×		X		×		×	
		Discharge brush	×		×		×		×		X	
	Staple UN											Replace UN at 100K staple (including the staple UN and the holder section).
	Staple cartridge											User replacement for every 5000 pcs.

Note 3: Replacement reference: Use the counter value of each paper feed port as the replacement reference.

Paper feed roller/Separation pad/Torque limiter section: 80K or 2 years

[8] SIMULATION

For the simulation, the following items have been changed.

22-10

Purpose	Adjustment, setup, operation data output, check
	(display)
Function (Content)	Used to check the system configuration
	(option, internal hardware).
Section	
Item	Spec
Operation/Procedure	The machine composition below is displayed.

SIMULATION 22-10
SYSTEM INFORMATION.
MACHINE: ********
SPF: ******* XXXXXXXXXX
FINISHER: ******* MAIL BIN: ******** PUNCH: *******
DESK/LCC: ******* ADU: ******** XXXXXXXXXX
PROCESS TYPE: *
SYSTEM MEMORY: **MB HDD: ***MB ICU F ******
NIC: ******* NSCN: ****** PS3: ******
FAX: ******* FAX MEMORY: **MB HAND SET: *******
STAMP: ********

<List of display value>

MACHINE	Model codes
SPF	NONE/ (Model code)
FINISHER	NONE/ (Model code)
MAIL BIN	NONE/ (Model code)
PUNCH	NONE/ (Model code)
DESK/LCC	NONE/ (Model code)
ADU	NONE/ (Model code)
PROCESS TYPE	Process control spec
	(1, 2: AR machine 3: DM machine)
SYSTEM MEMORY	Memory capacity (MB)
HDD	Hard disk capacity (MB)
ICU	PRINTER/MFP
NIC	NONE/ (Model code)
NSCN	NONE/ (Network scanner)
PS3	NONE/ (PS3 expansion kit)
FAX	NONE/ (Model code)
FAX MEMORY	FAX expansion memory capacity (MB)
HAND SET	NONE/ (Model code)
STAMP	Finisher stamp NONE/ (Model code)

<List of machine model codes>

	ne model codes>	
Item MACHINE	Display AR-P350/350LP	Content
IVIACHINE	AR-P350/350LP	
		(Include the N model)
	AR-M350/350M	(Include the N model)
	AR-M450/450M	(include the N Hodel)
	AR-310M AR-M350U	
	AR-M350U AR-M450U	
	AR-310S/310F	
	AR-350S/350F	
	AR-450S/450F	
SPF	An-4505/450F	Document feed unit not installed
SFF	AR-EF2	Document feed unit (SPF) installed
	AR-EF1	Duplex document feed unit installed
FINISHER	An-Li i	After-work unit not installed
FINISHER	AR-FN6	Built-in finisher installed
	AR-FN7	Console finisher installed
MAIL BIN	An-FN/	Mail bin not installed
INIVIE DIIA	AR-MS1	Mail bin installed
Punch unit		Punch unit not installed
i union unit	AR-PN1A	Punch unit 2 holes
	AR-PN1B	Punch unit 3 holes
	AR-PN1C	Punch unit 4 holes
	AR-PN1D	Punch unit 4 holes wide hole
ADU	-	Duplex module not installed
ADO	AR-DU3	Duplex module installed
	AR-DU4	Duplex module +
	AIT-DOT	manual feed unit installed
DESK	-	Paper feed desk not installed
	AR-MU1	Multi-purpose tray installed
	AR-D14/D15	Paper feed desk installed
	AR-D13	Tandem desk installed
ICU	PRINTER	Printer board
	AR-M11	MFP board
	AR-M12 *	MFP board (U model)
	AR-M13 *	MFP board (S model)
MEMORY	0MB	No expansion memory
	***MB	Expansion memory ***MB
HD	0MB	Hard disk not installed
	****MB	Hard disk installed (AR-HD3)
NIC	-	NIC not installed
	AR-NC5J	NIC installed
PS3	-	PS3 expansion kit not installed
expansion kit	AR-PK1	PS3 expansion kit installed
FAX	-	FAX expansion kit installed
	AR-FX5	FAX expansion kit not installed
Network	-	Network expansion kit not installed
scanner	AR-NS2F	Network expansion kit installed
Expansion memory	-	Expansion memory for FAX not installed
	AR-MM9	Expansion memory for FAX 8MB (AR-MM9) installed
Handset	-	handset not installed
	AR-HN5	Handset installed
Finish stamp	-	Finish stamp unit not installed
	AR-SU1	Finish stamp unit installed
	I.	1


^{*:} Not registered as a product.


[9] CIRCUIT DIAGRAM

1. MFP Control PWB(for AR-M350U/M450U)


A.Block Diagrams


General







ROM Block (Flash & Mask)








PCI-Bus









































































































































CAUTION FOR BATTERY REPLACEMENT

(Danish)

ADVARSEL!

Lithiumbatteri – Eksplosionsfare ved fejlagtig håndtering. Udskiftning må kun ske med batteri af samme fabrikat og type. Levér det brugte batteri tilbage til leverandoren.

(English)

Caution!

Danger of explosion if battery is incorrectly replaced.
Replace only with the same or equivalent type
recommended by the manufacturer.

Dispose of used batteries according to manufacturer's instructions.

(Finnish)

VAROITUS

Paristo voi räjähtää, jos se on virheellisesti asennettu. Vaihda paristo ainoastaan laitevalmistajan suosittelemaan tyyppiin. Hävitä käytetty paristo valmistajan ohjeiden mukaisesti.

(French)

ATTENTION

Il y a danger d'explosion s' il y a remplacement incorrect de la batterie. Remplacer uniquement avec une batterie du même type ou d'un type équivalent recommandé par le constructeur.

Mettre au rebut les batteries usagées conformément aux instructions du fabricant.

(Swedish)

VARNING

Explosionsfara vid felaktigt batteribyte.
Använd samma batterityp eller en ekvivalent
typ som rekommenderas av apparattillverkaren.
Kassera använt batteri enligt fabrikantens
instruktion.

(German)

Achtung

Explosionsgefahr bei Verwendung inkorrekter Batterien.
Als Ersatzbatterien dürfen nur Batterien vom gleichen Typ oder
vom Hersteller empfohlene Batterien verwendet werden.
Entsorgung der gebrauchten Batterien nur nach den vom
Hersteller angegebenen Anweisungen.

CAUTION FOR BATTERY DISPOSAL

(For USA, CANADA)

Contains lithium-ion battery. Must be disposed of properly.
Remove the battery from the product and contact
federal or state environmental
agencies for information on recycling and disposal options.



COPYRIGHT © 2002 BY SHARP CORPORATION

All rights reserved.
Printed in Japan.
No part of this publication may be reproduced,
stored in a retrieval system, or transmitted,
in any form or by any means,
electronic, mechanical, photocopying, recording, or otherwise,
without prior written permission of the publisher.

Trademark acknowledgments

Windows and Windows NT are trademarks of Microsoft Corporation in the U.S.A. and other countries.

IBM and PC/AT are trademarks of International Business Machines Corporation. PCL is a trademark of Hewlett-Packard Company.


Pentium is a registered trademark of Intel Corporation.

All other trademarks and copyrights are the property of their respective owners.

SHARP CORPORATION
Digital Document System Group
Products Quality Assurance Department
Yamatokoriyama, Nara 639-1186, Japan

SHARP SERVICE MANUAL

CODE: 00ZARP350/A1E



LASER PRINTER AR-P350 MODEL AR-P450

OPTIONS AR-HD3 / AR-PK1

_	CONTENTS
	[1] GENERAL 1-1
	[2] CONFIGURATION
	[3] SPECIFICATIONS 3 - 1
	[4] CONSUMABLE PARTS
	[5] EXTERNAL VIEWS AND INTERNAL STRUCTURES 5 - 1
	[6] UNPACKING AND INSTALLATION 6 - 1
	[7] DISASSEMBLY AND ASSEMBLY, MAINTENANCE 7 - 1
	[8] MACHINE OPERATION
	[9] ADJUSTMENTS9-1
	[10] DIAG
	[11] TROUBLE CODES
	[12] CIRCUIT DIAGRAM
	[13] OTHERS 13 - 1

Parts marked with "__" are important for maintaining the safety of the set.

Be sure to replace these parts with specified ones for maintaining the safety and performance of the set.

CAUTION

This product is a class 1 laser product that complies with 21CFR 1040.10 and 1040.11 of the CDRH standard and IEC825. This means that this machine does not produce hazardous laser radiation. The use of controls, adjustments or performance of procedures other than those specified herein may result in hazardous radiation exposure.

This laser radiation is not a danger to the skin, but when an exact focusing of the laser beam is achieved on the eye's retina, there is the danger of spot damage to the retina.

The following cautions must be observed to avoid exposure of the laser beam to your eyes at the time of servicing.

- 1) When a problem in the laser optical unit has occurred, the whole optical unit must be exchanged as a unit, not as individual parts.
- 2) Do not look into the machine with the main switch turned on after removing the developer unit, toner cartridge, and drum cartridge.
- Do not look into the laser beam exposure slit of the laser optical unit with the connector connected when removing and installing the optical system.
- 4) The middle frame contains the safety interlock switch.

 Do not defeat the safety interlock by inserting wedges or other items into the switch slot.

Warning!

This product is a class A product.

If it is operated in households, offices or similar surroundings, it can produce radio interferences at other appliances, so that the user has to take adequate countermeasures.

CLASS 1 LASER PRODUCT

LASER KLASSE 1

LUOKAN 1 LASERLAITE

KLASS 1 LASERAPPARAT

CAUTION

INVISIBLE LASER RADIATION,
WHEN OPEN AND INTERLOCKS DEFEATED. AVOID
EXPOSURE TO BEAM.

VORSICHT

UNSICHTBARE LASERSTRAHLUNG, WENN ABDECKUNG GEÖFFNET UND SICHERHEITSVERRIEGELUNG ÜBERBRÜCKT. NICHT DEM STRAHL AUSSETZEN.

VAROITUS!

LAITTEEN KÄYTTÄMINEN MUULLA KUIN TÄSSÄ KÄYTTÖOHJEESSA MAINITULLA TAVALLA SAATTAA ALTISTAA KÄYTTÄJÄN TURVALLISUUSLUOKAN 1 YLITTÄVÄLLE NÄKYMÄTTÖMÄLLE LASERSÄTEILYLLE.

VARNING

OM APPARATEN ANVÄNDS PÅ ANNAT SÄTT ÄN I DENNA BRUKSANVISNING SPECIFICERATS, KAN ANVÄNDAREN UTSÄTTAS FÖR OSYNLIG LASERSTRÅLNING, SOM ÖVERSKRIDER GRÄNSEN FÖR LASERKLASS 1.

VARO!


AVATTAESSA JA SUOJALUKITUS OHITETTAESSA OLET ALTTIINA NÄKYMÄTTÖMÄLLE LASERSÄTEILYLLE ÄLÄ KATSO SÄTEESEEN.

ADVARSEL

USYNLIG LASERSTRÅLNING VED ÅBNING, NÅR SIKKERHEDSBRYDERE ER UDE AF FUNKTION. UNDGÅ UDSAETTELSE FOR STRÅLNING

VARNING!

OSYNLIG LASERSTRÅLNING NÄR DENNA DEL ÄR ÖPPNAD OCH SPÄRREN ÄR URKOPPLAD. BETRAKTA EJ STRÅLEN. – STRÅLEN ÄR FARLIG.



CONTENTS

[1] GENERAL	[7] DISASSEMBLY AND ASSEMBLY, MAINTENANCE
1. Note for servicing	1. Maintenance System Table
[2] CONFIGURATION	2. Disassembly and assembly
1. System Configurations	[8] MACHINE OPERATION
2. Standard	1. Function of each LED
3. List of combination of peripheral devices	2. Outline of each mode
[3] SPECIFICATIONS	3. Setting mode on Computer side 2
1. Basic Specification	4. Printer environment setup
2. Printer Function Specification2	5. User setup
3. Expanded RAM	6. Web menu frame
[4] CONSUMABLE PARTS	7. Key operator program
1. Supply system table	8. Canceling a print job and deleting print data 4
2. Production number identification	9. Setting the paper size and type 4
3. Environmental conditions	10. Specifications of paper trays5
[5] EXTERNAL VIEWS AND INTERNAL STRUCTURES	[9] ADJUSTMENTS
1. Appearance	1. Process section
2. Internal1	2. Engine
3. Operation panel	[10] DIAG
4. Cross sectional view	1. Diag mode
5. PWB4	[11] TROUBLE CODES
6. Motor, Clutch, Solenoid	1. Trouble codes list
7. Switch, Sensor	2. Details of trouble codes 2
[6] UNPACKING AND INSTALLATION	3. Half of operation in trouble
1. Installing procedure flowchart1	
2. Note for installation place	
3. Unpacking procedure	
4. Machine installing procedure	
5. Option expansion memory installation 5	

[1] GENERAL

1. Note for servicing


Pictogram

This Service Manual uses some pictographs to assure safe operation. Please understand the meanings of pictographs before servicing.


CAUTION: If this CAUTION is ignored, an injury or damage to property could occur.

A.Cautions for servicing

- Do not touch the photoconductive drum. Scratches or smudges on the drum will cause dirty printouts.
- 2) The fusing unit is extremely hot. Exercise care in this area.




- Do not look directly at the light source of the scanner module. Doing so may damage your eyes.
- Five adjusters are provided on all optional stand/paper drawer units.
 These adjusters should be lowered until they contact the floor.



- Do not make any modifications to this machine. Doing so may result in personal injury or damage to the machine.
- Since this machine is heavy, it is recommended that it be moved by more than one person to prevent injury.
- 7) When connecting this machine to a computer, be sure to first turn both the computer and the machine off.
- 8) Do not print anything which is prohibited from printing by law. The following items are normally prohibited from printing by national law. Other items may be prohibited by local law.
 - Money
 - Stamps
 - •Bonds
 - Stocks
 - •Bank drafts
 - Checks
 - Passports
 - •Driver's licenses
- Do not throw toner or a toner cartridge into fire. Toner may be spattered, causing a burn.
- 10) Store toner or toner cartridges in a hard-to-reach place for children.

[2] CONFIGURATION

1.System Configurations



2. Standard

Category	Model	Other options required for the installation/mounting.	Remarks
	Name	(Such option has be ordered separately.)	
Printer model (35ppm)	AR-P350	•Multi Purpose Drawer (AR-MU1), or Stand/MPD&2000 Sheet Paper Drawer (AR-D13), or Three	
Printer model (45ppm)	AR-P450	paper drawer stand (AR-D14)	
		•Power Supply Unit (AR-DC1) is required for Stand/MPD&2000 Sheet Paper Drawer (AR-D13) and	
		Three paper drawer stand (AR-D14)	
MFP model (35ppm)	AR-M350	•B/W Scanner module/DSPF (AR-EF1), or B/W Scanner module/SPF(AR-EF2)	
MFP model (45ppm)	AR-M450	•Scanner Rack(AR-RK1)	
		•Stand/MPD&2000 sheet paper drawer (AR-D13) or Three paper drawer stand (AR-D14)	
		Power supply unit (AR-DC1)	

3. List of combination of peripheral devices

As shown in the table below, some other peripheral devices (B) may be needed for installation of a peripheral device (A) and some peripheral devices cannot be installed together.

			В																				
	Related to scanner feature		B/W scanner module/DSPF	Scanner rack	Multi purpose drawer	Stand/3 x 500 sheet paper drawer	Stand/MPD & 2000 sheet	Duplex module/bypass tray	Duplex module	Saddle stitch finisher	Finisher	Mail-bin stacker	Exit tray	Upper exit tray extension	Punch unit	Multi-function controller board	Print server card	PS3 expansion kit	Network scanner expansion kit	Facsimile expansion kit	Fax memory (8 MB)	Power supply unit	Hard disk drive
	B/W scanner module/DSPF	AR-EF1	-	0	×	O,	*1									0						0	
	Scanner rack	AR-RK1	Ŏ ¹	_	X	O'	*1									0						0	
	Related to paper feed unit Multi purpose drawer Stand/3 x 500 sheet paper drawer	AR-MU1 AR-D14	×	×	_ ×	× -	×			×					×				×	×	×	0	
	Stand/MPD & 2000 sheet paper drawer	AR-D13			×	×	_															0	
	Duplex module/bypass tray	AR-DU4			()*1		_		X					X							Č ²	
	Duplex module	AR-DU3			()*1			_													ਨ ੰ	
	Output units Saddle stitch finisher	AR-FN7			×	0	*1	×	0		×		×									0	_
	Finisher	AR-FN6)*1			_	X	_	×		X	X							O	
Α	Mail-bin stacker	AR-MS1			()*1					X	_		X								0	
	Exit tray	AR-TE3						0	*1	X	×	X	_		×								
	Upper exit tray extension	AR-TE4									×	X		_									
	Punch unit	AR-PN1			X	O	*1	×	0	0	×		X		_							0	
	Related to extension of functions and others																						
	PS3 expansion kit	AR-PK1																_					
	Network scanner expansion kit	AR-NS2	O*1		×	o [*]										0	0		_				
	Facsimile expansion kit	AR-FX5		0	×	O [*]	-1									0				_			
	Fax memory (8 MB)	AR-MM9	Ŏ ¹	0	X	O,	¥1									0				0		0	
	Power supply unit	AR-DC1																				Ξ	
	Hard disk drive	AR-HD3																					_
	Multi-function controller board	AR-M11	O ^{*1}	0	×	O [*]	1									_							
	Print server card	AR-NC5J															_						

O = Must be installed together. O^{*1} = Any of the units must be installed together. O^{*2} = Must be installed for installation of the stand/3 x 500 sheet paper drawer or the stand/MPD & 2000 sheet paper drawer. × = Cannot be installed together.

[3] SPECIFICATIONS

1.Basic Specification

A.Base Engine

(1) Form

AR-P350 / AR-P450 Desktop	
---------------------------	--

(2) Engine speed

Paper size	AR-P350	AR-P450		
A4, 8.5" x 11"	35ppm	45ppm		
A5R/5.5" x 8.5"R	35ppm	45ppm		
B5	35ppm	45ppm		
B4/8.5" x 14	20ppm	22ppm		
A3/11" x 17"	17ppm	20ppm		

(3) Engine composition


Charge method	development Charged saw-tooth method
Transfer method Cleaning method	Transfer roller Counter blade
Fusing method	Heat roller
Used toner disposal	Toner recycling system

(4) Engine resolution

Resolution	Write :600dpi
Smoothing	Write :1200dpi equivalent
Gradation	Write :2 levels

(5) Printable area

The print area of this product is shown below.



If a printer driver for Windows or Macintosh is used for printing, the printable area will be smaller. The actual printable area depends on the printer driver to be used.

(in mm)

Paper size	Α	В	С	D	E
A3	297	420	4	289	4
B4	257	364	4	242	4
A4	210	297	4	202	4
B5	182	257	4	168	4
A5	148	210	4	140	4
Japanese postcard	100	148	4	92	4
Ledger	279	432	4	271	4
Legal	216	356	4	208	4
Foolscap	216	330	4	208	4
Letter	216	279	4	208	4
Executive	184	267	4	183	4
Invoice	140	216	4	132	4
Com-10(envelope)	105	241	4	97	4
C5(envelope)	162	229	4	154	4
Monarch(envelope)	98	191	4	90	4
DL(envelope)	110	220	4	102	4
ISO B5(envelope)	176	250	4	168	4

(6) Warm-up

Warm-up time	Target: less than 95 seconds
Pre-heat requirement	Required
Jam recovery time	Target: about 30 seconds
	(Under standard condition of 60 seconds left
	after side cover opening, polygon motor halt)

(7) Power source

Voltage	100V system	200V system			
	100-127V	220-240V			
Frequency	50/60Hz	50/60Hz			
Power cord					

(8) Power consumption

	AR-P350	AR-P450
Max. Power consump.	1350W	1350W
Average waiting mode	1200W	1200W

(9) Energy Star benchmark

	AR-P350	AR-P450
Low power mode	40W	75W
Recovery time from low power mode	TBD	TBD
Sleep mode	-	-
Transition time to sleep mode	TBD	TBD

(10) Noise

	AR-P350	AR-P450
At working	TBD	TBD
At waiting mode	TBD	TBD
At sleep mode	TBD	TBD

^{*} Showing noise benchmark in each model as a whole system.

(11) Dimensions

External dimensions	428 x 559 x 468.5 (WxDxH) (mm)		
Occupied space dimensions	x (W x D) (mm)		
S .	Approx. 35 kg (excluded to Developer, Process, Controller unit)		

B. Document Feeding Equipment

(1) One-drawer tray (included in the base engine)

• •			
Paper feed method	One-drawer tray		
Sizes to be fed	A4, B5, 8.5" x 11"		
Paper capacity	500 sheets (at 80g/m²)		
Media available for	Plain paper 60 - 105g/m², 16 - 28lbs		
paper feeding			
Paper type	Plain, recycled, pre-printed, pre-punc	hed,	
	color, letter head		
Paper size switching	To be switched by user		
	(paper size to be entered from the operation		
	panel).		
Dehumidification	Not provided		
heater			
Balance detection	Provided (paper empty and 3 steps)		
Default size setting	100V system	200V	
		system	
	8.5" x 11" A4		
Mounting/demounting	Provided		
of the tray			

C. Output Equipment

(1) Face-down Exit Tray (included in the base engine)

the upper side of main heet)
heet)
sheet)
B5R, A5R
8.5" x 13", 8.5" x 11 ",
.5"R
d, Monarch (98 x 191)
DL (110 x 220),
B5 (176 x 250)
59g/m² / 14 ~ 15lbs
8g/m² / 16 ~ 34lbs
² / 47lbs
n² / 54 ~ 55lbs
TBD)
_
E

2.Printer Function Specification

A. Platform

IBM PC/AT (Include compatible machine)
Macintosh (680x0), Power Macintosh, iMac, G3Macintosh

B. Support OS

Custom PS	Windows 95/98/Me		
	Windows NT 4.0		
	Windows 2000		
	Mac OS 7.6 to Mac OS 9		
Custom	Windows 95/98/Me		
PCL5e/6(XL)	Windows NT 4.0		
SPDL	Windows 2000		
PPD	Windows 95/98/Me		
	Windows NT 4.0		
	Windows 2000		
	Mac OS 8.5.1 - Mac OS 9		

^{*} For Macintosh OS, the AR-PK1 is required.

C. Support OS

PCL5e compatible, PCL6 compatible, PostScript Level 2 compatible, PostScript 3 compatible

D. ESC/P • ESC/P Super

Emulation	ESC/P(VP-1100), ESC/P Super
Embedded font	Japanese:Mincho, Gothic (bitmap)
	ANK:Roman, Sans Serif (bitmap)

E. Print Function

(1) General

		When an optional PS3 expansion kit is installed		
Function	PCL5e/ PCL6	PS	PPD (Windows)	PPD (Macintosh)
Copies	1 - 999	1 - 999	1 - 999	1 - 999
Orientation	Yes	Yes	Yes	Yes
Duplex print	Yes	Yes	Yes	Yes
Saddle stitch	Yes	Yes	N/N	N/A
Binding edge	Left/top/ right	Left/top/ right	Long/short	Long/short
N-up	2/4/6/8	2/4/6/8	2/4*3*4	2/4/6/9/16
N-up direction	Fixed	Fixed	Fixed	Selectable
N-up border line	Yes	Yes	Yes(always)	Yes

(2) Paper input

		When an optional PS3 expansion kit is installed		
Function	PCL5e/	PS	PPD	PPD
	PCL6		(Windows)	(Macintosh)
Paper size	Yes	Yes	Yes	Yes
Custom paper size	1 size	1 size	3 sizes*3*5	N/A
Source selection	Yes	Yes	Yes	Yes
Different first page	Yes	Yes	N/A	Yes
Transparency inserts	Yes	Yes	N/A	Yes

(3) Paper output

		When an optional PS3 expansion installed		expansion kit is
Function	PCL5e/	PS	PPD	PPD
	PCL6		(Windows)	(Macintosh)
Output tray selection	Yes	Yes	Yes	Yes
Mail bin	Yes	Yes	Yes	Yes
Staple	Yes	Yes	Yes	Yes
Offset	Yes	Yes	Yes	Yes
Punch	Yes	Yes	Yes	Yes

(4) Graphic

		When an optional PS3 expansion kit is installed		
Function	PCL5e/ PCL6	PS	PPD (Windows)	PPD (Macintosh)
Resolution	600/300 dpi	600 dpi	600 dpi	600 dpi
Halftone	N/A	Yes	Yes	N/A
Graphic mode	Yes	N/A	N/A	N/A
Smoothing	Yes	Yes	Yes	Yes
Toner save	Yes	Yes	Yes	Yes
Photo enhancement	Yes*8	Yes	N/A	N/A
Negative image	N/A	Yes	Yes	Yes
Mirror image	N/A	Horizontal/ vertical	Horizontal	Yes
Zoom	N/A	N/A	Yes	Yes
Fit to page	Yes	Yes	N/A	N/A

For Macintosh OS, the AR-PK1 is required.

(5) Font

		When an optional PS3 expansion kit is installed		
Function	PCL5e/ PCL6	PS	PPD (Windows)	PPD (Macintosh)
Resident font	45 fonts	136 fonts	136 fonts*6	35 fonts
Download font	Bitmap TrueType, Graphic	Bitmap Type1 TrueType	Bitmap Type1 TrueType	N/A

(6) Others

		When an optional PS3 expansion kit is installed					
Function	PCL5e/ PCL6	PS	PPD (Windows)	PPD (Macintosh)			
Watermark*7	Yes	Yes	Yes	Yes			
Overlay	Yes	Yes	N/A	N/A			
Job retention*1	Yes	Yes	N/A	Yes			
Account control	Yes	Yes	N/A	Yes			
Custom settings	Yes	Yes	N/A	N/A			
Automatic configuration*2	Yes	Yes	N/A	Yes			
Job end notification	Yes	Yes	N/A	N/A			

- * 1 In the models without a hard disk drive, an optional hard disk drive must be installed .
- * 2 Functions when peripheral devices are installed.
- * 3 Not supported in the Windows NT 4.0 environment.
- * 4 $\,$ 2/4/6/9/16 is supported in the Windows 2000 environment.
- * 5 Only one size is supported in the Windows 2000 environment.
- * 6 Only 35 fonts are supported in the Windows NT 4.0 environment.
- * 7 This function is limited for PPD.
- * 8 PCL6 only

F. Compatibility

PCL 5e	Target for PCL5e is to be compatible with HP LaserJet
compatibility	4000.
	Small margin difference, rendering difference by
	different font family, default and transfer function
	difference are not to be included in the compatibility.
	All the PJL commands are not necessarily included in
	the compatibility.
PCL6	Target for PCL6 is to be compatible with HP LaserJet
compatibility	4000.
	Small margin difference, rendering difference by
	different font family, default and transfer function
	difference are not to be included in the compatibility.
	All the PJL commands are not necessarily included in
	the compatibility.
PostScript	Roman PostScript is targeted to be compatible with
Compatibility	Adobe PostScript as performed in HP LaserJet 4000.
	Small margin difference, rendering difference by
	different font family, default and transfer function
	difference are not to be included in the compatibility.
ESC/P and	Target for ESC/P and ESC/P Super is to be compatible
ESC/P Super	with Epson VP-1100.
compatibility	Small margin difference, rendering difference by
	different font family, default and transfer function
	difference are not to be included in the compatibility.

3. Expanded RAM

Installation of an expanded RAM will avoid the following status.

- 1) Time out error reduction
- 2) Spool time reduction
- 3)

Use a commercially available RAM of the following specifications. If a RAM which does not meet the specifications is installed, it may cause a trouble such as that it is not recognized or its capacity is not correctly recognized.

<Spesification>

DIMM TYPE	168pin 3.3V Unbuffered SDRAM DIMM Non-ECC
DIMM capacity	64MByte, 128MByte, 256MByte
CAS LATENCY	CL=2
SDRAM CLOCK	For PC100, PC133
SPD	Supporting
Parity	Not support
ECC	Not support

[4] CONSUMABLE PARTS

1. Supply system table

A.USA

NO	Name	Content		Life	Product name	Remark
1	Toner CA(Black) with IC	Toner(Toner : Net Weight 814g)		30K	AR-450MT (*1 AR-450MT-J)	*Life setup is based on A4 6%
2	Developer	Developer (Developer : Net Weight 450g)		100K	AR-450ND	
3	Drum	Drum	x1	50K	AR-450DR	
4	100K maintenance kit	Cleaner blade Drum separation pawl	x1 x4	100K	AR-450KA1	
5	Transfer roller kit	Transfer roller Transfer charging plate	x1 x2	100K	AR-450TX	
6	Upper heat roller kit	Upper heat roller Fusing separation pawl (Upper)	x1 x4	200K	AR-450UH	
7	Lower heat roller kit	Lower heat roller Fusing separation pawl (Lower)	x1 x2	100K	AR-450LH	
8	Cleaner blade	Cleaner blade	x10	100K(x10)	AR-450CB	AR-450CB=(AR-450BL)x10
9	Staple cartridge	Staple cartridge	х3	5000x3	AR-SC1	Common with cartridge for AR-FN4 & AR-FN6
10	Staple cartridge	Staple cartridge	хЗ	5000x3	AR-SC2	Common with cartridge for AR-FN7

^{*1:} For USA Government

Note1: Print on Master/individual carton:Toner/Developer in 2 languages (English/French), DR in 4 languages (English/French/German/Spanish).

Note2: Packed with machine: DR 50K/Developer UN/Process UN

Note3: The other maintenance parts which are not listed above are registered as service parts.

B.CANADA/Latin America

NO	Name	Content		Life	Product name	Remark
1	Toner CA(Black) with IC	Toner(Toner : Net Weight 814g)		30K	AR-450MT	*Life setup is based on A4 6%
2	Developer	Developer(Developer : Net Weight 450g)		100K	AR-450ND	
3	Drum	Drum	x1	50K	AR-450DR	
4	100K PM kit	Cleaner blade Screen grid Toner reception seal Side mall each DV blade DV side seal each	x1	100K	AR-450KA	
		Transfer roller Transfer charging plate Charging plate	x1 x1 x1			
5	200K PM kit	Upper heat roller Lower heat roller Fusing separation pawl (Upper) Fusing separation pawl (Lower)	x1 x1 x4 x2	100K	AR-450KB	
6	Staple cartridge	Staple cartridge	хЗ	5000x3	AR-SC1	Common with cartridge for AR-FN4 & AR-FN6
7	Staple cartridge	Staple cartridge	хЗ	5000x3	AR-SC2	Common with cartridge for AR-FN7

Note1: Print on Master/individual carton:Toner/Developer in 2 languages (English/French), DR in 4 languages (English/French/German/Spanish).

Note2: Packed with machine: DR 50K/Developer UN/Process UN

C.Europe/Australia/New Zealand

NO	Name	Content		Life	Product name	Remark
1	Toner CA(Black) with IC	Toner(Toner : Net Weight 814g)		30K	AR-450LT	*Life setup is based on A4 6%
2	Developer	Developer(Developer : Net Weight 450g)	-	100K	AR-450DV	
3	Drum	Drum	x1	50K	AR-450DM	
4	100K PM kit	Cleaner blade	x1	100K	AR-450KA	
		Screen grid	x1			
		Toner reception seal	x1			
		Side mall each	x1			
		DV blade	x1			
		DV side seal each	x1			
		Transfer roller	x1			
		Transfer charging plate	x1			
		Charging plate	x1			
5	200K PM kit	Upper heat roller	x1	100K	AR-450KB	
		Lower heat roller	x1			
		Fusing separation pawl (Upper)	x4			
		Fusing separation pawl (Lower)	x2			
6	Staple cartridge	Staple cartridge	хЗ	5000x3	AR-SC1	Common with cartridge for AR-FN4 & AR-FN6
7	Staple cartridge	Staple cartridge	х3	5000x3	AR-SC2	Common with cartridge for AR-FN7

Note1: Print on Master/individual carton:4 languages (English/French/German/Spanish).

Note2: Packed with machine: DR 50K/Developer UN/Process UN

Note3: The other maintenance parts which are not listed above are registered as service parts.

D.Middle East/ Africa

NO	Name	Content		Life	Product name	Remark
1	Toner CA(Black) with IC	Toner(Toner : Net Weight 814g)		30K	AR-450ET	*Life setup is based on A4 6%
2	Developer	Developer(Developer : Net Weight 4	Developer(Developer : Net Weight 450g)		AR-450SD	
3	Drum	Drum	x1	50K	AR-450DR	
4	100K PM kit	Cleaner blade Screen grid Toner reception seal Side mall DV blade DV side seal Transfer roller Transfer charging plate Charging plate	x1 x1 x1 each x1 x1 each x1 x1 x1	100K	AR-450KA	
5	200K PM kit	Upper heat roller Lower heat roller Fusing separation pawl (Upper) Fusing separation pawl (Lower)	x1 x1 x1 x1	100K	AR-450KB	
6	Staple cartridge	Staple cartridge	x3	5000x3	AR-SC1	Common with cartridge for AR-FN4 8 AR-FN6
7	Staple cartridge	Staple cartridge	х3	5000x3	AR-SC2	Common with cartridge for AR-FN7

Note1: Print on Master/individual carton:4 languages (English/French/German/Spanish).

Note2: Packed with machine: DR 50K/Developer UN/Process UN

E.Israel/Russia/CIS/Philippines

NO	Name	Content		Life	Product name	Remark
1	Toner CA(Black) with IC	Toner(Toner : Net Weight 814g)	30K	AR-450ET	*Life setup is based on A4 6%	
2	Developer	Developer(Developer : Net Weight 450g)		100K	AR-450SD	
3	Drum	Drum	x1	50K	AR-450DR	
4	100K PM kit	Cleaner blade	x1	100K	AR-450KA	
		Screen grid	x1			
		Toner reception seal	x1			
		Side mall each	x1			
		DV blade	x1			
		DV side seal each	x1			
		Transfer roller	x1			
		Transfer charging plate	x1			
		Charging plate	x1			
5	200K PM kit	Upper heat roller	x1	100K	AR-450KB	
		Lower heat roller	x1			
		Fusing separation pawl (Upper)	x4			
		Fusing separation pawl (Lower)	x2			
6	Staple cartridge	Staple cartridge	хЗ	5000x3	AR-SC1	Common with cartridge for AR-FN4 & AR-FN6
7	Staple cartridge	Staple cartridge	хЗ	5000x3	AR-SC2	Common with cartridge for AR-FN7

Note1: Print on Master/individual carton:4 languages (English/French/German/Spanish).

Note2: Packed with machine: DR 50K/Developer UN/Process UN

Note3: The other maintenance parts which are not listed above are registered as service parts.

F.Asia

NO	Name	Content		Life	Product name	Remark
1	Toner CA(Black) with IC	Toner(Toner : Net Weight 814g)		30K	AR-450CT	*Life setup is based on A4 6%
2	Developer	Developer(Developer : Net Weight 450g	1)	100K	AR-450SD	
3	Drum	Drum	x1	50K	AR-450DR	
4	100K PM kit	DV blade	x1 x1 x1 x1 xh x1 x1 xh x1 x1 x1 x1	100K	AR-450KA	
5	200K PM kit	Upper heat roller Lower heat roller Fusing separation pawl (Upper)	x1 x1 x1	100K	AR-450KB	
6	Staple cartridge	Fusing separation pawl (Lower) Staple cartridge	x1 x3	5000x3	AR-SC1	Common with cartridge for AR-FN4 & AR-FN6
7	Staple cartridge	Staple cartridge	хЗ	5000x3	AR-SC2	Common with cartridge for AR-FN7

Note1: Print on Master/individual carton:4 languages (English/French/German/Spanish).

Note2: Packed with machine: DR 50K/Developer UN/Process UN

G.Hong kong/China

NO	Name	Content		Life	Product name	Remark
1	Toner CA(Black) with IC	Toner(Toner : Net Weight 814g)		30K	AR-450CT-C	*Life setup is based on A4 6%
2	Developer	Developer(Developer : Net Weight 450g)	-	100K	AR-450SD-C	
3	Drum	Drum	x1	50K	AR-450DR-C	
4	100K PM kit	Cleaner blade	x1	100K	AR-450KA	
		Screen grid	x1			
		Toner reception seal	x1			
		Side mall each	x1			
		DV blade	x1			
		DV side seal each	x1			
		Transfer roller	x1			
		Transfer charging plate	x1			
		Charging plate	x1			
5	200K PM kit	Upper heat roller	x1	100K	AR-450KB	
		Lower heat roller	x1			
		Fusing separation pawl (Upper)	x4			
		Fusing separation pawl (Lower)	x2			
6	Staple cartridge	Staple cartridge	хЗ	5000x3	AR-SC1	Common with cartridge for AR-FN4 & AR-FN6
7	Staple cartridge	Staple cartridge	х3	5000x3	AR-SC2	Common with cartridge for AR-FN7

Note1: Print on Master/individual carton:2 languages (English/Chinease).

Note2: Packed with machine: DR 50K/Developer UN/Process UN

Note3: The other maintenance parts which are not listed above are registered as service parts.

H.Taiwan

NO	Name	Content		Life	Product name	Remark
1	Toner CA(Black) with IC	Toner(Toner : Net Weight 814g)	30K	AR-450ST-T	*Life setup is based on A4 6%	
2	Developer	Developer(Developer : Net Weight 4	50g)	100K	AR-450SD-C	
3	Drum	Drum	x1	50K	AR-450DR-C	
4	100K PM kit	DV blade	x1 x1 x1 each x1 x1 each x1 x1 x1	100K	AR-450KA	
5	200K PM kit	Upper heat roller Lower heat roller Fusing separation pawl (Upper) Fusing separation pawl (Lower)	x1 x1 x4 x2	100K	AR-450KB	
6	Staple cartridge	Staple cartridge	х3	5000x3	AR-SC1	Common with cartridge for AR-FN4 & AR-FN6
7	Staple cartridge	Staple cartridge	хЗ	5000x3	AR-SC2	Common with cartridge for AR-FN7

Note1: Print on Master/individual carton:4 languages (English/French/German/Spanish).

Note2: Packed with machine: DR 50K/Developer UN/Process UN

2. Production number identification

A. Drum cartridge

The lot number, printed on the front side flange, is composed of 10 digits, each digit showing the following content:

1	2	3	4	5	6	7	8	9	10

1 Number

For this model, this digit is 2.

2 Alphabet

Indicates the model conformity code. T for this model.

3 Number

Indicates the end digit of the production year.

4 Number or X, Y, Z

Indicates the production month.

X stands for October, Y November, and Z December.

5/6 Number

Indicates the production day on the month.

7 Number or X, Y, Z

Indicates the month of packing.

X stands for October, Y November, and Z December.

8/9 Number

Indicates the day of the month of packing.

10 Alphabet

Indicates the production factory. "A" for Nara Plant.

B. Toner cartridge

The lot number is of 7 digits, and each digit indicates as follows. The lot number shall be printed in the position shown in the figure.

1	2	3	4	5	6	7

- 1 Version number (A sequentially revised)
- 2 Numeral figure

Indicates the end digit of the production year.

3 Alphabet

Indicates the production factory. (B for SOCC)


- 4 Destination code
- 5,6 Numeral figures


Indicates the production day.

7 Numeral figure or X, Y, Z

Indicates the production month.


X stands for October, Y November, and Z December.






3. Environmental conditions

A. Operating conditions




B. Storage conditions



[5] EXTERNAL VIEWS AND INTERNAL STRUCTURES


1.Appearance



1	Bypass tray *	2	Exit tray *	3	Duplex module *
4	Upper paper output area	5	Upper exit tray extension *	6	Operation panel
7	Front cover	8	Main switch	9	Paper tray 1
10	Stand / 3 x 500 sheet paper drawer *	11	Stand / MPD & 2000 sheet paper drawer *	12	Multi purpose drawer *

^{* 1, 2, 3, 5, 10, 11,} and 12 are peripheral units. The configuration of peripheral units varies with the main unit model.


2.Internal



1	Duplex module side cover	2	Side cover open knob	3	Fusing unit
4	Developer cartridge	5	Toner cartridge	6	Photoconductive drum
7	Cartridge lock lever				

3.Operation panel

* This operation panel is valid only when a scanner unit is not installed.




1	Message display	2	[ERROR] indicator	3	[DATA] indicator
4	[READY] indicator	5	[MENU] key	6	[▲/▼] keys
7	[BACK/C] key	8	[OK] key	9	[INFORMATION] key

<Function of each LED>

	READY	DATA	ERROR
ON	Print job reception enable	•When RIP-completed print data are stored in memory.	•When a trouble which can be canceled by the user
			occurred.
Flash		•When data are processed in the printer board	•When a trouble which requires service call occurred.
		(during RIP).	
OFF	Print job reception disable	•Neither print data nor data under process are stored.	•No trouble


^{*} RIP:Raster In Processor. Develops the print command into pixel information.

4. Cross sectional view




No.	Name	No.	Name
1	OPC drum	15	Upper heat roller
2	Main charger	16	Pressure roller
3	Cleaning blade	17	Heater roller
4	LSU	18	Thermistor
5	Developing unit	19	Thermostat
6	Magnet roller	20	Fusing back roller
7	Toner hopper	21	Reverse gate
8	Transfer roller	22	Paper exit roller
9	PS roller	23	Full detection lever
10	PS front roller	24	Printer operation PWB
11	Machine tray paper feed roller	25	Printer control PWB
12	Machine tray separation roller	26	Power unit
13	Machine tray take-up roller		
14	Machine tray rotating plate		

5. PWB




	Name	Function/Operation
1	PRT controller	Image process, image data communication control
2	PCU PWB	Overall control of the machine and options
3	Power unit	DC power supply
4	LD PWB (Inside LSU)	Laser ON control (Inside LSU: LSU cannot be disassembled.)
5	Mother PWB	Signal interface between PCU and the controller
6	Filter PWB	AC power input
7	Printer operation PWB	Key input, machine state display
8	High voltage resistor PWB	High voltage load adjustment
9	Cassette detection PWB	Paper cassette control
10	Drawer PWB	Fan control
11	High voltage PWB	High voltage power supply
12	Fuse PWB	Protection of the machine when an abnormal power is supplied.
13	Initial detection PWB (in the developing unit)	New toner cartridge detection

6. Motor, Clutch, Solenoid



	Code	Function/Operation	Туре
1	DM	Drum motor	Brushless motor
2	MM	Main motor	Brushless motor
3	DSBM	Paper exit motor	Stepping motor
4	TM	Toner motor	Synchronous motor
5	LUM	Lift-up motor	Synchronous motor
6	VFM2	Exhaust fan motor	Fan motor
7	VFM1	Cooling fan motor	Fan motor
8	CFM1	Cooling fan motor	Fan motor
9	FM	Fan motor	Fan motor
10	CFM2	Cooling fan motor	Fan motor
11	CPFC	Paper cassette paper feed clutch	
12	TRC	Paper transport clutch	
13	PSPS	Separation solenoid	
14	RRC	Resist roller clutch	

7. Switch, Sensor



	Code	Function/Operation	Active logic
1	DSW-F	Front door open/close detection	H= Door open
2	DSW-L	Left door open/close detection	H=Door open
3	POD1	Paper exit detection	L= Paper detection
4	POD2	Paper exit detection	L= Paper detection
5	POD3	Paper exit detection	L= Paper detection
6	PPD1	Paper transport detection	L= Paper detection
7	TCS	Toner concentration sensor	
8	TUD	Paper feed cassette upper limit detection	H= Upper limit detection
9	PED	Paper feed cassette paper empty detection	L= Paper empty detection
10	MAIN SW	Power switch	

[6] UNPACKING AND INSTALLATION


1. Installing procedure flowchart


There are many combinations between this machine and option units. For installing option units, observe the following procedures for efficiency.

To install the devices effciently, follow the procedure below.

Some peripheral devices may have been installed as standard devices depending on the main unit model.

Part of descriptions and illustrations may be different.






* For installation of an option unit, refer to the Service Manual of the option unit.


2. Note for installation place

Improper installation may damage this product. Please note the following during initial installation and whenever the machine is moved.

- The machine should be installed near an accessible power outlet for easy connection.
- Be sure to connect the power cord only to a power outlet that meets the specified voltage and current requirements. Also make certain the outlet is properly grounded.
 - •For the power supply requirements, see the name plate of the main unit.
- 3) Do not install your machine in areas that are:
 - •damp, humid, or very dusty
 - •exposed to direct sunlight
 - poorly ventilated
 - •subject to extreme temperature or humidity changes, e.g., near an air conditioner or heater.
- Be sure to allow the required space around the machine for servicing and proper ventilation.



3. Unpacking procedure



Check the following items are included in the package.


Dust cover	
Magnification ratio table	
Paper size indication seal	
Developer	
Toner bottle for installation	
CD-ROM for AR-350/450 series printers	
Operating Manual	
Counter kit contract	

4. Machine installing procedure


Note: In advance to installation of the machine, the paper feed option units (AR-MU1, AR-D13 or AR-D14) should have been installed.

A. Removal of the machine

1) Pull out the front tray and remove it from the machine.



Hold the machine with your both hands and remove it from the package box s shown in the figure.




Note: The center of gravity of the machine lies in the left side when viewed from the machine. When lifting the machine, be careful not to drop.

B. Installation of paper feed options to the machine


Note: Before use of this machine, one of the paper feed option units (AR-D13/AR-D14/AR-MU1) should be installed to the machine for safety reasons.


Refer to the drawing of the AR-MU1 in this manual.

Put the machine on the previously installed option unit.
 Be sure to check that the boss of the option unit is securely engaged with the machine and that the external lines (front and left sides) of the option unit and those of the machine are aligned completely.



2) Connect the machine with the option unit.







- 3) Install the option power source (AR-DC1).
- * For necessity of installation, refer to the option combination.
- * For the installing procedure, refer to the AR-DC1 Service Manual.

C. Setting related to process


1) Open he left door and the front door.




2) Remove the developer cartridge from the machine.



3) Remove the top cover of the developer cartridge.



 While rotating the MG roller, supply developer into the developer cartridge evenly.B




Note: Before opening the developer seal, shake it 4 or 5 times.

Attach the top cover to the developer cartridge and install the cartridge to the machine.


D. Setting related to fusing

 Put down the right and the left levers of the fusing unit in the arrow direction.




E. Paper setting

1) Pull out the first stage paper feed tray.



2) While pressing the paper holding plate, remove the fixing pin.



3) Put paper in the tray, and close the paper feed tray.

F. Automatic developer adjustment

- 1) Attach the cabinets which were removed.
- 2) Close the left door and the front door.
- 3) Insert the power plug into the power outlet.
- 4) While pressing the [MENU] key and the [OK] key, turn on the power switch, and the machine will enter the diag mode.
- 5) On the operation menu, select "AUTOMATIC DV AD."

(LCD Display)



Press the [OK] key, and the automatic developer adjustment will be performed.

During execution of the automatic developer adjustment, the data (LED) blinks and the LCD indicates the toner sensor value.

After about 2 min, the adjustment value is stored in the machine.
 Check that the mode was normally completed.

Normal end: The data LED goes off.

Abnormal end: The error LED lights up.

Remove the cause of the error, and execute the automatic developer adjustment again.

8) Press the [BACK/C] key, and the machine returns to the normal mode and enters the warm-p mode.

G. Print test


- 1) Press the [MENU] key to display "USER SETTING."
- 2) Press the [OK] key to select the menu.
- Use [▲] and [▼] keys to select List Print, and print the user setup list to check the print quality.
- 4) Press the [MENU] key again to return to the normal menu.

5. Option expansion memory installation


A. Hard disk (ARHD3), PS3 Expansion kit (ARPK1), print server card (AR-NC5J), expansion memory (commercially available one)

Note: Before performing this installation work, check that the data lamp on the operation panel is neither lighting nor blinking.

- Turn off the power of the machine and disconnect the power plug from the power outlet.
- 2) Remove all the cables (such as printer cables) from the control PWB.




3) Remove the control PWB.



4) Install each option.

<Printer model>



Note:To prevent breakage by static electricity, take the following measures.

- a. Use an earth band for installing procedures.
- Keep the memory in the protection bag, and remove it from the bag only just before installation.
- 5) Install the control PWB to the machine.
- Attach the cables which were removed before installation of the memory.
- 7) Insert the power plug into the power outlet, and turn on the power.

B. Print test

- 1) Press the [MENU] key to display "USER SETTING."
- 2) Press the [OK] key to select the menu.
- Use [▲] and [▼] keys to select List Print, and print the setup list or demonstration page to check the print quality.
- 4) Press the [MENU] key again to return to the normal menu.

C. Other options

For installation of the other options, refer to the Service Manual of each option.

[7] DISASSEMBLY AND ASSEMBLY, MAINTENANCE

1.Maintenance System Table

A. Engine section

Unit name	Part name	When calling	50K	100K	150K	200K	250K	300K	350K	400K	Remark
Drum peripheral	Drum		A	Installed when shipping							
	Cleaner blade		A								
	Toner reception seal		A								
	Side molt		A								
	Transfer roller	×	×	A	X	A	X	A	X	A	
	Discharge plate	×	×	A	X	A	X	A	X	A	
	TR bearing (F/R)			×		×		X		A	
	Transfer roller collar			×		×		X		A	
	TR gear	×	X	X	X	A	X	X	X	A	
	Screen grid	(O)×	A								
	Drum separation pawl UN		A								
	Charger case (M/C)		0	0	0	0	0	0	0	0	
	Charging plate (saw teeth)	(O)×	A								
Developing section	Developer		×	A	X	A	×	A	X	A	Supplied when installing
	DV blade		X	A	×	A	X	A	×	A	
	DSD collar		0	0	0	0	0	0	0	0	
	DV side seal F		X	A	×	A	×	A	×	A	
	DV side seal R		×	A	×	A	×	A	×	A	
	Toner cartridge										Attached when installing./ EX Japan: 814g, user replacement for every 30K.
Fusing section	Upper heat roller		0	0	0	A	0	0	0	A	
	Lower heat roller		0	0	0	A	0	0	0	A	
	Upper separation pawl		X	X	×	A	X	×	×	A	
	Lower separation pawl		×	X	X	A	X	X	X	A	
	Thermistor		0	X	0	×	0	X	0	×	Clean and remove paper dust.
	Upper heat roller gear		×	X	×	A	X	X	X	A	
	Paper guides	0	0	0	0	0	0	0	0	0	
	Gears		☆	☆	☆	☆	☆	☆	☆	☆	
Filters	Ozone filter			A		A		A		A	
Paper feed section	Paper feed roller	0	0	×	0	×	0	X	0	×	Note 1
	Torque limiter	×		X		×		X		X	Note 1
Transport section	PS follower roller	0	0	0	0	0	0	0	0	0	
Paper exit reverse section	Transport rollers	0	0	0	0	0	0	0	0	0	
	Transport paper guides	0	0	0	0	0	0	0	0	0	
	Paper dust remover		×	A	X	A	×	A	×	A	
Drive section	Gears(Specified position)	☆	☆	☆	☆	☆	☆	☆	☆	☆	
	Belts				.,			X		.,	
Image quality		×	×	X	X	×	X	X	×	×	
Other	Sensors			X		X		X		X	

Note 1:Replacement reference: Use the counter value of each paper feed port as the replacement reference.

Paper feed roller/Torque limiter section: 80K or 2 years

B. Peripheral devices

Option name	Part r	ame	When calling	50K	100K	150K	200K	250K	300K	350K	400K	Remark
ADU + Manual feed	Paper feed separation section	Paper feed rollers	(O)×	0	×	0	×	0	×	0	×	Note 3
		Separation pad	(O)×	0	X	0	×	0	X	0	X	Note 3
		Torque limiter	(O)×		X		×		X		×	Note 3
	Transport section	Transport rollers	0	0	0	0	0	0	0	0	0	
		Transport paper guides	0	0	0	0	0	0	0	0	0	
	Drive section	Gears	☆		☆		☆		☆		☆	(Specified position)
		Belts							X			
	Other	Sensors	×		X		×		X		×	
Desk (Multi stage LCC)	Paper feed separation section	Paper feed rollers	(O)×	0	×	0	×	0	×	0	×	Note 3
Multi purpose		Torque limiter	(O)×		X		×		X		X	Note 3
	Transport section	Transport roller	0	0	0	0	0	0	0	0	0	
		Transport paper guides	0	0	0	0	0	0	0	0	0	
	Drive section	Gears	☆		☆		☆		☆		☆	(Specified position)
		Belts							×			
	Other	Sensors	×		X		×		X		X	
Finisher	Transport section	Transport rollers	0		0		0		0		0	
		De-curler roller	(O)×	×	0	×	0	×	0	×	0	
		Transport paper guides	0		0		0		0		0	
	Drive section	Gears	☆		☆		☆		☆		☆	(Specified position)
		Belts							X			
	Other	Sensors	×		X		×		X		X	
		Discharge brush	×		X		×		X		X	
	Staple un	l.										Replace UN at 100K staple.
	Staple cartridge											User replacement for every 3000pcs.
Mail-bin	Transport section	Transport roller	0		0		0		0		0	
stacker		Transport paper guides	0		0		0		0		0	
	Drive section	Gears	☆		☆		☆		☆		☆	(Specified position)
		Belts							×			
	Other	Sensors	×		×		×		×		×	
		Discharge brush	×		×		X		×		×	
Saddle finisher	Transport section	Transport roller	0		0		0		0		0	
		Transport paper guides	0		0		0		0		0	
	Drive section	Gears	☆		☆		☆		☆		☆	(Specified position)
		Belts							×			
	Other	Sensors	×		×		×		×		X	
		Discharge brush	×		×		×		×		X	
	Staple UN											Replace UN at 100K staple (including the staple UN and the holder section).
	Staple cartridge											User replacement for every 5000 pcs.

Note 3: Replacement reference: Use the counter value of each paper feed port as the replacement reference.

Paper feed roller/Separation pad/Torque limiter section: 80K or 2 years


2. Disassembly and assembly

Note:


- •When assembling, check that the flat cable and the harness connectors are securely connected.
- •When connecting the flat cable, be careful not to break the pins.
- •When installing the PWB unit and the memory module, use an earth band to prevent against breakage by static electricity.

A. Exterior


(1) Right cabinet




(2) Rear cabinet




(3) Left door unit



(4) Paper exit upper cabinet/Front left upper cabinet





(5) Upper cabinet/Operation panel/Front door




B. Drum peripheral

(1) Drum cartridge






(2)Main charger /charger case




(3) Screen grid




(4) Main charger


Loosen the screw and remove the charger.




(5)OPC drum/DSD collar





Note: When installing the DSD collar, engage the DSD collar boss with the hole in the drum frame.






(6) Drum separation pawl







(7)Cleaning blade




C. Transfer roller unit




(1) Discharge plate




(2) Transfer roller




D. Fusing unit







(1)Lower separation pawl




(2)Upper separation pawl




(3) Lower heat roller







(4)Heater lamp




(5)Upper heat roller



(6)Thermistor





E. Ozone filter (1)Ozone filter




(2)Ozone filter


Note: Not subject to maintenance
This part is not included in the counter kit.









F. Paper feed section




(1)Paper guide




(2)Separation roller/torque limiter




(3)pick-up roller/ paper feed roller




(4)Belt




(5)Upper limit sensor/paper empty sensor




G. Paper dust removing unit




H. Resist roller unit




(1) Resist roller




(2) Resist sensor




I. Paper exit unit







(1)Paper exit upper paper guide unit




(2)Paper exit sensor/switch-back sensor




(3)Paper exit sensor 2




(4)Paper exit roller




(5)Paper exit motor



(6)Paper exit drive section




J. Main motor/drum motor




K. PCU PWB


Note: When replacing the PCU PWB, remove the EEPROM from the PCU PWB and install it to a new PWB.




L. PCU PWB base plate unit





M. Main drive unit







(1)Drive gear/clutch









N. High voltage PWB




O. Fuse PWB







P. Power unit peripheral (1)Power switch




(2)Power unit







(3) Filter PWB




(4) Power PWB




Q. Printer operation PWB





R. Mother PWB





S. Laser unit












Note: When the LSU is disassembled, the LSU right angle adjustment is required.

T. Controller PWB



[8] MACHINE OPERATION

1. Function of each LED


	READY	DATA	ERROR
ON	Print job reception enable	•When RIP-completed print data are stored in memory.	•When a trouble which can be canceled by the user
			occurred.
Flash		•When data are processed in the printer board	•When a trouble which requires service call occurred.
		(during RIP).	
OFF	Print job reception disable	•Neither print data nor data under process are stored.	•No trouble

^{*} RIP:Raster In Processor. Develops the print command into pixel information.

2. Outline of each mode

The menu groups are classified into five groups and are selected consecutively by pressing the [MENU] key. If the [OK] key is pressed when the desired menu screen is displayed, a message will appear to indicate the next required operation.

In addition, there is the service diag mode used for a serviceman.(with the scanner unit installed)



3. Setting mode on Computer side

Mode	Outline	Remark
	Changed and set according to the print form of each job.	
Web menu frame	Used to set the work board functions from the Web browser (*1).	Only when the NIC board (AR-NC5J) is installed.

^{*1:} Recommended Web browser Internet Explorer 4.0 or later, Netscape Navigator 4.0 or later

4.Printer environment setup

		Cativalia (Dafavili)
		Set value (Default)
Initial setup	Smoothing	YES* • NO
	Number of copies	1* ~ 999
	Print direction	Vertical* • Horizontal
	Standard paper feed paper	A3 • B4 • A4* • B5 • A5
	size	11" x 17" • 8.5" x 14" • 8.5" x 13" • 8.5" x 11" •
		7.25" • 10.5" • 5.5" x 8.5"
	Standard paper feed paper	Normal paper, printed paper,
	type	recycled paper,
		letter head paper,
		punched paper, color paper
	Standard paper exit tray	Differs depending on
		installation of peripheral devices. *1
	White paper print inhibition	Inhibit / Allow*
SPDL setup	writte paper print initiotion	See separate sheet 1.
PS setup		(PS error cause)
r 3 setup		Print / not print *
ESC /	Print mode setup	
P(Super)	Paper position setup	
setup	(PC-PR201H only)	
	Position correction setup	
	Japanese font setup	
	European language font	
	setup	
	Character code table setup	
	Print column range setup	
	Print start position setup	
	Change-line code setup	
	Perforations skip setup	
	Each language character	
	setup (PC-PR201H only)	
	Zero character selection	
	Reduction print	
	Print quantity setup	
	Print direction setup	
	Standard paper feed paper	
	size setup	
	Standard paper exit tray setup	
	Hexadecimal dump output	
	setup	
	I / O timeout time setup	
	Setup list print	
	Standard paper feed paper	
	type setup	
	A4 / Letter automatic	
	selection	
	Precaution notifying page	
	print inhibition	

5.User setup

		Set value (Default)
Total print quantity display		
LCD contrast adjustment		
List print	Setup list	
	Printer test page	
Time setup		
Paper feed tray setup		
Paper feed tray automatic selection		

6.Web menu frame

		Set value (Default)
Receiver management	Email distribution scan receiver setup	
	File server store scan store receiver information setup	
	Desktop distribution scan receiver information setup	
	FAX receiver information setup	
	Internet FAX receiver information setup	
	Group receiver information setup	
	Confirmation of receiver information delete	
Memory box	Remote send	
management	Confidential reception	
	Interface broadcast (forward)	
Management	Network card setup	
setup	Password setup	
	Network scanner basic setup	
	Email status basic setup	
	Email system and DNS system	
	basic setup	
	Email sender setup	
	Group index setup	
	Email status setup	

7. Key operator program

	Key operator p	rogram	Set value (Default)	Remark
			Engine section LCD	Roman
Auditor setup	Department counter setup		ON / OFF*	
	Print quantity total	Print quantity total user display	ON / OFF*	
		Print quantity print		
	Total delete			
	Department number setup	Dpt. number registration (5 digits)		
		Dept. number / Delete		
		Dept. number / Change		
		Dept. number / Print		
	Print inhibit with disabled dept. number		Yes / No*	
Energy-save	Auto power shut off setup		15min / 30min / 60min* / 120min / 240min	
setup	Auto power shut off inhibit		Inhibit / Allow*	
	Pre-heat mode setup		15min / 30min / 60min / 120min / 240min / None*	
	Toner save		ON / OFF*	
Operation	Auto clear time setup		15sec / 30sec / 60sec* / OFF	
panel setup	Message display time setup		3sec / 6sec* / 9sec / 12sec	
	Display language setup		Japanese* • English • French • Spanish	
Device setup	Duplex function inhibit		Yes / No*	
	Staple inhibit		Yes / No*	
	Paper feed desk inhibit		Yes / No*	
	Finisher inhibit		Yes / No*	
	Male bin stacker inhibit		Yes / No*	
	Inter staple position	Paper size A3	-3.0mm ~ 0.0mm* ~ 3.0mm (0.1mm unit)	With the
	adjustment	Paper size B4	-3.0mm ~ 0.0mm* ~ 3.0mm (0.1mm unit)	saddle finisher
		Paper size A4R	-3.0mm ~ 0.0mm* ~ 3.0mm (0.1mm unit)	installed
		Paper size Leisure	-3.0mm ~ 0.0mm* ~ 3.0mm (0.1mm unit)	
		Paper size Letter R	-3.0mm ~ 0.0mm* ~ 3.0mm (0.1mm unit)	
Key operator program list print				
Key operator	First setup of key operator		00000*	
code change	code			
System	Basic setup	Print density adjustment	Standard* / Light / Slightly light / Slightly dark / Dark	
management setup		Precaution notifying page output inhibit	Yes* / No	
		Test page output inhibit	Yes* / No	
		A4 / Letter size auto selection	ON / OFF*	
	Interface setup	Hexadecimal dump mode	ON / OFF*	
		Parallel port PDL selection	Auto* / PostScript / SPDL / ESC / P(Super)	
		Network PDL selection	Auto* / PostScript / SPDL / ESC / P(Super)	
		I / O timeout selection	1sec ~ 20sec* ~ 999sec	
		Port selection setup	For every job * / Time out / Parallel port disable / Network port disable	
	Network setup	IP address setup	IP address setup000.000.000.000*	
	·		IP net mask setup000.000.000.000*	
			IP gateway setup000.000.000.000*	
		TCP / IP setup	Yes* / No	
		NetWare enable	Yes* / No	
		EtherTalk enable	Yes* / No	
		NetBEUI enable	Yes* / No	
		NIC reset	-	
	System setup store / recall			
	Cystem scrup store / recair	Setup store		
		Setup store Setup value recall		
	Coft kov	-		
	Soft key	PS3 expansion kit soft input		
		Network scanner expansion kit soft key input		

8. Canceling a print job and deleting print data

•To cancel a print job in progress and delete the print data:

Press the [BACK/CLEAR] key during printing. Printing will stop and a message asking for confirmation to delete the job will appear.

To delete the data, press the [OK] key.

To cancel deletion, press the [BACK/CLEAR] key. Printing will resume.

•To delete print data of a reserved job (that waits for printing):


Print data transmitted from computers will be stored in this printer (up to 99 jobs) and will be output sequentially. To delete print data of a reserved job before starting printing, press the $[\triangle]$ or $[\nabla]$ key to display the desired data in the message display.

If you press the [BACK/CLEAR] key at this time, a confirmation message for deletion will appear. To delete the data, press the [OK] key. To cancel deletion, press the [BACK/CLEAR] key. Printing will resume.

9. Setting the paper size and type


When the paper size or type is changed in a paper tray, set them referring to the following procedure.

 Press the [MENU] key repeatedly until "CUSTOM SETTINGS" appears in the message display.



2) Press the [OK] key.

When the [OK] key is pressed, "TRAY SETTING" will appear in the message display.




3) Press the [OK] key.

When the [OK] key is pressed, the message shown to the left will appear in the message display.



4) Select the desired paper tray.

Press the $[\triangle]$ or $[\bigtriangledown]$ key repeatedly until the desired paper tray is indicated in the display.



5) Press the [OK] key.

The paper size and paper type of the tray selected in step 4) will appear.

•If TRAY 1 is selected in step 4), the message shown to the below will appear in the display.



- 6) Press the [▽] key.
- •If TRAY 1 is selected in step 4), the message shown to the left will appear in the display.

CHANGE	TRAY1	
SETTING	OK?	

7) Press the [OK] key.

To cancel the setting change, press the [BACK/C] key to return to step 4).

NOTE: Special paper such as thick paper, transparency film, labels, and postcards can be set for tray 2 and the bypass tray. Envelopes can be set only for tray 2.

8) Select the paper type that has been set in the tray.

Press the $[\triangle]$ or $[\nabla]$ key repeatedly until the paper type that has been set appears.

PLAIN
OK?

- 9) Press the [OK] key.
- 10) Ensure that the desired paper size is selected.
- Press the [△] or [▽] key repeatedly until the desired paper size appears.



Depending on the selected tray, a selection for "AUTO-AB" and "AUTO-INCH" may appear

"AUTO-AB": Select when you have set AB system paper.

"AUTO-INCH": Select when you have set inch system paper.

When the paper system is changed from the inch system to the AB system or vise versa, the paper type must be designated. Select the paper type.

- •If you have set paper of non-standard size, select "NON STANDARD".

 This size can be selected when tray 2 or the bypass tray has been selected in step 4).
- 11) Press the [OK] key to terminate the setting.

10. Specifications of paper trays

The specifications for types and sizes of paper for loading paper trays are shown below.

Tray		Tray No. (tray name)		Applicable paper types	Applicable paper sizes	Paper weight
Paper tray 1		Tray 1	Plain paper (Refer to th	e next page for applicable papers.)	•8-1/2 x 11, A4, B5	16 to 28 lbs. or 60 to 105g/m ²
Multi purpose d bypass tray	lrawer/	Tray 2/ bypass tray	Plain paper (Refer to th	e next page for applicable papers.)	•If "AUTO-INCH" is selected in setting the paper size and type, the following paper sizes can be used with the automatic detection function: 11 x 17, 8-1/2 x 14, 8-1/2 x 11, 8-1/2 x 11R, 7-1/4 x 10-1/2, 5-1/2 x 8-1/2R •If "AUTO-AB" is selected in setting the paper size and type, the following paper sizes can be used with the automatic detection function: A3, B4, A4, A4R, B5, B5R, A5R, 8-1/2 x 13 •Non-standard sizes	16 to 34 lbs. or 60 to 128g/m ²
			Special paper (Refer to the next page for applicable papers.)	Thick paper Labels, transparency film Postcard	•If "AUTO-INCH" is selected in setting the paper size and type, the following paper sizes can be used with the automatic detection function: 8-1/2 x 11, 8-1/2 x 11R •If "AUTO-AB" is selected in setting the paper size and type, the following paper sizes can be used with the automatic detection function: A4, A4R, B5, B5R •Non-standard sizes smaller than 8-1/2 x 11 or A4 •Japanese official postcard	
				Envelopes can only be fed from the multi-purpose drawer. Applicable paper stock weight for envelopes is 20 to 23 lbs. or 75 to 90g/m ²	Applicable standard size envelopes: COM-10, Monarch, DL, C5, ISO B5 Non-standard size	
Stand/3 x 500	Upper	Tray 2	Same as m	ulti purpose drawer	1	
sheet paper	Middle	Tray 3	Plain paper	•	•If "AUTO-INCH" is selected in setting the paper	16 to 28 lbs. or
drawer	Lower	Tray 4		e next page for applicable papers.)	size and type, the following paper sizes can be used with the automatic detection function: 11 x 17, 8-1/2 x 14, 8-1/2 x 11, 8-1/2 x 11R, 7-1/4 x 10-1/2, 5-1/2 x 8-1/2R •If "AUTO-AB" is selected in setting the paper size and type, the following paper sizes can be used with the automatic detection function: A3, B4, A4, A4R, B5, B5R, A5R, 8-1/2 x 13	60 to 105g/m²
Stand/ MPD &	Upper	Tray 2	Same as m	ulti purpose drawer	1	
2000 sheet paper drawer	Lower	Tray 3	Plain paper	<u> </u>	•8-1/2 x 11, A4	16 to 28 lbs. or 60 to 105g/m²

A. Applicable plain paper

For satisfactory results, plain paper must conform to the following requirement

	Paper in AB system	Paper in inch system
	A5 to A3	5-1/2 x 8-1/2 to 11 x 17
Plain paper	16 to 28 lbs. or 60 to 105g/m ²	
Recycled, colored, pre-punched, pre-printed and letterhead papers must conform to the same conditions as above.		

B. Applicable special paper

For satisfactory results, special paper must conform to the following requirements.

	Type	Remarks
Special paper	Thick paper	•For 5-1/2 x 8-1/2 to 8-1/2 x 11 or A5 to A4 sizes, thick paper ranging from 16 to 34 lbs.
		or 60 to 128g/m² can be used.
		•For sizes larger than 8-1/2 x 11 or A4, thick paper ranging from 16 to 28 lbs. or 60 to 105g/m² can be
		used.
		•Other thick papers Index stock (65 lbs. or 176g/m²) can be used. Cover stock (110 lbs. or 200 to 205g/m²)
		can be used but only for 8-1/2 x 11, A4 or smaller paper in the portrait orientation.
	Transparency film, labels,	•Use SHARP recommended paper. Do not use labels other than SHARP recommended labels.
	and tracing paper	Doing so may leave adhesive residue in the printer, causing paper misfeeds, smudges on prints or other
		machine trouble.
	Postcards	Japanese official postcards can be used.
	Envelopes	•Applicable standard envelopes: COM-10, Monarch, DL, C5, ISO B5
		•Envelopes can only be fed from the multi-purpose drawer.
		Applicable paper stock weight for envelopes is 20 to 23 lbs. or 75 to 90g/m².

[9] ADJUSTMENTS

			Contents of adjustment
1	Process	Α	Doctor gap adjustment
	section	В	MG roller main pole position adjustment
		С	High voltage output check and adjustment
2	Engine	Α	LSU right-angle adjustment
		В	Print magnification ratio adjustment
		С	Print off-center adjustment
		D	Self print lead edge adjustment
		Е	Void area adjustment
		F	Resist quantity adjustment
		G	Option paper feed tray paper guide adjustment
		Н	Option manual feed section
			paper guide position adjustment

1. Process section


A. Doctor gap adjustment


This adjustment is performed in the following cases:

- •When developer is scattered.
- •When an uneven image is produced.
- Remove the developer cartridge and the developing unit from the machine.
- 2) Remove the DV cover and the developer from the developing unit.
- 3) Remove the DVR cover, the DVF handle, the idle correction plate assembly, and the HG gear 22T, insert a thickness gauge (0.46mm) as shown in the figure below, and check that the clearance is within the specified range.

If the clearance is not within the specified range, adjust the doctor gap in the following procedures.

- 4) Loosen the developing doctor fixing screw A.
- Insert the thickness gauge (0.46mm) again as shown in the figure below.
- Push the developing doctor in the arrow direction and tighten the fixing screw.
- Check the developing doctor gap. If the clearance is within the specified range, fix the screw with screw lock.
- 8) After completion of the job, apply screw lock.





<Adjustment specification>

		Specification	Ambient temperature
Both sides	Position at 20 - 50mm	0.45±0.03mm	5 - 30°C

B. MG roller main pole position adjustment


This adjustment is performed in the following cases:

- •When developer is scattered.
- •When an uneven image is produced.
- Remove the developer cartridge and the developing unit from the machine.
- 2) Remove the DV cover and the developer from the developing unit.
- Remove the DVF handle and put the developing unit on a flat surface.
- 4) Bind a string to a needle.
- 5) Hold the string and move the needle toward the MG roller. (Since the MG roller diameter is small, use of a clip cannot make an accurate adjustment.)
- 6) With the needle tip 2 3 mm apart from the MG roller surface, mark the point on the MG roller in the elongated line of the needle. (Keep the needle and the MG roller apart from each other.)
- 7) Measure the distance from the marking position to the P surface of the developing unit, and check that the distance is within the specified range.

If the distance is not within the specified range, perform the adjustment in the following procedures.

8) Loosen the fixing screw of the main pole fixing plate.

9) Move the adjustment plate in the arrow direction and adjust.




<Adjustment specification>

		Specification	
Marking position	Measure from the P surface above.	54.2mm	

C. High voltage output check and adjustment

- While pressing the MENU key and the OK key, turn on the power switch.
- 2) The operation panel displays "PCU DIAG MODE."
 - * After releasing your fingers from the keys, do not touch any key for about 8 sec.
- Press the MENU key several times until "HV TEST MC/GRID" is displayed.
- 4) Select a load to be outputted with $[\triangle]$ and $[\nabla]$ keys.
- 5) Press the OK key to determine the selected load.
- 6) Apply the high voltage tester across the measuring pin according to the selected load and the frame.



7) The set value is displayed on the LCD. Check it and adjust so that it is in the specified range.

The output mode is as shown in the table below.

LCD display				Spec	Measuring pin
MC/GRID	AE	MC grid	AE mode	-650V±5V*	CN2-7
	CHR		Text mode	-650V±5V*	
	MIX		Text Photo mode	-650V±5V*	
	PHT		Photo mode	-650V±5V*	
	PRT		Printer mode	-650V±5V*	
1	FAX		FX mode	-650V±5V*	
THV+	F	Transfer voltage	Front side		CN2-5
	В		Rear side		
BS	AE	Developing bias	AE mode	-500V±5V*	CN2-1
	CHR		Text mode	-500V±5V*	
	MIX		Text Photo mode	-500V±5V*	
	PHT		Photo mode	-500V±5V*	
	PRT		Printer mode	-500V±5V*	
	FAX		FX mode	-500V±5V*	
	PLUS		Positive bias	+500V±5V*	
SHV	F	Separation voltage	Front side	1.25V±0.1V	CN2-3
	R		Rear side	1.25V±0.1V	
THV		Transfer voltage discharge		-800V±10V*	CN2-5

^{*} Varies with time by the process control process.

2. Engine

A. LSU right-angle adjustment


This adjustment is required in the following cases:


- •When the LSU is replaced.
- •When a distortion is produced in print. (Check with self print pattern "71".)

After completion of this adjustment, the following adjustments should be performed.

- Print magnification ratio adjustment
- •Print off-center adjustment
- Void area adjustment

- Hold and push the [MENU] key and the [OK] key, and turn on the power. ("PCU DIAG MODE ***" is displayed.)
 - * Do not touch the keys for about 8sec after releasing fingers from the above keys.
- Push the [MENU] key several times until "TEST PRINT" is displayed, and push the [OK] key to enter the test print mode.
- Push the [MENU] key several times until "PRITN PATTERN" is displayed, and set "71".
- 4) Push the [MENU] key several times until "CASSETTE" is displayed, and check with $[\triangle]$ key that the paper for tray 1 is properly set for the destination.
 - * AB series: "A4" is displayed
 - * Inch series: LETTER is displayed.
- 5) Push the [OK] key to make self-print.
- 6) Check the output print.
- Loosen two fixing screws of the LSU unit (M4 screws which are fixing the LSU and the top plate).
- 8) Turn the adjustment screw on the upper side (on the back of the printer operation panel) clockwise or counterclockwise to adjust the height of the LSU front side.
- After completion of the adjustment, tighten two fixing screws of the LSU unit.
- 10) Print again in the grid pattern and check the print.
- 11) Repeat procedures 7) to 10) until the specification is satisfied.





<Specification>

	Measuring point	Specification	Set value
Print distortion	Self print	$\theta = 90^{\circ} \pm 0.13^{\circ}$	θ changes about
adjustment	pattern 71		0.25 degrees for 1 scale
-			of adjustment.

B. Print off-center adjustment

This adjustment is performed in the following cases:


- •When the center of print is misaligned.
- (Check with the self print pattern "1".)
- •When the LSU is replaced.
- •When the option paper feed unit or the automatic duplex unit is installed or replaced.

Before executing this adjustment, the following adjustments must have been completed.

- •LSU right-angle adjustment
- Print magnification ratio adjustment

After completion of this adjustment, the following adjustment must be performed.

- Void area adjustment
- Hold and push the [MENU] key and the [OK] key, turn on the power.
 ("PCU DIAG MODE ***" is displayed.)
 - Do not touch the keys for about 8sec after releasing fingers from the above keys.
- Push the [MENU] key several times until "TEST PRINT" is displayed, and push the [OK] key to enter the test print mode.
- 3) Make a print with "1".
- Push the [MENU] key several times until T1 OFF CENTER ADJ is displayed, and push the [OK] key.
- 5) Check the print and use [△] or [▽] key to adjust the value of T1 OFF CENTER ADJ so that the off-center value is within the specified range.
- 6) If the option paper feed unit or the automatic duplex unit is installed, make an adjustment for each unit.
 - * When using the duplex unit, set DUPLEX to USE.



	Measurement reference	Specification	Set value	
Standard tray self print off- center (T1 OFF CENTER ADJ) No. 2 tray self print off-center (T2 OFF CENTER ADJ)	Output pattern 1 Center line	0 ±1.5mm	Shift of 0.1mm for set value 1.	When the option paper feed unit is
No. 3 tray self print off-center (T3 OFF CENTER ADJ) No. 4 tray self print off-center (T4 OFF CENTER ADJ)				installed.
Manual feed tray self print off-center (MFT OFF CENTER ADJ) ADU Self print off-center (ADU OFF CENTER ADJ)		0 ±1.5mm		When the option automatic duplex unit is installed.

When the print line is shifted toward a from the paper center, decrease the value.

When the print line is shifted toward b from the paper center, increase the value.

C. Self print lead edge adjustment

This adjustment is performed in the following cases:

- •When the print start position is improper.
- (Check with the self print pattern "1".)
- •When the LSU is replaced.

Before executing this adjustment, the following adjustments must have been completed.

- •LSU right-angle adjustment
- Print magnification ratio adjustment


After completion of this adjustment, the following adjustment must be performed.

- Void area adjustment
- Hold and push the [MENU] key and the [OK] key, turn on the power. ("PCU DIAG MODE ***" is displayed.)
 - Do not touch the keys for about 8sec after releasing fingers from the above keys.
- Push the [MENU] key several times until "TEST PRINT" is displayed, and push the [OK] key to enter the test print mode.
- 3) Make a print with "1".
- Push the [MENU] key several times until LEAD EDGE is displayed, and push the [OK] key.
- 5) Check the print and use [△] or [▽] key to adjust the value LEAD EDGE so that the distance shown in the figure below is within the specified range.
- 6) Check that the print lead edge is within the specified range.

<Specification>

	Set position	Specification	Set value
Self print lead	Print start	A = 4.0mm or less	Shift of
edge adjustment	position A of the	(FR total: 8.0mm or	0.175mm
(LEAD EDGE)	output pattern 1	less)	(35ppm) /
			0.225mm
			(45ppm) for
			set value 1.

To increase the print lead edge, decrease the set value with $[\nabla]$ key. To decrease the print lead edge, increase the set value with $[\Delta]$ key.



D. Void area adjustment

This adjustment is performed in the following cases:

- •When the print start position is improper.
- (Check with the self print pattern "71".)
- •When the LSU is replaced.


Before executing this adjustment, the following adjustments must have been completed.

- •LSU right-angle adjustment
- Print magnification ratio adjustment
- Print off-center adjustment
- Hold and push the [MENU] key and the [OK] key, turn on the power. ("PCU DIAG MODE ***" is displayed.)
 - Do not touch the keys for about 8sec after releasing fingers from the above keys.
- Push the [MENU] key several times until "TEST PRINT" is displayed, and push the [OK] key to enter the test print mode.
- 3) Make a print with "71".
- Push the [MENU] key several times until LEAD EDGE VOID is displayed, and push the [OK] key.
- 5) Check the print and use [△] or [▽] key to adjust the value LEAD EDGE VOID so that the distance A shown in the figure below is within the specified range.
- Push the [MENU] key several times until TAIL EDGE VOID is displayed, and push the [OK] key to make a self print.
- 7) Check the self print and use [△] or [▽] key to adjust the value of TAIL EDGE VOID so that the distance B in the figure below is within the specified range.
- Push the [MENU] key several times to display SIDE EDGE VOID, and push the [OK] key to make a self print.
- 9) Check the self print and use [△] or [▽] key to adjust the value of SIDE EDGE VOID so that the total of distances C ands D in the figure below is within the specified range.
- 10) Check that the lead edge is within the specified range.

<Specification>

	Measuring point	Specification	Set value
Lead edge void adjustment (LEAD EDGE VOID)	Output pattern 71 print void A	A = 4.0mm or less (Total of A and B = 8.0mm or less)	Shift of 0.1 mm for set value
Rear edge void adjustment (TAIL EDGE VOID)	Output pattern 71 print void B	B = 4.0mm or less (Total of A and B = 8.0mm or less)	1.
Side edge void adjustment (SIDE EDGE VOID)	Output pattern 71 print void C-D	Total of C and D = 8.0mm or less	

To decrease the void quantity, decrease the set value with $[\ \ \]$ key. To increase the void quantity, increase the set value with $[\ \ \ \]$ key.



E. Resist quantity adjustment

This adjustment is performed in the following cases:

- •When the void quantity is changed by the paper feed tray.
- •When paper feed skew occurs.

Before executing this adjustment, the following adjustments must have been completed.

- •LSU right-angle adjustment
- •Print magnification ratio adjustment
- Print off-center adjustment
- Void area adjustment
- Hold and push the [MENU] key and the [OK] key, turn on the power. ("PCU DIAG MODE ***" is displayed.)
 - Do not touch the keys for about 8sec after releasing fingers from the above keys.
- 2) Push the [MENU] key several times until "TEST PRINT" is displayed, and push the [OK] key to enter the test print mode.
- 3) Make a print with "71" from each paper feed tray.
- Push the [MENU] key several times until PAPER BUCKLE is displayed.

Adjust the resist quantity so that paper is transported normally.


<Factory setup>

PAPER	45CPM	MFT	60
BUCKLE		T1	70
		T2	55
		T3	55
		T4	60
	35CPM	MFT	65
		T1	75
		T2	60
		T3	60
		T4	65

F. Option paper feed tray paper guide adjustment

This adjustment is performed in the following cases:

- •When the option paper feed tray is installed.
- •When the paper size detection fails.
- Hold and push the [MENU] key and the [OK] key, turn on the power. ("PCU DIAG MODE ***" is displayed.)
 - Do not touch the keys for about 8sec after releasing fingers from the above keys.
- Push the [MENU] key several times until "SIZE ADJUSTMENT A" is displayed, and push the [OK] key.
- 3) "MAXIMUM SIZE" is displayed on the LCD.
 - Pull out the cassette, open the paper guide to the maximum, return the cassette to the machine, and push the [OK] key.
- 4) "MINIMUM SIZE" is displayed on the LCD.
 - Pull out the cassette again from the machine, close the paper guide to the minimum, return the cassette to the machine, and push the [OK] key.




G. Manual feed section paper guide position adjustment

This adjustment is performed in the following cases:

- •When the duplex unit with the manual feed unit is installed.
- •When the manual feed tray paper size detection fails.
- Hold and push the [MENU] key and the [OK] key, turn on the power. ("PCU DIAG MODE ***" is displayed.)
 - * Do not touch the keys for about 8sec after releasing fingers from the above keys.



- 2) Push the [MENU] key several times until "SIZE ADJUSTMENT A" is displayed, and push [△] key to display "SIZE ADJUSTMENT B" and push the [OK] key.
- "MAXIMUM SIZE" is displayed on the LCD.
 Check the value displayed with MAXIMUM SIZE. Use [△] or [▽] key to make the displayed value same as the MAX value specified on the label (* Note).
- "P1 SIZE" and a value are displayed. Use [△] or [▽] key to make the displayed value same as the P1 value specified on the label (* Note).
- "P2 SIZE" and a value are displayed. Use [△] or [▽] key to make the displayed value same as the P2 value specified on the label (* Note).
- "MINIMUM SIZE" and a value are displayed. Use [△] or [▽] key to make the displayed value same as the MIN value specified on the label (* Note).



[10] DIAG

1.Diag mode

When the scanner unit is not installed, the machine can be checked and tested with the following diag mode.

Note: If the scanner unit is installed, this mode does not work.

A. Entering the diag mode

With the power OFF, hold and press the [MENU] key and the [OK] key, and at the same time turn on the power.

B. Selecting diag menus

Press the [MENU] key to change the diag menu.

- *Press the [OK] key to execute the test.
- *Press [\triangle] or [∇] key to go to the input menu.
- *Press the [BACK/C] key to return to the previous menu.


C. Canceling the diag mode


Power OFF/ON.


D. Diag mode list


Menu	LCD display
Diag mode initial display	PCU DIAG MODE #
Sensor check mode	SENSOR CHECK XX
LSU test	LASER SYSTEM TEST
LED/LCD test	LED/LCD TEST
High voltage test	HV TEST XXX
Operation test mode	LOAD TEST XX
Auto developer adjustment	AUTOMATIC DV ADJ.
Laser output setup	LASER OUTPUT SETUP (XXX)
Fusing temperature setup	FUSER TEMP. SETTING X
Process control value setup	SLOW UP SETTING
Paper feed size setup	SIZE ADJUSTMENT X
ICU print mode setup	ICU PRINT MODE SET
Test print	TEST PRINT XX
Warm-up time display	WARM UP TIME DISPLAY
Counter display	COUNTER DISPLAY
Counter clear	COUNTER CLEAR
Trouble cancel	TROUBLE CANCEL X
Paper feed tray size setup	XXX SIZE SETUP
Destination setup	DESTINATION SETUP
Paper feed tray paper type setup	TRAY DETECT TYPE xx
CE mark setup	CE MARK SETTING
A3 count mode setup	COUNTUP MODE SETUP X
Maintenance cycle setup	MNT CYCLE SETUP
Operation-at-life-over setup	LIFE OVER SETTING
Finisher jogger adjustment	FINISHER JOGGER ADJ.
Console finisher setup	CONSOLE FIN. SET X
Trouble memory mode setup	MEMORY MODE SETTING
Last JAM code display	LAST JAM CODE DISP
System information display	SYSTEM INFORMATION X
Process control data display	PROCESS DATA DISP X
Port check	CENTRO PORT CHECK
SELECT IN signal setup	SELECT IN SIGNAL SET


E. Diag mode menu transition











F. Diag mode

PCU DIAG MODE #	Initial scre				value	Set range
	illitiai scie	en of the diag mode				
		PCU DIAG M	(ODF			
			מעטו			
		# . # #				
	*To termina	te the diag mode, turn off and on the pov	MΩr			
		number is displayed in the #.	WCI.			
SENSOR CHECK XX		heck mode.				
	Used to che	eck the sensors of the machine and the c	ptions.			
	(LCD displa	y)				
		IACED CYCI	ויח זעידוי	7.00		
		LASER SYST	. E.M. 11	721		
	*Dressing [↑ lor [¬] key selects the sensor group t	for the Sc	ansor check mode		
	Fressing	△] or [▽] key selects the sensor group f	e 36	misor check mode.		
		*PPD1, POD)1,*P(DD2		
		POD3,*DSW	•			
		FOD3, NDSW	и т, D,	J VV Z.		
	*Pressina I	OK] key starts the selected Sensor chec	k.			
		D) blinks during the processing				
		NU] moves to the next sensor data.				
	*Pressing [I	BACK/C] key terminates the Sensor chec	ck Mode.			
	(Selectable	sensor group)				
	00: Main	body				
	PPD1	Paper entry sensor	POD1	Paper sensor 1		
	POD2	Paper exit sensor 2	POD3	Paper sensor 2		
	DSW1	Front door switch	DSW2	Left door switch		
		purpose tray		T		
		Multi-purpose connection detection		Left side door SW		
		Vertical size detection SW4 Vertical size detection SW2		Vertical size detection SW3 Vertical size detection SW1		
		Remaining quantity sensor		Lift upper limit sensor		
		Paper empty sensor	MCPFD			
	02: ADU					
		Manual feed paper length sensor	APIND	ADU paper entry sensor		
		Tray collection sensor	APOD	ADU paper exit sensor		
	MPLS1	Tray pull-out sensor	APPD1	ADU transport sensor 1		
	MPED	Manual paper feed sensor	APPD2	ADU transport sensor 2		
	03: Large	capacity paper feed tray				
	DRS	Left side door SW	TSD	Tandem tray installation detection		
	LUD2	Tandem right tray upper limit sensor	LUD1	Tandem left tray upper limit sensor		
	SPD2	Tandem right tray remaining quantity	SPD1	Tandem left tray remaining quantity		
	DEDO	Sensor	DED4	Sensor Tandom left tray paper empty capsor		
	PED2 PFD3	Tandem right tray paper empty sensor Tandem horizontal transport section	PED1 PFD2	Tandem left tray paper empty sensor Tandem vertical transport section		
		transport sensor	1 02	transport sensor		
		pecified sensor is active, " * "mark will ap		'		

Menu		Cor	ntent		Initial value	Set range
SENSOR CHECK XX		check mode.	_			
	Used to che	eck the sensors of the machine and the c	options.			
	(Selectable	sensor group)				
	,	paper feed unit				
	DRS	Left side door SW	SPD2	Multi-stage desk lower tray remaining		
				quantity sensor		
	SPD1	Multi-stage desk upper tray remaining quantity sensor	CSS24	Multi-stage desk lower tray vertical size detection SW4		
	CSS23	Multi-stage desk lower tray vertical size detection SW3	CSS22	Multi-stage desk lower tray vertical size detection SW2		
	CSS21	Multi-stage desk lower tray vertical size detection SW1		Multi-stage desk upper tray lift upper limit sensor		
	PED2	Multi-stage desk lower tray paper empty sensor	PFD3	Multi-stage desk lower tray transport (paper detection) sensor		
	CSS14	Multi-stage desk upper tray vertical size sensor	CSS13	Multi-stage desk upper tray vertical size sensor		
	CSS12	Multi-stage desk upper tray vertical size sensor	CSS11	Multi-stage desk upper tray vertical size sensor		
	LUD1	Multi-stage desk upper tray lift upper limit sensor	PED1	Multi-stage desk upper tray paper empty sensor		
	LUD1	Multi-stage desk upper tray lift upper limit sensor				
	05: Finish					
	STHP	Stapler home position sensor	PSHP	Pusher home position sensor		
	POD	Paper exit sensor	PPD	Paper hold return sensor		
	SCID	Staple paper entry sensor	DSW2	Front door open/close sensor		
	PID T2PD	Paper entry sensor	DSW1 24VM	Right upper door open/close sensor		
	T2DN	Offset tray paper sensor Offset tray lower limit sensor	T1PF	24V supply monitor signal Upper tray full sensor		
	T2UP	Offset tray upper limit sensor	STSP	Stapler staple ready sensor		
	JRHP	Jogger R home position sensor	STLS	Stapler staple empty sensor		
	JFHP	Jogger F home position sensor	STNC	Stapler cartridge empty sensor		
	SCID2	Staple paper entry sensor 2	DOPD	Upper cover open/close sensor		
	STHP2	Staple rotation home position sensor	MMLK	Main motor lock signal		
	STHP1	Staple rotation home position sensor	SCPD	Paper sensor		
	-	Staple shift home position sensor				
	06: Sadd	le finisher	_	,		
	07: Male	bin stacker				
	24MV	24V detection	PFD1	Paper exit full sensor 1		
	DD1	Front cover open/close sensor	PFD2	Paper exit full sensor 2		
	DOPD	Upper cover open/close sensor	PFD3	Paper exit full sensor 3		
	PID	Paper entry sensor	PFD4	Paper exit full sensor 4		
	PPD1	Transport sensor 1	PFD5	Paper exit full sensor 5		
	PPD2	Transport sensor 2	PFD6	Paper exit full sensor 6		
	PPD3	Transport sensor 3	PFD7	Paper exit full sensor 7		
	PPD4	Transport sensor 4	PFD8	Paper exit full sensor 8		
	PPD5	Transport sensor 5		are the concernous		
LACED OVOTERATECT		pecified sensor is active, " * "mark will ap	ppear ber	ore the sensor name.		
LASER SYSTEM TEST		eck the operation of the laser system.				
		LASER SYST	EM T	EST		
		OK] key turns on the polygonal mirror a	nd the las	er.		
	,	D) blinks during the processing				
		polygonal mirror does not rotate and the		ppen, ERROR LED lights up.		
	vvnen tne	HSYNC is properly detected, READY lig	nıs up.			


			Cor	ntent	Initial value	Set range
LED/LCD TEST		display test. eck the lighting test	of the operation pane	el LED and LCD.		
			LED/LCD TE	CST		
				inated by pressing [BACK/C] key.		
	*All LCD do	ots will be "on" during	g the operation.			
HV TEST XXX	High voltage Used to per (LCD display	rform the output test	from the high voltag	e PWB.		
			HV TEST XX	XX		
	*Pressing *Using [△] *Pressing		ligh voltage output.			
		econds high voltage	output is terminated. ates the High voltage			
		econds high voltage	output is terminated.			
		econds high voltage BACK/C] key termin	output is terminated.	e test.		
		econds high voltage BACK/C] key termin XXX:	output is terminated. ates the High voltage Main charger / Grid Transfer High volta	e test. d bias test ge test		
		Econds high voltage BACK/C] key termin XXX: MC/GRID(xx): THV+(x): BS(xx):	output is terminated. ates the High voltage Main charger / Grid	e test. d bias test ge test		
		Econds high voltage BACK/C] key termin XXX: MC/GRID(xx): THV+(x): BS(xx): BS PLUS:	output is terminated. ates the High voltage Main charger / Gric Transfer High volta Developer bias tes Developer bias tes	d bias test ge test t /Volume t(cleaning mode)		
		Econds high voltage BACK/C] key termin XXX: MC/GRID(xx): THV+(x): BS(xx): BS PLUS: SHV(x):	output is terminated. ates the High voltage Main charger / Grid Transfer High volta Developer bias tes Developer bias tes separate high volta	d bias test ge test t /Volume t(cleaning mode) age test		
		Econds high voltage BACK/C] key termin XXX: MC/GRID(xx): THV+(x): BS(xx): BS PLUS:	output is terminated. ates the High voltage Main charger / Gric Transfer High volta Developer bias tes Developer bias tes	d bias test ge test t /Volume t(cleaning mode) age test		
		Econds high voltage BACK/C] key termin XXX: MC/GRID(xx): THV+(x): BS(xx): BS PLUS: SHV(x): THV-:	output is terminated. ates the High voltage Main charger / Grid Transfer High volta Developer bias tes Developer bias tes separate high volta transfer cleaning h	d bias test ge test t /Volume t(cleaning mode) age test		
		econds high voltage BACK/C] key termin XXX: MC/GRID(xx): THV+(x): BS(xx): BS PLUS: SHV(x): THV-:	output is terminated. ates the High voltage Main charger / Grid Transfer High volta Developer bias tes Developer bias tes separate high volta transfer cleaning h	d bias test ge test t /Volume t(cleaning mode) age test igh voltage test		
		econds high voltage BACK/C] key termin XXX: MC/GRID(xx): THV+(x): BS(xx): BS PLUS: SHV(x): THV-:	output is terminated. ates the High voltage Main charger / Grid Transfer High volta Developer bias tes Developer bias tes separate high volta transfer cleaning h	d bias test ge test t /Volume t(cleaning mode) age test		
		Econds high voltage BACK/C] key termin XXX: MC/GRID(xx): THV+(x): BS(xx): BS PLUS: SHV(x): THV-: X F Front	Main charger / Grid Transfer High volta Developer bias tes separate high volta transfer cleaning h	d bias test ge test t /Volume t(cleaning mode) age test igh voltage test AE mode		
		Econds high voltage BACK/C] key termin XXX: MC/GRID(xx): THV+(x): BS(xx): BS PLUS: SHV(x): THV-: X F Front	Main charger / Grid Transfer High volta Developer bias tes separate high volta transfer cleaning h XX AE CHR	d bias test ge test t /Volume t(cleaning mode) age test igh voltage test AE mode Text mode		
		Econds high voltage BACK/C] key termin XXX: MC/GRID(xx): THV+(x): BS(xx): BS PLUS: SHV(x): THV-: X F Front	Main charger / Gric Transfer High volta Developer bias tes separate high volta transfer cleaning h XX AE CHR MIX	d bias test ge test t /Volume t(cleaning mode) age test igh voltage test AE mode Text mode Text/Photo mode		

Menu		Con	tent		Initial value	Set ran
AD TEST XX	Load test mode.					
	Used to perform t	the operation test of the motors and	I clutches of the	machine and the options.		
	(LCD display)					
		LOAD TEST	XX			
	*Pressing [△] or	[igtriangledown] key selects the LOAD group fo	r the Load Test	mode.		
	*Press [OK] key t	o determine the load operation grou	up.			
	*Press [MENU] k	ey to select the load to be tested.				
		ey starts the selected Load Test.				
		nks during the processing.				
		C] key terminates the Load Test Mo	ode.			
	0.	. ,				
	(Selectable Loads	s Group)				
	00: Main body					
	MSWPR		VG_FAX	Grid FAX		
	HLPR		VG_PRT	Grid Printer		
	DCPR		VG PHT	Grid Photo		
	MM	Main motor	VG_MIX	Grid Text/Photo		
	DM	Drum motor	VG_CHR	Grid Text		
	DSB_FW	Paper exit motor normal rotation	VG_AE	Grid AE		
	DSB_RV	Paper exit motor reverse rotation	THV+_BACK	Transfer voltage back		
	TM	Toner motor	THV+_FRONT	Transfer voltage front		
	CPFC	Paper cassette paper feed clutch		Transfer cleaning		
	RRC	Resist roller clutch	SHV_BACK	Separation voltage back		
	TRC	Paper transport clutch	SHV_FRONT	Separation voltage front		
	FGS_FIN	100				
	TRC_DSK	Paper transport desk				
	LUM HL1	Lift-up motor				
	HL2	Fusing lamp 1 Fusing lamp 2				
	BS_PLUS	Developing bias				
	BS_FAX	Developing bias (FAX)				
	BS_PRT	Developing bias (Printer)				
	BS_PHT	Developing bias (Photo)				
	BS_MIX	Developing bias (Text/Photo)				
	BS_CHR	Developing bias (Text)				
	BS_AE	Developing bias (AE)				
	FMHi	Fan motor high speed				
	FMLo	Fan motor low speed				
	PSPS	Separation solenoid				
	01: Multi-purpo	ose tray				
	MCM	MP tray drive motor control	MCPCL	MP tray paper feed clutch		
	MCFCL	MP tray transport clutch	MCULM	MP lift-up motor		
	02: ADU (Man	ual paper feed section)				
	MPFS	Manual paper feed solenoid	MSS	Shutter solenoid		
	MPFC	Manual paper feed clutch				
	03: ADU					
	ADMEN1	Upper transport motor	DGS	Gate solenoid		
	ADMEN2	Lower transport motor				
	04: Large capa	acity paper feed tray				
	TLUM2	Tandem right tray lift-up motor	TLUM1	Tandem left tray lift-up motor		
	L_MCLM	Multi-purpose tray lift-up motor	TPFCL	Transport clutch		
	TPCL2	Tandem right tray paper feed	TPCL1	Tandem left tray paper feed		
		clutch		clutch		
	L_MCPCL	Multi-purpose tray paper feed	TMM	Transport motor		
		clutch				
	05: 3-stage pa	per feed desk				
	DLUM2	Multi-stage desk lower tray lift-up	DLUM1	Multi-stage desk upper tray lift-		
		motor		up motor		
	D_MCLM	Multi-purpose tray lift-up motor	DPFCL	Transport clutch		
	DPCL2	Multi-stage desk lower tray	DPCL1	Multi-stage desk upper tray		
		paper feed clutch		paper feed clutch		
	D_MCPCL	Multi-purpose tray paper feed	DMM	Transport motor		
		clutch				

Menu			Content		Initial value	Set range	
LOAD TEST XX	Load test mode						
	Used to perform	the operation test of the motor	s and clutches of th	ne machine and the options.			
	(0.1						
	(Selectable Loa 06: Finisher	as Grope)					
	T2S	Offeet trougelensid	STUM	Ctanla shift mater	_		
	T2OM	Offset tray solenoid Offset tray paper exit motor	MM	Staple shift motor Main motor			
	SPS	Stopper solenoid	EVM	Elevator motor			
	SCRS	Pressure relief solenoid	STM	Staple motor			
	PPS	Rear edge holding solenoid	JRM	Jogger R motor			
	SCGS	Staple paper entry gate sole	enoid JFM	Jogger F motor			
	STTM	Staple rotation motor	PSM	Finisher motor			
	07: Saddle fir	nisher	•	,			
	FFC		FRJM				
	FPSM		FFJM				
	FPNM		FAM				
	FLM		FPM				
	FFSM		FFM				
	08: Male bin	stacker					
	MM	Main drive motor	MGSOL4	Gate solenoid 4			
	MGSOL1	Gate solenoid 1	MGSOL5	Gate solenoid 5			
	MGSOL2	Gate solenoid 2	MGSOL6	Gate solenoid 6			
	MGSOL3	Gate solenoid 3	MGSOL7	Gate solenoid 7			
AUTOMATIC DV ADJ.	Automatic DV	adiustment.					
		the auto developer adjustmen	•				
	(LCD display)						
		7.1100.47.00					
		AUTOMAT.	IC DV ADJ.				
				128			
		key starts the automatic DV ad					
		ensor value is displayed in the	-CD during the ope	ration.			
		links during the processing	N.P. alata and				
		ent error occurred, ERROR LEI					
	-	ue is memorized after 2 minute	_				
	*Pressing [BACK/C] key terminates the adjustment mode.						
LASER OUTPUT	Laser output setup.						
SETUP (XXX)	Used to set the laser output value.						
	Note: Do no	t change the factory setup on the	ne laser output.				
	(LCD display)						
		LASER PO	OWER SET (>	(X)			
		or [$igtriangle$] key selects the LASER C		ode.			
		key starts the laser output setu	p.				
		*Using [\triangle] or [∇] key changes the value.					
		ey memorize the value.					
	*Pressing [BAC	K/C] key terminates the setting.					
		XX					
	 	AE AE mod	le				
		CHR Text mo					
			oto mode				
		PHT Photo r					
		PRT Printer					
		FAX Fax mo	i				

Menu	Content	Initial value	Set range
FUSER control temperature setting X	Fuser control Temperature setting. Used to set the fusing temperature. (LCD display)		
	FUSER TEMP.SETTING X		
	*Using [△] or [▽] key select the thermistor. *Pressing [OK] key starts the setting. *Using [△] or [▽] key changes the value. *Pressing [OK] key memorize the value.		
	*Pressing [BACK/C] key terminates the setting.		
	X:		
	A: control temperature FUSER 1		
	B: control temperature FUSER 2		
	C: preheat temperature FUSER 1		
	D: preheat temperature FUSER 2		
	E: Bypass tray control temperature FUSER 1 F: Bypass tray control temperature FUSER 2		
SLOW UP SETTING	Process control value setting. Used to set the process control value for each destination.		
	SLOW UP SETTING X		
	*Using [\triangle] or [∇] key select the process control value.		
	*Pressing [OK] key starts the setting.		
	*Using [△] or [▽] key changes the value.		
	*Pressing [OK] key memorize the value. *Pressing [BACK/C] key terminates the setting.		
	X:		
	A: slow up adjust wait time		
	B: Vb1-1		
	C: Vb1-2		
	D: Vb1-3		
	E: Vb2-1		
	F: Vb2-2		
	G: Vb2-3		

Menu	Content	Initial value	Set range
SIZE adjstment X	SIZE adjustment. Used to perform the size detection adjustment of the optional universal tray and the manual (LCD display)	ieed tray.	
	SIZE ADJUSTMENT X		
	*Using [△] or [▽] key select the tray. Pressing [OK] key enter the adjustment mode.		
	(Selectable modes)	ļ	
	X:	ļ	
	A: A3 Universal tray adjustment		
	B: Bypass tray setting		
	C: Bypass tray adjustment		
	<select a=""></select>		
	1. Widen the guide to the MAXIMUM position.		
	*Pressing [OK] key starts the adjustment.	ļ	
	Narrow the guide to the MINIMUM position. *Pressing [OK] key starts the adjustment.	ļ	
	*Pressing [BACK/C] key terminates the setting.		
	<pre><select b=""></select></pre>		
	*Pressing [OK] key displays the adjustment value.		
	*Using $[\triangle]$ and $[\nabla]$ keys changes the value.		
	*Pressing [OK] key set the changes of the value, and moves to the next mode		
	*Pressing [BACK/C] key terminates the setting.		
	<pre><select c=""></select></pre>		
	Widen the guide to the MAXIMUM position. *Pressing [OK] key starts the adjustment.		
	2. Guide to the P1 position.		
	*Pressing [OK] key starts the adjustment.		
	3.Guide to the P2 position.		
	*Pressing [OK] key starts the adjustment.		
	4.Narrow the guide to the MINIMUM position.		
	*Pressing [OK] key starts the adjustment.		
ICH DDINT MODE SET	*Pressing [BACK/C] key terminates the setting.		
ICO FRINT WODE SET	Icu print mode setting.	ļ	
	ICU PRINT MODE SET	ļ	
		ļ	
	*Press [OK] key to start the setup mode.		
	*Press [MENU] key to shift to the next item.		
	*Pressing [MENU] moves to the next item		
	*Using [△] and [▽] keys changes the mode.		
	*Pressing [BACK/C] key releases the print mode set.		
	*Pressing [OK] key starts the print mode set.		
	*DATA (LED) blinks during the print mode set execution.		



Menu		•	Content		Initial value	Set range		
	Printing Test							
L	Jsed to perform self-print	ing under the set condi	itions, and to adjust and check the	ne engine set value.				
	Selection Menu:							
	LCD display	Content	Set value	<u>, </u>				
	MULTI SETTING	Continuous print	001 - 999					
	WOLITSETTING	quantity setup	001 - 998					
	PRINT PATTERN	Test print pattern	1 - 99 (94 - 97 for pro	duction only)				
		root print pattorn	1	Off center pattern				
			40	White copy				
			64	All white copy				
			70	Scale pattern				
			70	Grid pattern				
				-				
			75	ID: BG pattern				
	04005775	0	87	Test image pattern				
	CASSETTE	Cassette selection	BPT: No. 1 tray TRAY1: No. 1 tray (STD) TRAY2: No. 2 tray	DESK1: No. 3 tray DESK2: No. 4 tray LCC: LCC tray				
	DUPLEX	Duplex setup	NO/USE	-				
	OUTPUT	Paper exit,	STD: Standard paper exit tray	SADLE: Saddle				
		finishing	JSP:	OFFSET: Offset				
		method setup	FIN1: Finisher Top	PUNCH: Punch				
			FIN2: Finisher Second	MAIL_TEST				
			STAPLE (F): Staple front STAPLE (R): Staple rear	BIN1: No. 1				
			STAPLE (R): Staple real STAPLE (2POS): Staple	~ bin-BIN8: No.8 bin				
			2 positions					
	LEAD EDGE	Lead edge	1 - 99 (mn					
	LEAD EDGE VOID	Lead edge void setup	1 - 99 (mn	,				
	TAIL EDGE VOID	Rear edge void setup	1 - 99 (mn	,				
	SIDE EDGE VOID	Side edge void setup	1 - 99 (mn	,				
	T1 PAPER BUCKLE	Tray 1	1 - 99	"'/				
	TTTAL EN BOOKEE	resist quantity setup	1 33					
	T2 PAPER BUCKLE	Tray 2	1 - 99					
		resist quantity setup						
	T3 PAPER BUCKLE	Tray 3 resist quantity setup	1 - 99					
	T4 PAPER BUCKLE	Tray 4	1 - 99					
		resist quantity setup						
	MFT PAPER BUCKLE	quantity adjustment	1 - 99					
	ADU PAPER BUCKLE	quantity setup	1 - 99					
	MFT OFF CENTER ADJ	Manual feed tray off-center adjustment	0 - 99					
	T1 OFF CENTER ADJ	of-center adjustment	0 - 99					
	T2 OFF CENTER ADJ	off-center adjustment	0 - 99					
	T3 OFF CENTER ADJ	Desk 1 tray/LCC1 off-center adjustment	0 - 99					
	T4 OFF CENTER ADJ	Desk 2 tray/LCC2 off-center adjustment	0 - 99					
	ADU OFF CENTER ADJ	Duplex off-center adjustment value setup	0 - 99					

Menu				Content		Initial value	Set range
WARM UP TIME DISPLAY	Us	irm up time di ed to display th CD display)	splay mode. ne warm-up time.				
			WARM UP	TIME DISPLA	Y		
			ey enter the Warm up time disp (C] key terminates the Warm u				
COUNTER DATA DISPLAY	Us	unter data dis ed to display e CD display)	splay. ach counter value.				
			COUNTER	DISPLAY			
	*Pr	essing [BACK DUNTER DISP					
		COUNTER DIS	SP.	PROCESS COUNTER	R DISP.		
		TOTAL	Total print quantity	DRUM	Drum counter		
		DRUM	Drum counter	TONER	Toner counter		
		TONER	Toner counter	DEVE	Developing counter		
		DEVE	Developing counter	MAINTE	Maintenance counter		
		MAINTE	Maintenance counter		Drum motor drive time		
		TOTAL DUTPUT	Copy counter (Effective paper counter)	DV MOTOR TIME	Developing motor drive time		
		STAPLE COUT		PROCESS WAY	Process system		
		STAPLE	Staple counter	DESTINATION	Destination		
		PUNCH	Punch counter				
		FEED COUNTI					
			Paper feed tray 1 counter				
			Paper feed tray 2 counter				
			Paper feed tray 3 counter LCC2				
			or paper feed tray 4 counter				
		MFT	Manual paper feed counter				
	P	\DJ	Duplex counter				

Menu				Conte	ent		Initial value	Set range
COUNTER DATA	Counter dat	a clear.						
LEAR	Used to clea	r each co	ounter v	alue.				
	(LCD display	/)						
				XXXXX COUNT				
				XXXXX COUNT	ER CLEAR			
	*Pressing th	e[∧]or	[selects the counter group	ip for the counter clear mo	da		
	-			he counter clear group.	ip for the counter clear mo	uc.		
	*Using [MEN			- ·				
		-		s changes the YES or N	O.			
	_			counter data clear mode				
		-		inates the counter data of				
		_	•					
	COUNTER (CLEAR:						
	FEED CO	UNTER	CLEAR		DEVE COUNTER CLEAF	₹		
	TRAY1	F	Paper fee	ed tray 1 counter	DEVE	Developing counte	er	
	TRAY2		•	ed tray 2 counter	DRUM COUNTER CLEA	, ,		
	LCC1/TR/		•	ed tray 3 counter	DRUM	Drum counter		
	LCC1/TR/		•	•	TONER COUNTER CLEA		-	
	MFT			paper feed counter	TONER	Toner counter		
	ADU		Duplex c	•	OUTPUT COUNTER CLE			
	STAPLE C		•		TOTAL OUTPUT	Copy counter		
	SIAPLE	JOUNTE	K CLEA	.rx	TOTAL OUTPUT	(Effective paper		
						counter)		
	STAPLE	ç	Staple co	ounter	TIMER DATA CLEAR	,		
	PUNCH		Punch co		DRUM ROTATION	Drum motor RPM		
	MNT COL			Juntoi	DEVE ROTATION	Developing motor		
	WINT OOC	NVI LIK O	ZEZAK		DEVE KOTATION	RPM		
	MENTEN	ANCE I	Maintena	ance counter				
ROUBLE CANCEL X								
	Used to cand		ıble code	Э.				
	(LCD display	")						
				TROUBLE CAN	JCEL X			
	*Pressing the	e [△] or	[selects the trouble canc	el mode.			
	*Pressing [OK] key start the trouble cancel mode.							
	*Using [△] a	and [▽] k	keys cha	inges the YES or NO.				
	*Pressing [O	K] key st	tarts the	trouble cancel mode.				
	*Pressing [B	ACK/C] k	key term	inates the trouble cancel	mode.			
		X:	. 1					
		E-TI		Cancal traubles except for	or U2 in the engine mode.			
		E-U		Cancel U2 trouble in the	<u> </u>			
		C-TI		Cancel trouble in the cor				
			DL	Cancel trouble in the cor	itoroller mode.			
XX SIZE SETUP	Tray size se							
0000122 02101			r size on	No. 1 paper feed tray ar	nd the LCC tray.			Tray1
	(LCD display	<i>'</i>)						Set
	(LOD diopid)			XXX SIZE SE	TTUP			value
	(200 diopid)			, > 1				A4
	(LOD diopid)							1 ——
	(LOD diopia)							B5
		e [△] or	[select the tray.				
				•				
	*Pressing the	K] key di	isplays t	he tray size.				8.5"x11
	*Pressing the *Pressing [O *Using [△] a	K] key di and [▽] k	isplays t keys cha	he tray size. Inges the tray size.				
	*Pressing the *Pressing [O *Using [△] a *Pressing [O	0K] key di and [\bigtriangledown] k 0K] key se	isplays to keys cha et the ch	he tray size.				8.5"x11
	*Pressing the *Pressing [O *Using [△] a *Pressing [O	OK] key di and [▽] k OK] key se ACK/C] k	isplays to keys cha et the ch key term	he tray size. anges the tray size. ange of the tray size.				8.5"x11
	*Pressing the *Pressing [O *Using [△] a *Pressing [O	0K] key di and [▽] k 0K] key se ACK/C] k	isplays to keys char et the char key term X:	the tray size. Inges the tray size. Inange of the tray size. Inates the setting.				8.5"x11 LCC Set
	*Pressing the *Pressing [O *Using [△] a *Pressing [O	OK] key di and [▽] k OK] key se ACK/C] k	isplays to keys cha et the ch key term X:	he tray size. anges the tray size. ange of the tray size.				8.5"x11 LCC Set value

Menu			Со	ntent		Initial value	Set range
DESTINATION SETUP		orm the destination setu	ıp.				
	(STIND TI	ON SETUP			
			DIINAII	ON SEIGI			
	*Pressing the	 e [△] or [▽] key select	the destination	ı.			
	*Pressing [O	K] key displays the dest	ination.				
		and [\bigtriangledown] keys changes th PK] key set the change o		n.			
		ACK/C] key terminates					
TRAY DETECT TYPE xx			s and the inch	series for size detection of each page	aper feed tray.		Set
		TR.	AY DETE	CT TYPE XXX			AB INCH
	*Pressing the	 e [∆] or [▽] key select	the trav				
		$[C] \times [C] $					
		and [\bigtriangledown] keys changes th (K] key set the change o		n			
		ACK/C] key terminates		11.			
		XX:					
		M:		MFT			
		T2: T3:		A3 Universal tray Desk tray1			
		T4:		Desk tray2			
CE MARK SETTING	CE mark se Used to set t (LCD display	the operation mode conf	forming to the (CE mark.			Set value
		CE	MARK SI	ETTING			YES NO
	*Using [△] a *Pressing [O	DK] key start the setting. and [♥] keys changes the DK] key memorize the CE ACK/C] key terminates	ne YES or NO. E mark mode.				
COUNTUP MODE SETUP		et the count-up mode of a					A ~ C Set value
		COUNTUP MODE SETUP X					SINGLE DOU- BLE
	*Pressing [O	*Pressing the [△] or [▽] key select the counter mode. *Pressing [OK] key start the setting. *Using [△] and [▽] keys changes the countup number.					D
	*Pressing [O	oK] key memorize the co ACK/C] key terminates the	untup number.				Set value NO
		X:					(NO- COUNT
		Α.		Loounton A0/44V47\			
		A: B:		I counter A3(11X17) countup mod nte counter A3(11X17) countup mod			UP)
		A: B: C:	maii	I counter A3(11X17) countup mod nte counter A3(11X17) countup mod e counter A3(11X17) countup mod	ode.		

Menu	Content	Initial value	Set range
MNT CYCLE SETUP	Maintenance cycle setup. Used to set the maintenance cycle. (LCD display)		Set value
	MNT CYCLE SETUP		DEFAU LT 40K
	*Pressing [OK] key displays the maintenance cycle. *Using [△] and [▽] keys changes the maintenance cycle. *Pressing [OK] key set the change of the maintenance cycle. *Pressing [BACK/C] key terminates the setting.		50K 80K 100K 120K FREE
LIFE OVER SETTING	Life over setting. Used to set whether to stop printing when the developer life is over. (LCD display)		Set value
	LIFE OVER SETTING		YES NO
	*Pressing [OK] key start the setting. *Using [△] and [▽] keys changes the YES or NO. *Pressing [OK] key memorize the life over mode. *Pressing [BACK/C] key terminates the setting.		
FINISHER JOGGER ADJ.	Finisher jogger adjustment. Used to adjust the finisher (AR-FN6/FN7) jogger. For details, refer to each Service Manual of the AR-FN6/FN7. (LCD display)		
	FINISHER JOGGER ADJ.		
	*Press [OK] key to display the finisher jogger adjustment value. *Using [△] or [▽] key changes the value. *Press [MENU] key to display the adjustment value. *Press [△] or [▽] key to change the value. *Pressing [OK] key starts the finisher jogger adjustment.		
CONSOLE FIN. SET X	*DATA (LED) blinks during the processing. *Pressing [BACK/C] key terminates the finisher jogger adjustment. Console finisher setting.		
	Used to perform the adjustments of the console finisher (AR-FN7). For details, refer to the Service Manual of the AR-FN7. (LCD display)		
	CONSOLE FIN. SET X		
	*Pressing the [△] or [▽] key select the console finisher mode. *Pressing [OK] key start the setting. *Using [△] and [▽] keys changes the value. *Pressing [OK] key manariza they like.		
	*Pressing [OK] key memorize thevalue. *Pressing [BACK/C] key terminates the setting.		

Menu	Content				Initial value	Set range
CONSOLE FIN. SET X	Used to perfe			nsole finisher (AR-FN7). he AR-FN7.		
			X:			
			A:	saddle binding position		
			B:	saddle fold position		
			C:	console finisher adjustment (front)		
			D:	console finisher adjustment (rear)		
			E:	staple position (rear)		
			F:	staple position (front)		
			G:	center adjustment (staple)		
			H:	staple pitch		
			l:	center adjustment (punch)		
			J:	punch position		
			J.	purier position		
TROUBLE MEM. MODE SET				memory in case of a trouble.		Set value
			MEMORY	MODE SETTING		ONCE ANY
	*Using [△] a *Pressing [O	K] key memor	changes the value			
		Set value		Operation		
		ONCE	The same troub	ele as the previous one is not stored.		
		ANY		tored unconditionally.		
LAST JAM CODE DISP	Last iam co	de display.				
		lay the jam his	story.			
			LAST 3	JAM CODE DISP		
	51-	1 - 7	he last jam code	display mode. jam code display mode.		
SYSTEM		rmation disp				
INFORMATION X	Use to display	y the machine)	e information.			
		SYSTEM INFORMATION X				
	*Pressing the [△] or [▽] key selects the group. *Pressing [OK] key displays the system information.					
	*Using [MENU] moves to the next item. *Pressing [BACK/C] key terminates the system information					
	Mode group	is:				
			X:			
			A:	ROM version		
			B:	machine speed		
			C:	process type		
L						

Menu			Content	Initia value	Set range
PROCESS DATA DISPLAY	Process cor (LCD display	trol data display.)			
		DRUM AD	J. (VG)		
	*Pressing [O *Using [MEN	$[\triangle]$ or $[\nabla]$ key selects the group $[K]$ key displays the process control $[V]$ moves to the next item $[ACK/C]$ key terminates the process	ol data.		
	group is:				
		X:			
		A:	process control data		
		B:	toner control data		
XXX CHECK.	Controller p (LCD display				
		CENTRO	PORT CHECK OK		
	*Pressing [O	$e[\triangle]$ or $[\bigtriangledown]$ key selects the port $e[A]$ key start the port check. ACK/C] key terminates the the po			
	[XXX:		¬	
		7000	CENTRO PORT CHECK	-	
			NIC CHECK (network interface card check)		
SELECT IN SIGNAL SET	Select in sig (LCD display				
		SELECT	IN SIGNAL SET ON		
	*Using the [/ *Pressing [O	K] key start the select in signal se ∆] and [♥] keys changes the ON K] key starts the select in signal s ACK/C] key terminates the select	or OFF. etting.		

[11] TROUBLE CODES

1.Trouble codes list

Trouble		Contents	Remark	Trouble
COC		110		detection
C1		MC trouble		PCU
E7		Laser trouble	With LIDD	Controller
	03	HDD trouble	With HDD installed	
	06	Decode error trouble		Controller
	50	LSU connection trouble		PCU
F1	00	Finisher communication trouble	With Finisher installed	PCU
•	80	Finisher staple shift motor trouble	With Finisher installed	PCU
	80	Finisher 24V power supply trouble	With Finisher installed	PCU
	87	Finisher staple rotation motor trouble	With Finisher installed	
F1	00	Mail bin stacker communication trouble	With Mail bin stacker installed	PCU
	02	mail bin stacker main drive motor trouble	With Mail bin stacker installed	PCU
	12	Mail bin stacker gate trouble	With Mail bin stacker installed	PCU
	80	Mail bin stacker 24V power supply trouble	With Mail bin stacker installed	PCU
F1	03	Console finisher paddle motor trouble	With Console Finisher installed	PCU
	06	Console finisher slide motor	With Console	PCU
	UO	trouble	Finisher	1 00
		Trouble	installed	
	10	Console finisher stapler motor	With Console	PCU
		trouble	Finisher installed	
	11	Console finisher bundle exit	With Console	PCU
		motor trouble	Finisher installed	
•	15	Console finisher lift motor trouble	With Console Finisher installed	PCU
	19	Console finisher alignment motor trouble FRONT	With Console Finisher	PCU
			installed	
	20	Console finisher alignment motor trouble	With Console Finisher	PCU
			installed	
	30	Console finisher communication trouble	With Console Finisher installed	PCU
	31	Console finisher fold sensor trouble	With Console Finisher installed	PCU
	32	Console finisher punch unit communication trouble	With Console Finisher installed	PCU
	33	Console finisher punch side register motor trouble	With Console Finisher installed	PCU
	34	Console finisher punch motor trouble	With Console Finisher installed	PCU
	35	Console finisher punch side register sensor trouble	With Console Finisher installed	PCU

Troi	ماطر	Contents	Remark	Trouble
Trouble codes		Contents	Remark	Trouble detection
F1	36	Console finisher punch timing	With Console	PCU
' '	00	sensor trouble	Finisher	. 00
			installed	
	37	Console finisher backup RAM	With Console	PCU
		trouble	Finisher	
			installed	
	38	Console finisher punch backup	With Console	PCU
		RAM trouble	Finisher	
			installed	
	81	Console finisher transport	With Console	PCU
		motor trouble	Finisher	
-		-	installed	DOLL
F2	00	Toner concentration sensor		PCU
	00	open		DOLL
	02	Toner supply abnormality		PCU
	04	Improper cartridge (Destination error, life cycle		PCU
		error)		
	05	CRUM error		PCU
		Process thermistor breakdown		PCU
F2	39			PCU
F3	12	Tray 1 lift-p trouble	NA III	
	22	Tray 2 lift-up trouble (Multi-purpose tray)	Multi-purpose	PCU
H2	00	1,	tray	DOLL
HZ.	00	Thermistor open (HL1)		PCU
1.10	01	Thermistor open (HL2)		PCU
H3	00	Heat roller high temperature		PCU
	04	detection (HL1)		PCU
	01	Heat roller high temperature detection (HL2)		PCU
H4	00	Heat roller low temperature		PCU
П4	00	detection (HL1)		PCU
	01	Heat roller low temperature		PCU
	01	detection (HL2)		1 00
H5	01	5-time continuous POD1		PCU
		not-reaching JAM detection		
L4	01	main motor lock detection		PCU
	02	Drum motor lock detection		PCU
L6	10	Polygon motor lock detection		PCU
L8	01	No full-wave signal		PCU
	02	Full-wave signal width		PCU
	-	abnormality		
U6	00	Desk/LCC communication	With Paper feed	PCU
		trouble	desk installed	
'	01	Desk/LCC1CS lift-up trouble	With Paper feed	PCU
		(Multi-purpose tray)	desk installed	
'	02	Desk2 CS lift-up trouble/LCC1	With Paper feed	PCU
		lift-up trouble	desk installed	
	03	Desk3 CS lift-up trouble/LCC2	With Paper feed	PCU
		lift-up trouble	desk installed	
	10	Desk/LCC transport motor	With Paper feed	PCU
		trouble	desk installed	
EE	EL	Auto developer adjustment	Only during	PCU
	F	trouble (Over-toner)	DIAG	DOLL
	EU	Auto developer adjustment	Only during DIAG	PCU
F0	00	trouble (Under-toner)	DIAG	Controlle
F9	02	Centro port check error		Controller
	03	NIC port check error	March East:	Controller
U1	01	Battery abnormality	With FAX board	Controller
110	00	EEDDOM read/with a read	installed	Contactica
U2	00	EEPROM read/write error (Controller)		Controller
	11	Counter check sum error		Controller
	11	(Controller EEPROM)		Controller
L		(similar LEI (tolvi)	1	

Tro	uble	Contents	Remark	Trouble
codes				detection
110	40	A diverter and value also also asset		Caratrallar
U2	12	Adjustment value check sum		Controller
		error (Controller EEPROM)		
	90	PCU section EEPROM read/		PCU
		write error		
	91	PCU section memory sum		PCU
		check error		
U7	00	PC/MODEM communication		Controller
07	00			Controller
		error		
PF		RIC copy inhibit command		Controller
		reception		
011		'		DOLL
СН		Door open (CH ON)		PCU
	00	No developer cartridge		PCU
	01	No toner cartridge		PCU
		Auditor not ready		Controller
PC		Personal counter not installed		Controller
		I .		1

2.Details of trouble codes

MAIN	SUB		
C1	00	Content	MC trouble
		Detail	Main charger output abnormality (Output open) Trouble signal is outputted from the high voltage transformer.
		Cause	The main charger is not installed properly. The main charger is not assembled properly. Disconnection of connector of high voltage transformer. High voltage harness disconnection or breakage.
		Check and remedy	Use the diag mode or DIAG to check the main charger output. Check for disconnection of the main charger. Replace the high voltage unit.
E7	02	Content	Laser trouble
		Detail	BD signal from LSU is kept OFF, or ON.
		Cause	The connector of LSU or the harness in LSU is disconnected or broken. The polygon motor does not rotate normally. The laser home position sensor in LSU is shifted. The proper voltage is not supplied to the power line for laser. Laser emitting diode trouble PCU PWB trouble Controller PWB trouble
		Check and remedy	Check for disconnection of the LSU connector. Use DIAG (SIM 61-1) to check LSU operation. Check that the polygon motor rotates normally or not. Check light emission of laser emitting diode. Replace the LSU unit. Replace the PCU PWB. Replace the Controller PWB.

MAIN	SUB		
E7	03	Content	HDD trouble
		Detail	HDD does not operate properly in the machine with HDD installed.
		Cause	HDD is not installed properly to the Controller PWB.
			HDD does not operate properly in the Controller PWB. Controller PWB trouble
		Check and	Check installation of HDD to the Controller
		remedy	PWB. Check connection of the harness of HDD to the Controller PWB. Use DIAG (SIM 62-2, -3) to check read/write of HDD. Replace HDD. Replace Controller PWB.
	06	Contont	Decode error trouble
	00	Content Detail	
		Detail	A decode error occurs during making of an image.
		Cause	Data error during input from PCI to PM. PM trouble Data error during image compression/ transfer.
			Controller PWB abnormality
		Check and remedy	If the error occurred in a FAX job, check installation of the FAX PWB. For the other cases, check the Controller
			PWB. Replace the Controller PWB.
	50	Content	LSU connection trouble
		Detail	An LSU which does not conform to the machine is installed.
		Cause	PCU PWB trouble LSU trouble
		Check and remedy	Check LSU PWB. Check PCU PWB. Check connection of the connector and the harness between PCU and LSU.
F1	00	Content	Finisher communication trouble
		Detail	Communication cable test error after turning on the power or exiting from DIAG. Communication error with the finisher
		Cause	Improper connection or disconnection of connectors and harness between the machine and the finisher. Finisher control PWB trouble Control PWB (PCU) trouble Malfunction by noises
		Check and remedy	Canceled by turning OFF/ON the power. Check connectors and harness in the
			communication line. Replace the finisher control PWB or PCU PWB.
	80	Content	Finisher staple shift motor trouble
		Detail	Staple motor drive trouble
		Cause	Motor lock Motor rpm abnormality Overcurrent to the motor
			Finisher control PWB trouble
		Check and remedy	Use DIAG (SIM3-3) to check operations of the staple motor.

MAIN	SUB		
F1	80	Content	Finisher power abnormality
		Detail	The 24V power is not supplied to the finisher PWB.
		Cause	Improper connection or disconnection of connector and harness Finisher control PWB trouble Power unit trouble
		Check and remedy	Use DIAG (SIM3-2) to check the sensor.
•	87	Content	Finisher staple rotation motor trouble
		Detail	Front staple rotation motor trouble
		Cause	Motor lock Motor rpm abnormality Overcurrent to the motor Finisher control PWB trouble
		Check and remedy	Use DIAG (SIM3-3) to check the motor operation.
F1	00	Content	Mail box communication trouble
		Detail	Communication cable test error after turning on the power or exiting from DIAG. Communication error with the mail box.
		Cause	Improper connection or disconnection of connector and harness between the machine and the mail box. Mail box control PWB trouble Control PWB (PCU) trouble Malfunction by noises
		Check and remedy	Canceled by turning OFF/ON the power. Check harness and connector in the communication line. Replace the mail box PWB or PCU PWB.
:	02	Content	Mail box transport motor abnormality
		Detail	Transport motor trouble
		Cause	Motor lock Motor rpm abnormality Overcurrent to the motor Mail box control PWB trouble
		Check and remedy	Use DIAG (SIM3-21) to check the transport motor operation.
•	12	Content	Mail box gate trouble
		Detail	Gate operation abnormality
		Cause	Gate lock Mail box control PWB trouble
		Check and	Use DIAG (SIM3-21) to check the transport
	00	remedy Content	gate operation.
	80	Detail	Finisher power abnormality The 24V power is not supplied to the finisher PWB.
		Cause	Improper connection or disconnection of connector and harness Finisher control PWB trouble Power unit trouble
		Check and	Use DIAG (SIM3-20) to check the sensor
		remedy	operation.

MAIN	SUB		
F1	03	Content	Console finisher paddle motor trouble
		Detail	Paddle motor operation abnormality
		Cause	Motor lock
			Motor rpm abnormality
			Overcurrent to the motor
			Console finisher control PWB trouble
		Check and	Use DIAG (SIM3-3) to check the motor
		remedy	operation.
	06	Content	Console finisher slide motor trouble
		Detail	Slide motor operation abnormality
		Cause	Motor lock
			Motor rpm abnormality
			Overcurrent to the motor
		01 1 1	Console finisher control PWB trouble
		Check and	Use DIAG (SIM3-3) to check the motor
	10	remedy	operation.
	10	Content	Console finisher stapler motor trouble
		Detail	Stapler motor operation abnormality
		Cause	Motor lock Motor rpm abnormality
			Overcurrent to the motor
			Console finisher control PWB trouble
		Check and	Use DIAG (SIM3-3) to check the motor
		remedy	operation.
	11	Content	Console finisher bundle exit motor trouble
		Detail	Bundle exit motor operation abnormality
		Cause	Motor lock
			Motor rpm abnormality
			Overcurrent to the motor
			Console finisher control PWB trouble
		Check and	Use DIAG (SIM3-3) to check the motor
		remedy	operation.
	15	Content	Console finisher lift motor trouble
		Detail	Lift motor operation abnormality
		Cause	Motor lock
			Motor rpm abnormality Overcurrent to the motor
			Console finisher control PWB trouble
		Check and	
		remedy	operation.
	19	Content	Console finisher front alignment motor
			trouble
		Detail	Front alignment motor operation abnormality
		Cause	Motor lock
			Motor rpm abnormality
			Overcurrent to the motor
		01	Console finisher control PWB trouble
		Check and	Use DIAG (SIM3-3) to check the motor operation.
	20	remedy	
	20	Detail	Console finisher rear alignment motor trouble
			Rear alignment motor operation abnormality Motor lock
		Cause	Motor lock Motor rpm abnormality
			Overcurrent to the motor
			Console finisher control PWB trouble
		Check and	Use DIAG (SIM3-3) to check the motor
		remedy	operation.

MAIN	SUB		
F1	30	Content	Console finisher communication trouble
		Detail	Communication cable test error after turning
			on the power or exiting from DIAG. Communication error with the console
			finisher
		Cause	Improper connection or disconnection of
			connector and harness between the machine
			and the console finisher.
			Console finisher control PWB trouble
			Control PWB (PCU) trouble Malfunction by noises
		Check and	Canceled by turning OFF/ON the power.
		remedy	Check connectors and harness in the
			communication line.
			Replace the console finisher control PWB or
			PCU PWB.
	31	Content	Console finisher fold sensor trouble
		Detail	Sensor input value abnormality
		Cause	Sensor breakage
			harness breakage Console finisher control PWB trouble
		Check and	Use DIAG (SIM3-2) to check the sensor
		remedy	operation.
	32	Content	Communication trouble between the console
	<i>52</i>	Jonath	finisher and the punch unit.
		Detail	Communication err between the console
			finisher and the punch unit.
		Cause	Improper connection or disconnection of
			connector and harness between the console
			finisher and the punch unit. Console finisher control PWB trouble
			Control PWB (PCU) trouble
			Malfunction by noise
		Check and	Canceled by turning OFF/ON the power.
		remedy	Check connectors and harness in the
			communication line.
-		_	Replace the console finisher control PWB.
	33	Content	Console finisher punch side registration motor trouble
		Detail	Punch side registration motor operation abnormality
		Cause	Motor lock
			Motor rpm abnormality
			Overcurrent to the motor Console finisher control PWB trouble
		Check and	Use DIAG (SIM3-3) to check the motor
		remedy	operation.
	34	Content	Console finisher punch motor trouble
		Detail	Punch motor operation abnormality
		Cause	Motor lock
			Motor rpm abnormality
			Overcurrent to the motor
		Object	Console finisher control PWB trouble
		Check and remedy	Use DIAG (SIM3-3) to check the motor operation.
	35	Content	Console finisher punch side registration
	55	Joinell	sensor trouble
		Detail	Sensor input value abnormality
		Cause	Sensor breakage
			Harness disconnection
			Console finisher control PWB trouble
		Check and	Use DIAG (SIM3-2) to check the sensor
Ì		remedy	operation.

MAIN	SUB		
F1	36	Content	Console finisher punch timing sensor trouble
		Detail	Sensor input value abnormality
		Cause	Sensor breakage
			Harness disconnection Console finisher control PWB trouble
		Check and	Use DIAG (SIM3-2) to check the sensor
		remedy	operation.
	37	Content	Console finisher backup RAM trouble
		Detail	Backup RAM contents are disturbed.
		Cause	Console finisher control PWB trouble Malfunction by noise
		Check and remedy	Replace the console finisher control PWB.
	38	Content	Console finisher punch backup RAM trouble
		Detail	Punch unit backup RAM contents are disturbed.
		Cause	Punch control PWB trouble Malfunction by noise
		Check and	Replace the punch control PWB.
		remedy	, ,
•	81	Content	Console finisher transport motor abnormality
		Detail	Transport motor trouble
		Cause	Motor lock
			Motor rpm abnormality
			Overcurrent to the motor Console finisher control PWB trouble
		Check and	Use DIAG (SIM3-3) to check the motor
		remedy	operation.
F2	00	Content	Toner control sensor abnormality
		Detail	Toner control sensor output open
		Cause	Connector harness trouble
		0	Connector disconnection
		Check and remedy	Check connection of the toner control sensor. Check connection of connector and harness
		Tomody	to the main PWB.
			Check for disconnection of harness.
	02	Content	Toner supply abnormality
		Detail	Toner control sensor output value becomes
			under-toner too earlier.
		Cause	Connector harness trouble Toner control sensor trouble
		Check and	Check connection of the connector in the
		remedy	toner motor section.
			Check connection of connector and harness
			to the main PWB. Check for disconnection of harness.
			Toner control sensor output check DIAG (SIM25-1)
	04	Content	Improper cartridge (life cycle error, etc.)
		Detail	An improper process cartridge is inserted.
		Cause	IC chip trouble
			Improper cartridge
		Check and remedy	Insert a proper cartridge.
	05	Content	CRUM error
		Detail	Communication with IC chip cannot be made.
		Cause	IC chip trouble Improper cartridge
		Check and	Insert a proper cartridge.
		remedy	

F2 39 Content Process thermistor trouble Detail Process thermistor trouble Process thermistor open Cause Process thermistor trouble Process thermistor harness disconnection PCU PWB trouble Check and remedy of the process thermistor. Check PCU PWB. F3 12 Content Machine no. 1 tray lift-up trouble Detail PED does not turn ON in the specified time. LUD does not turn ON in the specified time. LUD does not turn on the specified time. Check and remedy Check connection of harness between the PCVU PWB, lift-up unit, and paper feed unit. Check and remedy Check Connection of harness between the PCVU PWB, lift-up unit, and paper feed unit. Check and remedy Check Connection of harness between the PCVU PWB, lift-up unit, and paper feed unit. Check the lift-up unit. Cause MCPED does not turn ON in the specified time. MCLUD does not turn ON in the specified time. MCLUD does not turn ON in the specified time. MCLUD does not turn ON in the specified time. Cause MCPED/MCLUD trouble No. 2 tray lift-up motor trouble Harness disconnection if the PCU PWB, the lift-up unit, and the paper feed unit. Check and remedy Check the lift-up unit. H12 00 H1.1 (RT H1) 01 O1	MAJAI	CLID		
Detail Process thermistor open Cause Process thermistor trouble Process thermistor harness disconnection PCU PWB trouble Check and Check connection of harness and connector of the process thermistor. Check PCU PWB. F3 12 Content Machine no. 1 tray lift-up trouble Detail PED does not turn ON in the specified time. Cause PED/LUD trouble No. 1 tray lift-up trouble Check connection of harness between the PCVU PWB, lift-up unit, and paper feed unit. Check and Check PED, LUD, and their harness and connectors. Check the lift-up unit. 22 Content Machine No. 2 tray lift-up trouble Detail MCPED does not turn ON in the specified time. Cause MCPED/MCLUD trouble No. 2 tray lift-up motor trouble Harness disconnection of the PCU PWB, the lift-up unit, and the paper feed unit. Check and remedy Check the lift-up unit not installed No. 2 tray lift-up motor trouble Harness disconnection of the PCU PWB, the lift-up unit, and the paper feed unit. Check and remedy Check the lift-up unit. Check the lift-up unit. H12 00	MAIN	SUB	Contact	Dro coos thormists a travella
Cause Process thermistor trouble Process thermistor harness disconnection PCU PWB trouble Check and Check connection of harness and connector of the process thermistor. Check PCU PWB. F3 12 Content Machine no. 1 tray lift-up trouble Detail PED does not turn ON in the specified time. LUD does not turn ON in the specified time. Cause PED/LUD trouble No. 1 tray lift-up trouble Check connection of harness between the PCVU PWB, lift-up unit, and paper feed unit. Check and Check PED, LUD, and their harness and connectors. Check the lift-up unit. Check and Check PED, LUD, and their harness and connectors. Check the lift-up unit. Cause MCPED does not turn ON in the specified time. MCLUD does not turn ON in the specified time. Cause MCPED/MCLUD trouble No. 2 tray lift-up motor trouble Harness disconnection of the PCU PWB, the lift-up unit, and the paper feed unit. Check and Check MCPED, PCLUD, and their harness and connectors. Check the lift-up unit. Check and Check MCPED, PCLUD, and their harness and connectors. Check the lift-up unit. Check and Check MCPED, PCLUD, and their harness and connectors. Check the lift-up unit. Thermistor open Fusing unit not installed Thermistor is open. (An input voltage of 2.92V or above is detected.) Fusing unit not installed Check and Check harnesses and connectors from the thermistor to the control PWB. Use DIAG (SIM14) to clear the self diag display. H3 00 Content Fusing section high temperature trouble Fusing section connector disconnection AC power trouble Fusing section high temperature trouble Control PWB trouble Fusing section connector disconnection AC power trouble Control PWB trouble Fusing section connector disconnection AC power trouble Control PWB trouble Fusing section connector disconnection AC power trouble Control PWB trouble Fusing section connector disconnection AC power trouble Check the thermistor and its harness. Check the thermistor and its h	F2	39		
Process thermistor harness disconnection PCU PWB trouble				'
F3 12 Content Machine no. 1 tray lift-up trouble Detail PED does not turn ON in the specified time. LUD does not turn ON in the specified time. Cause PED/LUD trouble No. 1 tray lift-up trouble Check connection of harness between the PCVU PWB, lift-up unit, and paper feed unit. Check and remedy connectors. Check the lift-up unit. 22 Content Machine No. 2 tray lift-up trouble Detail MCPED does not turn ON in the specified time. MCLUD does not turn ON in the specified time. MCPED/MCLUD trouble No. 2 tray lift-up brouble Harness disconnection of the PCU PWB, the lift-up unit, and the paper feed unit. Check and remedy Check MCPED, PCLUD, and their harness and connectors. Check the lift-up unit and the paper feed unit. Check and Check MCPED, PCLUD, and their harness and connectors. Check the lift-up unit. Thermistor open Fusing unit not installed Thermistor is open. (An input voltage of 2.92V or above is detected.) Fusing unit not installed Check and Pusing unit not installed Check and Check harnesses and connectors from the thermistor to the control PWB. Use DIAG (SIM14) to clear the self diag display. H3 00 Content Fusing section high temperature trouble Fusing section connector disconnection AC power trouble Control PWB trouble Fusing section connector disconnection AC power trouble Control PWB trouble Fusing section connector disconnection AC power trouble Check and the mist of the control PWB. Check the thermistor and its harness. Check the AC PWB and the lamp control circuit in the control PWB.			Cause	Process thermistor harness disconnection
Detail PED does not turn ON in the specified time. Cause PED/LUD trouble No. 1 tray lift-up trouble Check connection of harness between the PCVU PWB, lift-up unit, and paper feed unit. Check and Check PED, LUD, and their harness and connectors. Check the lift-up unit. Content Machine No. 2 tray lift-up trouble Detail MCPED does not turn ON in the specified time. Cause MCPED/MCLUD trouble No. 2 tray lift-up motor trouble Harness disconnection f the PCU PWB, the lift-up unit, and the paper feed unit. Check and remedy and connectors. Check the lift-up unit. Check de MCPED, PCLUD, and their harness and connectors. Check the lift-up unit. Check and Check MCPED, PCLUD, and their harness and connectors. Check the lift-up unit. Cause Thermistor open Fusing unit not installed Detail Thermistor is open. (An input voltage of 2.92V or above is detected.) Cause Thermistor trouble Control PWB trouble Fusing unit not installed Check and Check harnesses and connectors from the thermistor to the control PWB. Use DIAG (SIM14) to clear the self diag display. H3 00 Content Fusing section high temperature trouble Fusing section connector disconnection AC power trouble Control PWB trouble Fusing section connector disconnection AC power trouble Control PWB trouble Fusing section connector disconnection AC power trouble Check and Check and Check harnesses and connectors from the thermistor to the control PWB. Use DIAG (SIM5-2) to check the heater lamp Blinking operation. If the heater lamp blinks normally: Check the thermistor and its harness. Check the thermistor input circuit in the control PWB. If the heater lamp keep lighting: Check the AC PWB and the lamp control circuit in the control PWB.				of the process thermistor.
LUD does not turn ON in the specified time. Cause PED/LUD trouble No. 1 tray lift-up trouble Check connection of harness between the PCVU PWB, lift-up unit, and paper feed unit. Check and Check PED, LUD, and their harness and connectors. Check the lift-up unit. 22 Content Machine No. 2 tray lift-up trouble Detail MCPED does not turn ON in the specified time. Cause MCPED/MCLUD trouble No. 2 tray lift-up motor trouble Harness disconnection f the PCU PWB, the lift-up unit, and the paper feed unit. Check and Check MCPED, PCLUD, and their harness and connectors. Check the lift-up unit. Check MCPED, PCLUD, and their harness and connectors. Check the lift-up unit. Check MCPED, PCLUD, and their harness and connectors. Check the lift-up unit. Check MCPED, PCLUD, and their harness and connectors. Check the lift-up unit. Check MCPED, PCLUD, and their harness and connectors. Check the lift-up unit. Check MCPED, PCLUD, and their harness and connectors. Check the lift-up unit. Check and Check Marnesses and connector is detected.) Cause Thermistor trouble Control PWB trouble Fusing section connector disconnection AC power trouble Control PWB trouble Fusing section connector disconnection AC power trouble Control PWB trouble Fusing section connector disconnection AC power trouble Control PWB trouble Fusing section connector disconnection AC power trouble Check and Use DIAG (SIM5-2) to check the heater lamp Blinking operation. If the heater lamp blinks normally: Check the thermistor and its harness. Check the thermistor input circuit in the control PWB. If the heater lamp keep lighting: Check the AC PWB and the lamp control circuit in the control PWB.	F3	12	Content	Machine no. 1 tray lift-up trouble
No. 1 tray lift-up trouble Check connection of harness between the PCVU PWB, lift-up unit, and paper feed unit. Check and remedy connectors. Check the lift-up unit. 22 Content Machine No. 2 tray lift-up trouble Detail MCPED does not turn ON in the specified time. Cause MCPED/MCLUD trouble No. 2 tray lift-up motor trouble Harness disconnection f the PCU PWB, the lift-up unit, and the paper feed unit. Check and remedy and connectors. Check the lift-up unit. Check And remedy and connectors. Check the lift-up unit. H2 00			Detail	·
remedy connectors. Check the lift-up unit. Detail MCPED does not turn ON in the specified time.			Cause	No. 1 tray lift-up trouble Check connection of harness between the
Check the lift-up unit. Check Machine No. 2 tray lift-up trouble			Check and	Check PED, LUD, and their harness and
Content Machine No. 2 tray lift-up trouble			remedy	
Detail MCPED does not turn ON in the specified time. MCLUD does not turn ON in the specified time. Cause MCPED/MCLUD trouble No. 2 tray lift-up motor trouble Harness disconnection f the PCU PWB, the lift-up unit, and the paper feed unit. Check and remedy and connectors. Check the lift-up unit. H2 00			0	•
time. MCLUD does not turn ON in the specified time. Cause MCPED/MCLUD trouble No. 2 tray lift-up motor trouble Harness disconnection f the PCU PWB, the lift-up unit, and the paper feed unit. Check and check the lift-up unit. Detail Thermistor open Fusing unit not installed Check (An input voltage of 2.92V or above is detected.) Fusing unit not installed Cause Thermistor trouble Control PWB trouble Fusing section connector disconnection AC power trouble Fusing unit not installed Check and remedy Check harnesses and connectors from the thermistor to the control PWB. Use DIAG (SIM14) to clear the self diag display. H3 Oo Content Fusing section high temperature trouble 1HL1 (RT H1) Detail The fusing temperature exceeds 242°C. (An input voltage of 0.27V or above is detected.) Cause thermistor trouble Control PWB trouble Fusing section connector disconnection AC power trouble Cause Use DIAG (SIM5-2) to check the heater lamp Blinking operation. If the heater lamp blinks normally: Check the thermistor and its harness. Check the thermistor input circuit in the control PWB. If the heater lamp keep lighting: Check the AC PWB and the lamp control circuit in the control PWB.		22		
MCLUD does not turn ON in the specified time. Cause MCPED/MCLUD trouble No. 2 tray lift-up motor trouble Harness disconnection if the PCU PWB, the lift-up unit, and the paper feed unit. Check and remedy Check MCPED, PCLUD, and their harness and connectors. Check the lift-up unit. H1 (RT H1) Detail Thermistor open (An input voltage of 2.92V or above is detected.) Fusing unit not installed Cause Thermistor trouble Fusing unit not installed Check and remedy Check harnesses and connectors from the thermistor to the control PWB. Use DIAG (SIM14) to clear the self diag display. H3 00 Content Fusing section high temperature trouble The fusing temperature exceeds 242°C. (An input voltage of 0.27V or above is detected.) Cause Thermistor trouble Check and remedy The fusing temperature exceeds 242°C. (An input voltage of 0.27V or above is detected.) Cause Control PWB trouble Fusing section connector disconnection AC power trouble Cause Thermistor trouble Check thermistor trouble Check and remedy The fusing temperature exceeds 242°C. (An input voltage of 0.27V or above is detected.) Cause Use DIAG (SIM5-2) to check the heater lamp Blinking operation. If the heater lamp blinks normally: Check the thermistor and its harness. Check the thermistor input circuit in the control PWB. If the heater lamp keep lighting: Check the AC PWB and the lamp control circuit in the control PWB.			Detail	·
No. 2 tray lift-up motor trouble Harness disconnection f the PCU PWB, the lift-up unit, and the paper feed unit. Check and remedy O0				MCLUD does not turn ON in the specified
Harness disconnection f the PCU PWB, the lift-up unit, and the paper feed unit. Check and remedy Check MCPED, PCLUD, and their harness and connectors. Check the lift-up unit. H2 00 Check the lift-up unit. HL1 (RT H1) O1 HL2 (RT H2) Cause Check and remedy Check and remedy Thermistor is open. (An input voltage of 2.92V or above is detected.) Fusing unit not installed Cause Check and remedy Check and remedy Thermistor trouble Fusing section connector disconnection AC power trouble Fusing unit not installed Check harnesses and connectors from the thermistor to the control PWB. Use DIAG (SIM14) to clear the self diag display. H3 00 Content The fusing section high temperature trouble The fusing temperature exceeds 242°C. (An input voltage of 0.27V or above is detected.) Cause Thermistor trouble Control PWB trouble Fusing section connector disconnection AC power trouble Use DIAG (SIM5-2) to check the heater lamp Blinking operation. If the heater lamp blinks normally: Check the thermistor input circuit in the control PWB. If the heater lamp keep lighting: Check the AC PWB and the lamp control circuit in the control PWB.			Cause	
Iiff-up unit, and the paper feed unit.				
Check and remedy Check MCPED, PCLUD, and their harness and connectors. Check the lift-up unit. Content thermistor open Fusing unit not installed Detail Thermistor is open. (An input voltage of 2.92V or above is detected.) Fusing unit not installed Cause Thermistor trouble Control PWB trouble Fusing section connector disconnection AC power trouble Fusing unit not installed Check and remedy Check harnesses and connectors from the thermistor to the control PWB. Use DIAG (SIM14) to clear the self diag display. H3 Oo				·
Check the lift-up unit. H2 00 HL1 (RT H1) O1 HL2 (RT H2) O1 HL2 (RT H2) O2 HL2 (RT H2) O3 HL2 (RT H2) O4 HL2 (RT H2) O5 HL2 (RT H2) C5 HL2 (RT H2) O6 HL2 (RT H2) C6 HL2 (RT H2) O7 HL2 (RT H2) C6 HL2 (RT H2) O8 HL3 (RT H2) C6 HL1 (RT H1) O9 HL1 (RT H1) O1 HL2 (RT H1) O1 HL2 (RT H2) C6 HL2 (RT H2) C6 HL2 (RT H2) C6 C6 C7 C7 C7 C7 C6 C6 C6 C6 C6 C6 C6 C7			Check and	
H2 00 HL1 (RT H1) O1 HL2 (RT H2) O1 HL2 (RT H2) O1 HL2 (RT H2) O2 HL2 (RT H2) O3 HL2 (RT H2) O3 HL2 (RT H2) O4 HL2 (RT H2) O5 HL2 (RT H2) O6 HL2 (RT H2) O6 HL2 (RT H2) O7 HL2 (RT H2) O8 Check and remedy O8 HL3 O9 HL1 (RT H1) O1 HL2 (RT H1) O1 HL2 (RT H2) O2 Cause (Content Fusing section high temperature trouble fusing temperature exceeds 242°C. (An input voltage of 0.27V or above is detected.) Cause (Control PWB trouble fusing section connector disconnection AC power trouble Control PWB trouble Fusing section connector disconnection AC power trouble Check and remedy O1 Check and remedy O1 If the heater lamp blinks normally: Check the thermistor and its harness. Check the thermistor input circuit in the control PWB. If the heater lamp keep lighting: Check the AC PWB and the lamp control circuit in the control PWB.			remedy	
HL1 (RT H1) Detail Thermistor is open. (An input voltage of 2.92V or above is detected.) Fusing unit not installed Cause Thermistor trouble Control PWB trouble Fusing section connector disconnection AC power trouble Fusing unit not installed Check and remedy Check harnesses and connectors from the thermistor to the control PWB. Use DIAG (SIM14) to clear the self diag display. H3 00 1HL1 (RT H1) O1 HL2 (RT H2) Cause The fusing section high temperature trouble Detail The fusing temperature exceeds 242°C. (An input voltage of 0.27V or above is detected.) Cause Thermistor trouble Control PWB trouble Fusing section connector disconnection AC power trouble Control PWB trouble Fusing section connector disconnection AC power trouble Check and remedy Blinking operation. If the heater lamp blinks normally: Check the thermistor and its harness. Check the thermistor input circuit in the control PWB. If the heater lamp keep lighting: Check the AC PWB and the lamp control circuit in the control PWB.				•
H1) O1 HL2 (RT H2) Cause Thermistor trouble Control PWB trouble Fusing section connector disconnection AC power trouble Fusing unit not installed Check and remedy Check harnesses and connectors from the thermistor to the control PWB. Use DIAG (SIM14) to clear the self diag display. H3 O0 HL1 (RT H1) Detail The fusing temperature exceeds 242°C. (An input voltage of 0.27V or above is detected.) Cause Thermistor trouble Control PWB trouble Fusing section connector disconnection AC power trouble Control PWB trouble Fusing section connector disconnection AC power trouble Check and remedy Check the thermistor and its harness. Check the thermistor input circuit in the control PWB. If the heater lamp keep lighting: Check the AC PWB and the lamp control circuit in the control PWB.	H2	HL1 (RT H1) 01 HL2		Fusing unit not installed
HL2 (RT H2) Cause Thermistor trouble Control PWB trouble Fusing section connector disconnection AC power trouble Fusing unit not installed Check and remedy Thermistor to the control PWB. Use DIAG (SIM14) to clear the self diag display. H3 O0 1HL1 (RT H1) Cause Thermistor to the control PWB. Use DIAG (SIM14) to clear the self diag display. The fusing section high temperature trouble The fusing temperature exceeds 242°C. (An input voltage of 0.27V or above is detected.) Cause Thermistor trouble Control PWB trouble Fusing section connector disconnection AC power trouble Control PWB trouble Fusing section connector disconnection AC power trouble Check and remedy Check and If the heater lamp blinks normally: Check the thermistor and its harness. Check the thermistor input circuit in the control PWB. If the heater lamp keep lighting: Check the AC PWB and the lamp control circuit in the control PWB.			Detail	(An input voltage of 2.92V or above is
RT H2) Cause Control PWB trouble Fusing section connector disconnection AC power trouble Fusing unit not installed Check and remedy Check harnesses and connectors from the thermistor to the control PWB. Use DIAG (SIM14) to clear the self diag display. Content HL1 (RT H1) Cause Cause The fusing section high temperature trouble The fusing temperature exceeds 242°C. (An input voltage of 0.27V or above is detected.) Cause The fusing temperature exceeds 242°C. (An input voltage of 0.27V or above is detected.) Cause The fusing temperature exceeds 242°C. (An input voltage of 0.27V or above is detected.) Cause The fusing temperature exceeds 242°C. (An input voltage of 0.27V or above is detected.) Cause The fusing temperature exceeds 242°C. (An input voltage of 0.27V or above is detected.) Cause The fusing temperature exceeds 242°C. (An input voltage of 0.27V or above is detected.) Cause The fusing temperature exceeds 242°C. (An input voltage of 0.27V or above is detected.) Cause The fusing temperature exceeds 242°C. (An input voltage of 0.27V or above is detected.) Cause The fusing temperature exceeds 242°C. (An input voltage of 0.27V or above is detected.) Cause The fusing temperature exceeds 242°C. (An input voltage of 0.27V or above is detected.) Cause The fusing temperature exceeds 242°C. (An input voltage of 0.27V or above is detected.) Cause The fusing temperature exceeds 242°C. (An input voltage of 0.27V or above is detected.) Cause The fusing temperature exceeds 242°C. (An input voltage of 0.27V or above is detected.) Cause The fusing temperature exceeds 242°C. (An input voltage of 0.27V or above is detected.) Cause The fusing temperature exceeds 242°C. (An input voltage of 0.27V or above is detected.) Cause The fusing temperature exceeds 242°C. (An input voltage of 0.27V or above is detected.) Cause The fusing temperature exceeds 242°C. (An input voltage of 0.27V or above is detected.) Cause The fusing temperature exceeds 242°C. (An input voltage of 0.27V or above is d				Fusing unit not installed
Fusing section connector disconnection AC power trouble Fusing unit not installed Check and remedy Check harnesses and connectors from the thermistor to the control PWB. Use DIAG (SIM14) to clear the self diag display. H3 00 The fusing section high temperature trouble The fusing temperature exceeds 242°C. (An input voltage of 0.27V or above is detected.) Cause Check and remedy Check and remedy Check and remedy Check and remedy Check the thermistor and its harness. Check the thermistor input circuit in the control PWB. If the heater lamp keep lighting: Check the AC PWB and the lamp control circuit in the control PWB.			Cause	
AC power trouble Fusing unit not installed Check and remedy Check harnesses and connectors from the thermistor to the control PWB. Use DIAG (SIM14) to clear the self diag display. H3 00··· 1HL1 (RT (RT H1)) O1··· HL2 (RT H2) Cause (RT H2) Check and remedy Check and remedy AC power trouble Fusing section high temperature trouble The fusing temperature exceeds 242°C. (An input voltage of 0.27V or above is detected.) Cause (An input voltage of 0.27V or above is detected.) Check and remedy (Check and remedy) Check and remedy (SiM5-2) to check the heater lamp blinking operation. If the heater lamp blinks normally: Check the thermistor and its harness. Check the thermistor input circuit in the control PWB. If the heater lamp keep lighting: Check the AC PWB and the lamp control circuit in the control PWB.		`		
Fusing unit not installed Check and remedy Check harnesses and connectors from the thermistor to the control PWB. Use DIAG (SIM14) to clear the self diag display. H3 00··· Content The fusing section high temperature trouble Detail The fusing temperature exceeds 242°C. (An input voltage of 0.27V or above is detected.) Cause Thermistor trouble Control PWB trouble Fusing section connector disconnection AC power trouble Check and remedy Check and remedy Check the heater lamp blinks normally: Check the thermistor and its harness. Check the thermistor input circuit in the control PWB. If the heater lamp keep lighting: Check the AC PWB and the lamp control circuit in the control PWB.		,		
remedy thermistor to the control PWB. Use DIAG (SIM14) to clear the self diag display. H3 00 Content Fusing section high temperature trouble Detail The fusing temperature exceeds 242°C. (An input voltage of 0.27V or above is detected.) Cause thermistor trouble Control PWB trouble Fusing section connector disconnection AC power trouble Check and remedy Use DIAG (SIM5-2) to check the heater lamp Blinking operation. If the heater lamp blinks normally: Check the thermistor and its harness. Check the thermistor input circuit in the control PWB. If the heater lamp keep lighting: Check the AC PWB and the lamp control circuit in the control PWB.				· ·
Use DIAG (SIM14) to clear the self diag display. H3 00··· Content Fusing section high temperature trouble Detail The fusing temperature exceeds 242°C. (An input voltage of 0.27V or above is detected.) Cause thermistor trouble Control PWB trouble Fusing section connector disconnection AC power trouble Check and remedy Use DIAG (SIM5-2) to check the heater lamp Blinking operation. If the heater lamp blinks normally: Check the thermistor and its harness. Check the thermistor input circuit in the control PWB. If the heater lamp keep lighting: Check the AC PWB and the lamp control circuit in the control PWB.				
display. H3 00 Content Fusing section high temperature trouble Detail The fusing temperature exceeds 242°C. (An input voltage of 0.27V or above is detected.) Cause thermistor trouble Control PWB trouble Fusing section connector disconnection AC power trouble Check and remedy Use DIAG (SIM5-2) to check the heater lamp Blinking operation. If the heater lamp blinks normally: Check the thermistor and its harness. Check the thermistor input circuit in the control PWB. If the heater lamp keep lighting: Check the AC PWB and the lamp control circuit in the control PWB.			remedy	
H3 00 Content Fusing section high temperature trouble				` ,
1HL1 (RT H1) Otali The fusing temperature exceeds 242°C. (An input voltage of 0.27V or above is detected.) O1 HL2 (RT H2) Cause thermistor trouble Control PWB trouble Fusing section connector disconnection AC power trouble Check and remedy Use DIAG (SIM5-2) to check the heater lamp Blinking operation. If the heater lamp blinks normally: Check the thermistor and its harness. Check the thermistor input circuit in the control PWB. If the heater lamp keep lighting: Check the AC PWB and the lamp control circuit in the control PWB.	НЗ	00	Content	
H1) O1 HL2 (RT H2) Check and remedy Check the heater lamp blinks normally: Check the thermistor and its harness. Check the thermistor input circuit in the control PWB. If the heater lamp keep lighting: Check the AC PWB and the lamp control circuit in the control PWB.			Detail	The fusing temperature exceeds 242°C.
Cause thermistor trouble Control PWB trouble Fusing section connector disconnection AC power trouble Check and remedy Use DIAG (SIM5-2) to check the heater lamp Blinking operation. If the heater lamp blinks normally: Check the thermistor and its harness. Check the thermistor input circuit in the control PWB. If the heater lamp keep lighting: Check the AC PWB and the lamp control circuit in the control PWB.		`		
O1 HL2 (RT H2) Check and remedy Check the heater lamp blinks normally: Check the thermistor and its harness. Check the thermistor input circuit in the control PWB. If the heater lamp keep lighting: Check the AC PWB and the lamp control circuit in the control PWB.		,	Causa	,
(RT H2) Check and remedy Check the heater lamp blinks normally: Check the thermistor and its harness. Check the thermistor input circuit in the control PWB. If the heater lamp keep lighting: Check the AC PWB and the lamp control circuit in the control PWB.			Jause	
Check and remedy Blinking operation. If the heater lamp blinks normally: Check the thermistor and its harness. Check the thermistor input circuit in the control PWB. If the heater lamp keep lighting: Check the AC PWB and the lamp control circuit in the control PWB.				
remedy Blinking operation. If the heater lamp blinks normally: Check the thermistor and its harness. Check the thermistor input circuit in the control PWB. If the heater lamp keep lighting: Check the AC PWB and the lamp control circuit in the control PWB.		H2)	Check and	<u> </u>
Check the thermistor and its harness. Check the thermistor input circuit in the control PWB. If the heater lamp keep lighting: Check the AC PWB and the lamp control circuit in the control PWB.				
Check the thermistor input circuit in the control PWB. If the heater lamp keep lighting: Check the AC PWB and the lamp control circuit in the control PWB.				If the heater lamp blinks normally:
control PWB. If the heater lamp keep lighting: Check the AC PWB and the lamp control circuit in the control PWB.				
Check the AC PWB and the lamp control circuit in the control PWB.				
circuit in the control PWB.				

MAIN	SUB		
H4	00…	Content	Fusing section low temperature trouble
	1HL1 (RT H1) 01 HL2 (RT	Detail	The set temperature is not reached within the specified time (normally 3 min) when warming up or resetting from pre-heating. Under the ready state. (An input voltage of 1.21V or below is detected 5 times continuously.)
	H2)	Cause	thermistor trouble Heater lamp trouble Control PWB trouble Thermostat trouble AC power trouble Interlock switch trouble
		Check and remedy	Use DIAG (SIM5-2) to check the heater lamp Blinking operation. If the heater lamp blinks normally: Check the thermistor and its harness. Check the thermistor input circuit in the control PWB. If the heater lamp does not light: Check for heater lamp disconnection and thermostat disconnection. Check the interlock switch. Check the AC PWB and the lamp control circuit in the control PWB. Use DIAG (SIM14) to cancel the trouble.
H5	01	Content	5-time continuous POD1 not-reaching jam detection
		Detail	5-time continuous POD1 not-reaching jam detection
		Cause	A fusing section jam is not properly removed. (Jam paper remains.) POD1 sensor trouble, or harness disconnection Improper installation of fusing unit
		Check and remedy	Check jam paper in the fusing section. (winding, etc.) Check POD1 sensor harness, and check installation the fusing unit. Use DIAG (SIM14) to cancel the trouble.
L4	01	Content Detail	Main motor lock detection The motor lock signal is detected for 1.5sec during rotation of the main motor.
		Cause	main motor trouble Check connection of harness between the PCU PWB and the main motor. Control circuit trouble
		Check and remedy	Use DIAG (SIM25-1) to check the main motor operation. Check harness and connector between the PCU PWB and the main motor.
	02	Content Detail	Drum motor lock detection The motor lock signal is detected for 1.5sec during rotation of the drum motor.
		Cause	Drum motor trouble Improper connection of harness between the PCU PWB and the drum motor. Control circuit trouble
		Check and remedy	Use DIAG (SIM25-1) to check the drum motor operation. Check harness and connector between the PCU PWB and the drum motor.

MAIN	SUB		
L6	10	Content	Polygon motor lock detection
		Detail	It is judged that the polygon motor lock signal is not outputted. Lock signal is checked in the interval of 10sec after starting the polygon motor, and it is judged that the polygon motor does not rotate normally.
		Cause	The LSU connector or harness in the LSU is disconnected or broken. Polygon motor trouble
		Check and remedy	Use DIAG (SIM61-1) to check the polygon motor operation. Check connector and harness connection. Replace LSU.
L8	01	Content	No fullwave signal
		Detail	Full wave signal is not detected.
		Cause	The PCU PWB connector or the power unit harness is disconnected or broken. PCU PWB trouble Power unit trouble
		Check and remedy	Check connection of the harness and connector. Replace PCU PWB. Replace the power unit.
	02	Content Detail	Full wave signal width abnormality It is judged as frequency abnormality of full wave signal. (When the detection cycle is judged as 69Hz or above or 42.5Hz or below)
		Cause	The connector or harness of the PCU PWB and the power PWB is disconnected. PCU PWB trouble Power unit trouble
		Check and remedy	Check connection of the harness and connector. Replace the PCU PWB. Replace the power unit.
U6	00	Content Detail	Desk/LCC communication trouble Desk/LCC communication error Communication cable test error after turning on the power or exiting DIAG.
		Cause	Improper connection or disconnection of connector and harness Desk control PWB trouble Control PWB (PCU) trouble Malfunction by noise
		Check and remedy	Canceled by turning OFF/ON the power. Check connection of the harness and connector in the communication line.
	01	Content	Desk/LCC No. 1 tray lift-up trouble
		Detail	Desk/LCC No. 1 tray lift-up trouble
		Cause	Sensor trouble Desk control PWB trouble Gear breakage Lift-up motor trouble
		Check and remedy	Use DIAG (SIM4-2) to check the lift-up sensor detection. Use DIAG (SIM4-3) to check the lift-up motor operation.

U6	SUB	0	Deal No. 0 (co. // 004) (f
	02	Content	Desk No. 2 tray/LCC1 lift-up trouble
		Detail	Desk No. 2 tray/LCC lift-up trouble
		Cause	Sensor trouble Desk control PWB trouble
			Gear breakage
			Lift-up motor trouble
		Check and	Use DIAG (SIM4-2) to check the lift-up
		remedy	sensor detection.
			Use DIAG (SIM4-3) to check the lift-up motor
			operation.
	03	Content	Desk No. 3 tray/LCC2 lift-up trouble
		Detail	Desk no. 3 tray lift-up trouble
		Cause	Sensor trouble
			Desk control PWB trouble Gear breakage
			Lift-up motor trouble
		Check and	Use DIAG (SIM4-2) to check the lift-up
		remedy	sensor detection.
			Use DIAG (SIM4-3) to check the lift-up motor
			operation.
	10	Content	Desk/LCC transport motor trouble
		Detail	Desk/LCC transport motor operation trouble
		Cause	Motor lock
			Motor rpm abnormality Overcurrent to the motor
			Desk control PWB trouble
		Check and	Use DIAG (SIM4-3) to check the transport
		remedy	motor operation.
EE	EL	Content	Auto developer adjustment trouble
			(Over-toner)
		Detail	The sample data is of 68 or below when auto
			developer adjustment is performed.
		Cause	Toner concentration sensor trouble
			Charging voltage, developing voltage
			abnormality Insufficient toner concentration
			Developing unit trouble
			PCU PWB trouble
		Check and	Use DIAG (SIM25-2) to perform auto
		remedy	developer adjustment.
	EU	Content	Auto developer adjustment trouble
			(Under-toner)
		Detail	The sample data is of 168 or above when auto developer adjustment is performed.
1		(,OHICO	Incufficient tener concentration
		Cause	Insufficient toner concentration Charging voltage, developing voltage
		Cause	Insufficient toner concentration Charging voltage, developing voltage abnormality
		Cause	Charging voltage, developing voltage
		Cause	Charging voltage, developing voltage abnormality Insufficient toner concentration Developing unit trouble
			Charging voltage, developing voltage abnormality Insufficient toner concentration Developing unit trouble PCU PWB trouble
		Check and	Charging voltage, developing voltage abnormality Insufficient toner concentration Developing unit trouble PCU PWB trouble Use DIAG (SIM25-2) to perform auto
EO	02	Check and remedy	Charging voltage, developing voltage abnormality Insufficient toner concentration Developing unit trouble PCU PWB trouble Use DIAG (SIM25-2) to perform auto developer adjustment.
F9	02	Check and remedy	Charging voltage, developing voltage abnormality Insufficient toner concentration Developing unit trouble PCU PWB trouble Use DIAG (SIM25-2) to perform auto developer adjustment. PRT Centro port check error
F9	02	Check and remedy Content Detail	Charging voltage, developing voltage abnormality Insufficient toner concentration Developing unit trouble PCU PWB trouble Use DIAG (SIM25-2) to perform auto developer adjustment. PRT Centro port check error Controller Centro port trouble
F9	02	Check and remedy	Charging voltage, developing voltage abnormality Insufficient toner concentration Developing unit trouble PCU PWB trouble Use DIAG (SIM25-2) to perform auto developer adjustment. PRT Centro port check error Controller Centro port trouble Centro port trouble
F9	02	Check and remedy Content Detail Cause	Charging voltage, developing voltage abnormality Insufficient toner concentration Developing unit trouble PCU PWB trouble Use DIAG (SIM25-2) to perform auto developer adjustment. PRT Centro port check error Controller Centro port trouble Centro port trouble Controller PWB trouble
F9	02	Check and remedy Content Detail	Charging voltage, developing voltage abnormality Insufficient toner concentration Developing unit trouble PCU PWB trouble Use DIAG (SIM25-2) to perform auto developer adjustment. PRT Centro port check error Controller Centro port trouble Centro port trouble
F9	02	Check and remedy Content Detail Cause Check and	Charging voltage, developing voltage abnormality Insufficient toner concentration Developing unit trouble PCU PWB trouble Use DIAG (SIM25-2) to perform auto developer adjustment. PRT Centro port check error Controller Centro port trouble Centro port trouble Controller PWB trouble
F9		Check and remedy Content Detail Cause Check and remedy	Charging voltage, developing voltage abnormality Insufficient toner concentration Developing unit trouble PCU PWB trouble Use DIAG (SIM25-2) to perform auto developer adjustment. PRT Centro port check error Controller Centro port trouble Centro port trouble Controller PWB trouble Replace the Controller PWB.
F9		Check and remedy Content Detail Cause Check and remedy Content	Charging voltage, developing voltage abnormality Insufficient toner concentration Developing unit trouble PCU PWB trouble Use DIAG (SIM25-2) to perform auto developer adjustment. PRT Centro port check error Controller Centro port trouble Centro port trouble Controller PWB trouble Replace the Controller PWB.
F9		Check and remedy Content Detail Cause Check and remedy Content Detail	Charging voltage, developing voltage abnormality Insufficient toner concentration Developing unit trouble PCU PWB trouble Use DIAG (SIM25-2) to perform auto developer adjustment. PRT Centro port check error Controller Centro port trouble Centro port trouble Controller PWB trouble Replace the Controller PWB. NIC port check error
F9		Check and remedy Content Detail Cause Check and remedy Content Detail	Charging voltage, developing voltage abnormality Insufficient toner concentration Developing unit trouble PCU PWB trouble Use DIAG (SIM25-2) to perform auto developer adjustment. PRT Centro port check error Controller Centro port trouble Centro port trouble Controller PWB trouble Replace the Controller PWB. NIC port check error NIC port trouble
F9		Check and remedy Content Detail Cause Check and remedy Content Detail	Charging voltage, developing voltage abnormality Insufficient toner concentration Developing unit trouble PCU PWB trouble Use DIAG (SIM25-2) to perform auto developer adjustment. PRT Centro port check error Controller Centro port trouble Centro port trouble Controller PWB trouble Replace the Controller PWB. NIC port check error NIC port trouble NIC PWB trouble

U1	MAIN	SUB		
Cause Battery life Battery circuit abnormality Check and remedy or above. Check that the battery circuit. EEPROM read/write error (Controller) Detail EEPROM write error Cause EEPROM trouble EEPROM access circuit trouble Check and remedy Save the counter/adjustment values with the DIAG simulation. Use DIAG (SIM16) to cancel U2 trouble. Replace the Controller PWB. 11 Content Counter data area check sum error Cause EEPROM trouble EEPROM trouble Replace the Controller PWB. 11 Content Counter data area check sum error Cause EEPROM trouble Control circuit trouble by noise Controller PWB EEPROM access circuit trouble Check and Check that EEPROM is properly inserted. Save the counter/adjustment values with the DIAG simulation. Use DIAG (SIM16) to cancel U2 trouble. Replace the Controller PWB. 12 Content Adjustment value check sum error Cause EEPROM trouble Control circuit trouble by noise Controller PWB EEPROM access circuit trouble Replace the Controller PWB. 12 Content Adjustment value check sum error Cause EEPROM trouble Control circuit trouble by noise Controller PWB EEPROM access circuit trouble Control circuit trouble by noise Controller PWB EEPROM access circuit trouble Check and Check that EEPROM is properly inserted. Save the counter/adjustment values with the DIAG simulation. Use DIAG (SIM16) to cancel U2 trouble. Replace the Controller PWB. 90 Content EEPROM read/write error (Controller) Detail PCU EEPROM write error Cause EEPROM trouble EEPROM trouble EEPROM to access circuit trouble Check and Check that EEPROM is properly inserted. Save the counter/adjustment values with the DIAG simulation. Use DIAG (SIM16) to cancel U2 trouble. Replace the Controller PWB. 91 Content Memory check sum error (PCU) Detail PCU memory check sum	U1	01	Content	Battery abnormality
Check and remedy			Detail	Backup SRAM battery voltage fall
Check and remedy or above. Check the battery voltage is about 2.5V or above. Check the battery circuit. U2 00 Content EEPROM read/write error (Controller) Detail EEPROM write error Cause EEPROM is not initialized. Controller PWB EEPROM access circuit trouble Check and remedy Save the counter/adjustment values with the DIAG simulation. Use DIAG (SIM16) to cancel U2 trouble. Replace the Controller PWB. 11 Content Counter check sum error (Controller) Detail Counter data area check sum error Cause EEPROM trouble Control crouit trouble by noise Controller PWB EEPROM access circuit trouble Check and remedy Save the counter/adjustment values with the DIAG simulation. Use DIAG (SIM16) to cancel U2 trouble. Replace the Controller PWB. 12 Content Adjustment value check sum error (Controller) Detail Adjustment value check sum error (Controller) Detail Adjustment value check sum error (Controller PWB EEPROM access circuit trouble Control circuit trouble by noise Controller PWB EEPROM access circuit trouble Control circuit trouble by noise Controller PWB EEPROM access circuit trouble Control circuit trouble by noise Controller PWB EEPROM access circuit trouble Check and Check that EEPROM is properly inserted. Save the counter/adjustment values with the DIAG simulation. Use DIAG (SIM16) to cancel U2 trouble. Replace the Controller PWB. 90 Content EEPROM read/write error Cause EEPROM trouble EEPROM so not initialized. PCU PWB EEPROM scess circuit trouble Check and Check that EEPROM is properly inserted. Save the counter/adjustment values with the DIAG simulation. Use DIAG (SIM16) to cancel U2 trouble. Replace the Controller PWB. 91 Content Memory check sum error (PCU) Detail PCU memory check sum error (PCU)			Cause	Battery life
remedy check the battery circuit. Detail EEPROM read/write error (Controller) Detail EEPROM trouble EEPROM access circuit trouble Check and remedy Controller PWB EEPROM is properly inserted. Save the counter/adjustment values with the DIAG simulation. Use DIAG (SIM16) to cancel U2 trouble. Replace the Controller PWB. 11 Content Counter data area check sum error Cause EEPROM trouble Controller PWB. Check and Check that EEPROM is properly inserted. Save the counter/adjustment values with the DIAG simulation. Use DIAG (SIM16) to cancel U2 trouble. Replace the Controller PWB. Control circuit trouble by noise Controller PWB EEPROM access circuit trouble Check and Check that EEPROM is properly inserted. Save the counter/adjustment values with the DIAG simulation. Use DIAG (SIM16) to cancel U2 trouble. Replace the Controller PWB. 12 Content Adjustment value check sum error (Controller) Detail Adjustment value check sum error Cause EEPROM trouble Control circuit trouble by noise Controller PWB EEPROM access circuit trouble Check and Check that EEPROM is properly inserted. Save the counter/adjustment values with the DIAG simulation. Use DIAG (SIM16) to cancel U2 trouble. Replace the Controller PWB. 90 Content EEPROM read/write error (Controller) Detail PCU EEPROM write error Cause EEPROM is not initialized. PCU PWB EEPROM is properly inserted. Save the counter/adjustment values with the DIAG simulation. Use DIAG (SIM16) to cancel U2 trouble. Replace the Controller PWB. 91 Content Memory check sum error (PCU) Detail PCU memory check sum error (PCU) Deta				Battery circuit abnormality
Content EEPROM read/write error (Controller)				, ,
U2 00 Content EEPROM read/write error (Controller) Detail EEPROM write error Cause EEPROM is not initialized. Controller PWB EEPROM access circuit trouble Check and Check that EEPROM is properly inserted. Save the counter/adjustment values with the DIAG simulation. Use DIAG (SIM16) to cancel U2 trouble. Replace the Controller PWB. 11 Content Counter check sum error (Controller) Detail Counter data area check sum error Cause EEPROM trouble Control circuit trouble by noise Controller PWB EEPROM access circuit trouble Check and Check that EEPROM is properly inserted. Save the counter/adjustment values with the DIAG simulation. Use DIAG (SIM16) to cancel U2 trouble. Replace the Controller PWB. 12 Content Adjustment value check sum error (Controller) Detail Adjustment data area check sum error Cause EEPROM trouble Control circuit trouble by noise Control erpwB EEPROM access circuit trouble Check and check that EEPROM is properly inserted. Save the counter/adjustment values with the DIAG simulation. Use DIAG (SIM16) to cancel U2 trouble. Replace the Controller PWB. 90 Content EEPROM trouble EEPROM trouble EEPROM access circuit trouble Check and check that EEPROM is properly inserted. Save the counter/adjustment values with the DIAG simulation. Use DIAG (SIM16) to cancel U2 trouble. Replace the Controller PWB. 91 Content Memory check sum error (PCU) Detail PCU memory check sum error Cause EEPROM trouble EEPROM trouble EEPROM trouble EEPROM trouble EEPROM is not initialized. PCU PWB EEPROM access circuit trouble Uninitialized E2PROM installed. Check and check that EEPROM is properly inserted. Save the counter/adjustment values with the DIAG simulation. Use DIAG (SIM16) to cancel U2 trouble.			remedy	
Detail EEPROM write error Cause EEPROM trouble EEPROM is not initialized. Controller PWB EEPROM access circuit trouble Check and Check that EEPROM is properly inserted. Save the counter/adjustment values with the DIAG simulation. Use DIAG (SIM16) to cancel U2 trouble. Replace the Controller PWB. 11 Content Counter check sum error (Controller) Detail Counter data area check sum error Cause EEPROM trouble Control circuit trouble by noise Controller PWB EEPROM access circuit trouble Check and Check that EEPROM is properly inserted. Save the counter/adjustment values with the DIAG simulation. Use DIAG (SIM16) to cancel U2 trouble. Replace the Controller PWB. 12 Content Adjustment data area check sum error (Controller) Detail Adjustment data area check sum error (Controller) Detail Adjustment data area check sum error Cause EEPROM trouble Control circuit trouble by noise Controller PWB EEPROM access circuit trouble Check and remedy Save the counter/adjustment values with the DIAG simulation. Use DIAG (SIM16) to cancel U2 trouble. Replace the Controller PWB. 90 Content EEPROM read/write error (Controller) Detail PCU EEPROM write error (Controller) Detail PCU memory check sum error (PCU) Detail PCU pWB EEPROM is properly inserted. Save the counter/adjustment values with the DIAG simulation. Use DIAG (SIM16) to cancel U2 trouble. EEPROM is not initialized. PCU PWB EEPROM is properly inserted. Save the counter/adjustment values with the DIAG simulation. Use DIAG (SIM16) to cancel U2 tro	112	00	Content	
Cause EEPROM is not initialized. Controller PWB EEPROM access circuit trouble Check and remedy Check that EEPROM is properly inserted. Save the counter/adjustment values with the DIAG simulation. Use DIAG (SIM16) to cancel U2 trouble. Replace the Controller PWB. 11 Content Counter check sum error (Controller) Detail Control circuit trouble by noise Controller PWB EEPROM access circuit trouble Check and Check that EEPROM is properly inserted. Save the counter/adjustment values with the DIAG simulation. Use DIAG (SIM16) to cancel U2 trouble. Replace the Controller PWB. 12 Content Adjustment value check sum error (Controller) Detail Adjustment value check sum error (Controller) Detail Adjustment data area check sum error Cause EEPROM trouble Control circuit trouble by noise Controller PWB EEPROM access circuit trouble Check and Check that EEPROM is properly inserted. Save the counter/adjustment values with the DIAG simulation. Use DIAG (SIM16) to cancel U2 trouble. Replace the Controller PWB. 90 Content EEPROM read/write error (Controller) Detail PCU EEPROM write error Cause EEPROM is not initialized. PCU PWB EEPROM access circuit trouble Check and Check that EEPROM is properly inserted. Save the counter/adjustment values with the DIAG simulation. Use DIAG (SIM16) to cancel U2 trouble. Replace the Controller PWB. 91 Content Memory check sum error (PCU) Detail PCU expys EEPROM installed. Check and check that EEPROM is properly inserted. Save the counter/adjustment values with the DIAG simulation. Use DIAG (SIM16) to cancel U2 trouble.	02	00		` ,
EEPROM is not initialized. Controller PWB EEPROM access circuit trouble Check and Check that EEPROM is properly inserted. Save the counter/adjustment values with the DIAG simulation. Use DIAG (SIM16) to cancel U2 trouble. Replace the Controller PWB. 11 Content Counter check sum error (Controller) Detail Counter data area check sum error Cause EEPROM trouble Control circuit trouble by noise Controller PWB EEPROM access circuit trouble Check and Check that EEPROM is properly inserted. Save the counter/adjustment values with the DIAG simulation. Use DIAG (SIM16) to cancel U2 trouble. Replace the Controller PWB. 12 Content Adjustment value check sum error Cause EEPROM trouble Control circuit trouble by noise Controller PWB EEPROM access circuit trouble Control circuit trouble by noise Controller PWB EEPROM access circuit trouble Control circuit trouble by noise Controller PWB EEPROM access circuit trouble Control circuit trouble by noise Controller PWB EEPROM access circuit trouble Check and Check that EEPROM is properly inserted. Save the counter/adjustment values with the DIAG simulation. Use DIAG (SIM16) to cancel U2 trouble. Replace the Controller PWB. 90 Content EEPROM read/write error (Controller) Detail PCU EEPROM write error Cause EEPROM is not initialized. PCU PWB EEPROM access circuit trouble Check and Check that EEPROM is properly inserted. Save the counter/adjustment values with the DIAG simulation. Use DIAG (SIM16) to cancel U2 trouble. Replace the Controller PWB. 91 Content Memory check sum error (PCU) Detail PCU memory check sum error Cause EEPROM is not initialized. PCU PWB EEPROM is properly inserted. Save the counter/adjustment values with the DIAG simulation. Use DIAG (SIM16) to cancel U2 trouble. Replace the Controller PWB. 91 Content Memory check sum error (PCU) Detail PCU memory check sum error (PCU) Detail PCU pWB EEPROM is properly inserted. Save the counter/adjustment values with the DIAG simulation.				
trouble Check and Check that EEPROM is properly inserted. Save the counter/adjustment values with the DIAG simulation. Use DIAG (SIM16) to cancel U2 trouble. Replace the Controller PWB. 11 Content Counter check sum error (Controller) Detail Counter data area check sum error Cause EEPROM trouble Control circuit trouble by noise Controller PWB EEPROM access circuit trouble Check and Check that EEPROM is properly inserted. Save the counter/adjustment values with the DIAG simulation. Use DIAG (SIM16) to cancel U2 trouble. Replace the Controller PWB. 12 Content Adjustment value check sum error (Controller) Detail Adjustment data area check sum error Cause EEPROM trouble Control circuit trouble by noise Controller PWB EEPROM access circuit trouble Check and Check that EEPROM is properly inserted. Save the counter/adjustment values with the DIAG simulation. Use DIAG (SIM16) to cancel U2 trouble. Replace the Controller PWB. 90 Content EEPROM read/write error (Controller) Detail PCU EEPROM write error (Controller) Detail PCU EEPROM is not initialized. PCU PWB EEPROM is properly inserted. Save the counter/adjustment values with the DIAG simulation. Use DIAG (SIM16) to cancel U2 trouble. Replace the Controller PWB. 91 Content Memory check sum error (PCU) Detail PCU memory check sum error (PCU)				
Check and remedy Check that EEPROM is properly inserted. Save the counter/adjustment values with the DIAG simulation. Use DIAG (SIM16) to cancel U2 trouble. Replace the Controller PWB. 11 Content Counter data area check sum error Cause EEPROM trouble Control circuit trouble by noise Control circuit trouble by noise Controller PWB EEPROM access circuit trouble Check and remedy Check that EEPROM is properly inserted. Save the counter/adjustment values with the DIAG simulation. Use DIAG (SIM16) to cancel U2 trouble. Replace the Controller PWB. 12 Content Adjustment data area check sum error (Controller) Detail Adjustment data area check sum error (Controller) Detail Adjustment data area check sum error (Controller PWB EEPROM access circuit trouble Control circuit trouble by noise Controller PWB EEPROM access circuit trouble Check and remedy Save the counter/adjustment values with the DIAG simulation. Use DIAG (SIM16) to cancel U2 trouble. Replace the Controller PWB. 90 Content EEPROM read/write error (Controller) Detail PCU EEPROM write error (Controller) Detail PCU EEPROM write error (Controller) Cause EEPROM trouble EEPROM is properly inserted. Save the counter/adjustment values with the DIAG simulation. Use DIAG (SIM16) to cancel U2 trouble. Replace the Controller PWB. 91 Content Memory check sum error (PCU) Detail PCU memory check sum error (PCU)				
remedy Save the counter/adjustment values with the DIAG simulation. Use DIAG (SIM16) to cancel U2 trouble. Replace the Controller PWB. 11 Content Counter check sum error (Controller) Detail Counter data area check sum error Cause EEPROM trouble Controller PWB EEPROM access circuit trouble Check and remedy Save the counter/adjustment values with the DIAG simulation. Use DIAG (SIM16) to cancel U2 trouble. Replace the Controller PWB. 12 Content Adjustment value check sum error (Controller) Detail Adjustment data area check sum error (Controller PWB. Cause EEPROM trouble Control circuit trouble by noise Controller PWB EEPROM access circuit trouble Control circuit trouble by noise Controller PWB EEPROM access circuit trouble Check and remedy Save the counter/adjustment values with the DIAG simulation. Use DIAG (SIM16) to cancel U2 trouble. Replace the Controller PWB. 90 Content EEPROM read/write error (Controller) Detail PCU EEPROM write error (Controller) Detail PCU EEPROM write error (Controller) Detail PCU EPROM is properly inserted. Save the counter/adjustment values with the DIAG simulation. Use DIAG (SIM16) to cancel U2 trouble. Replace the Controller PWB. 91 Content Memory check sum error (PCU) Detail PCU pWB EEPROM is properly inserted. EEPROM trouble EEPROM trouble EEPROM trouble EEPROM touble EEPROM so not initialized. PCU PWB EEPROM access circuit trouble Uninitialized E2PROM is properly inserted. Save the counter/adjustment values with the DIAG simulation. Use DIAG (SIM16) to cancel U2 trouble.			01 1 1	
DIAG simulation. Use DIAG (SIM16) to cancel U2 trouble. Replace the Controller PWB. 11 Content Counter check sum error (Controller) Detail Counter data area check sum error Cause EEPROM trouble Controller PWB EEPROM access circuit trouble Check and remedy Save the counter/adjustment values with the DIAG simulation. Use DIAG (SIM16) to cancel U2 trouble. Replace the Controller PWB. 12 Content Adjustment value check sum error (Controller) Detail Adjustment value check sum error (Controller PWB EEPROM access circuit trouble Control circuit trouble by noise Controller PWB EEPROM access circuit trouble Control circuit trouble by noise Controller PWB EEPROM access circuit trouble Control controller PWB EEPROM access circuit trouble Check and Check that EEPROM is properly inserted. Save the counter/adjustment values with the DIAG simulation. Use DIAG (SIM16) to cancel U2 trouble. Replace the Controller PWB. 90 Content EEPROM read/write error (Controller) Detail PCU EEPROM write error (Controller) Detail PCU EEPROM is properly inserted. Save the counter/adjustment values with the DIAG simulation. Use DIAG (SIM16) to cancel U2 trouble. Replace the Controller PWB. 91 Content Memory check sum error (PCU) Detail PCU pWB EEPROM is properly inserted. Save the counter/adjustment values with the DIAG simulation. Use DIAG (Simulation). Use DIAG (Simulation). Use DIAG (Simulation) to cancel U2 trouble.				
Replace the Controller PWB. 11 Content Counter check sum error (Controller) Detail Counter data area check sum error Cause EEPROM trouble Control circuit trouble by noise Controller PWB EEPROM access circuit trouble Check and remedy Save the counter/adjustment values with the DIAG simulation. Use DIAG (SIM16) to cancel U2 trouble. Replace the Controller PWB. 12 Content Adjustment value check sum error (Controller) Detail Adjustment value check sum error (Controller) Detail Adjustment data area check sum error Cause EEPROM trouble Control circuit trouble by noise Controller PWB EEPROM access circuit trouble Check and remedy Save the counter/adjustment values with the DIAG simulation. Use DIAG (SIM16) to cancel U2 trouble. Replace the Controller PWB. 90 Content EEPROM read/write error (Controller) Detail PCU EEPROM write error (Controller) Detail PCU EEPROM so properly inserted. Save the counter/adjustment values with the DIAG simulation. Use DIAG (SIM16) to cancel U2 trouble. Replace the Controller PWB. 91 Content EEPROM is not initialized. PCU PWB EEPROM access circuit trouble EEPROM is not initialized. PCU PWB Controller PWB. 91 Content Memory check sum error (PCU) Detail PCU PWB EEPROM access circuit trouble Uninitialized E2PROM is not initialized. PCU PWB EEPROM access circuit trouble Uninitialized E2PROM is properly inserted. Save the counter/adjustment values with the DIAG simulation. Use DIAG (SIM16) to cancel U2 trouble. See PROM is not initialized. PCU PWB EEPROM access circuit trouble Uninitialized E2PROM installed. Check and remedy Save the counter/adjustment values with the DIAG simulation. Use DIAG (SIM16) to cancel U2 trouble.			Terriedy	· · · · · · · · · · · · · · · · · · ·
Content Counter check sum error (Controller)				Use DIAG (SIM16) to cancel U2 trouble.
Detail Counter data area check sum error Cause EEPROM trouble Control circuit trouble by noise Controller PWB EEPROM access circuit trouble Check and Check that EEPROM is properly inserted. Save the counter/adjustment values with the DIAG simulation. Use DIAG (SIM16) to cancel U2 trouble. Replace the Controller PWB. 12 Content Adjustment value check sum error (Controller) Detail Adjustment data area check sum error Cause EEPROM trouble Control circuit trouble by noise Controller PWB EEPROM access circuit trouble Check and remedy Save the counter/adjustment values with the DIAG simulation. Use DIAG (SIM16) to cancel U2 trouble. Replace the Controller PWB. 90 Content EEPROM read/write error (Controller) Detail PCU EEPROM write error Cause EEPROM trouble EEPROM trouble EEPROM so not initialized. PCU PWB EEPROM access circuit trouble Check that EEPROM is properly inserted. Save the counter/adjustment values with the DIAG simulation. Use DIAG (SIM16) to cancel U2 trouble. Replace the Controller PWB. 91 Content Memory check sum error (PCU) Detail PCU memory check sum error Cause EEPROM trouble EEPROM trouble EEPROM trouble EEPROM trouble EEPROM is not initialized. PCU PWB EEPROM access circuit trouble Uninitialized E2PROM is properly inserted. Save the counter/adjustment values with the DIAG simulation. Use DIAG (SIM16) to cancel U2 trouble. Replace the Controller PWB.				Replace the Controller PWB.
Cause		11		` ,
Control circuit trouble by noise Controller PWB EEPROM access circuit trouble Check and remedy Check that EEPROM is properly inserted. Save the counter/adjustment values with the DIAG simulation. Use DIAG (SIM16) to cancel U2 trouble. Replace the Controller PWB. 12 Content Adjustment value check sum error (Controller) Detail Adjustment data area check sum error Cause EEPROM trouble Control circuit trouble by noise Controller PWB EEPROM access circuit trouble Check and remedy Save the counter/adjustment values with the DIAG simulation. Use DIAG (SIM16) to cancel U2 trouble. Replace the Controller PWB. 90 Content EEPROM read/write error Cause EEPROM trouble EEPROM is not initialized. PCU PWB EEPROM access circuit trouble Check and remedy Check that EEPROM is properly inserted. Save the counter/adjustment values with the DIAG simulation. Use DIAG (SIM16) to cancel U2 trouble. Replace the Controller PWB. 91 Content Memory check sum error Cause EEPROM trouble EEPROM trouble EEPROM to sund initialized. PCU pWB EEPROM access circuit trouble Check and check that EEPROM is properly inserted. Save the counter/adjustment values with the DIAG simulation. Use DIAG (SIM16) to cancel U2 trouble. Replace the Controller PWB. 91 Content Memory check sum error Cause EEPROM trouble EEPROM is not initialized. PCU pWB EEPROM access circuit trouble Uninitialized E2PROM installed. Check that EEPROM is properly inserted. Save the counter/adjustment values with the DIAG simulation. Use DIAG (SIM16) to cancel U2 trouble.				
Controller PWB EEPRÓM access circuit trouble Check and remedy Check that EEPROM is properly inserted. Save the counter/adjustment values with the DIAG simulation. Use DIAG (SIM16) to cancel U2 trouble. Replace the Controller PWB. 12 Content Adjustment value check sum error (Controller) Detail Adjustment data area check sum error Cause EEPROM trouble Control circuit trouble by noise Controller PWB EEPROM access circuit trouble Check and check that EEPROM is properly inserted. Save the counter/adjustment values with the DIAG simulation. Use DIAG (SIM16) to cancel U2 trouble. Replace the Controller PWB. 90 Content EEPROM read/write error (Controller) Detail PCU EEPROM write error Cause EEPROM is not initialized. PCU PWB EEPROM access circuit trouble Check and remedy Check that EEPROM is properly inserted. Save the counter/adjustment values with the DIAG simulation. Use DIAG (SIM16) to cancel U2 trouble. Replace the Controller PWB. 91 Content Memory check sum error (PCU) Detail PCU pWB EEPROM is properly inserted. Seprence of the counter/adjustment values with the DIAG simulation. Use DIAG (SIM16) to cancel U2 trouble. Replace the Controller PWB.			Cause	
Check and remedy Check that EEPROM is properly inserted. Save the counter/adjustment values with the DIAG simulation. Use DIAG (SIM16) to cancel U2 trouble. Replace the Controller PWB. 12 Content Adjustment value check sum error (Controller) Detail Adjustment data area check sum error Cause EEPROM trouble Control circuit trouble by noise Controller PWB EEPROM access circuit trouble Check and remedy Check that EEPROM is properly inserted. Save the counter/adjustment values with the DIAG simulation. Use DIAG (SIM16) to cancel U2 trouble. Replace the Controller PWB. 90 Content EEPROM read/write error (Controller) Detail PCU EEPROM write error Cause EEPROM trouble EEPROM is not initialized. PCU PWB EEPROM access circuit trouble Check and remedy Check that EEPROM is properly inserted. Save the counter/adjustment values with the DIAG simulation. Use DIAG (SIM16) to cancel U2 trouble. Replace the Controller PWB. 91 Content Memory check sum error (PCU) Detail PCU memory check sum error Cause EEPROM trouble EEPROM is not initialized. PCU PWB EEPROM access circuit trouble Uninitialized E2PROM is poperly inserted. Save the counter/adjustment values with the DIAG simulation. Use DIAG (SIM16) to cancel U2 trouble.				, , , , , , , , , , , , , , , , , , ,
remedy Save the counter/adjustment values with the DIAG simulation. Use DIAG (SIM16) to cancel U2 trouble. Replace the Controller PWB. 12 Content Adjustment value check sum error (Controller) Detail Adjustment data area check sum error Cause EEPROM trouble Control circuit trouble by noise Controller PWB EEPROM access circuit trouble Check and remedy Check that EEPROM is properly inserted. Save the counter/adjustment values with the DIAG simulation. Use DIAG (SIM16) to cancel U2 trouble. Replace the Controller PWB. 90 Content EEPROM read/write error (Controller) Detail PCU EEPROM write error Cause EEPROM trouble EEPROM is not initialized. PCU PWB EEPROM access circuit trouble Check and remedy Check that EEPROM is properly inserted. Save the counter/adjustment values with the DIAG simulation. Use DIAG (SIM16) to cancel U2 trouble. Replace the Controller PWB. 91 Content Memory check sum error (PCU) Detail PCU memory check sum error Cause EEPROM trouble EEPROM trouble EEPROM access circuit trouble Uninitialized. PCU PWB EEPROM access circuit trouble Uninitialized E2PROM installed. Check and remedy Check that EEPROM is properly inserted. Save the counter/adjustment values with the DIAG simulation. Use DIAG (SIM16) to cancel U2 trouble.				trouble
DIAG simulation. Use DIAG (SIM16) to cancel U2 trouble. Replace the Controller PWB. 12 Content Adjustment value check sum error (Controller) Detail Adjustment data area check sum error EEPROM trouble Control circuit trouble by noise Controller PWB EEPROM access circuit trouble Check and remedy Check that EEPROM is properly inserted. Save the counter/adjustment values with the DIAG simulation. Use DIAG (SIM16) to cancel U2 trouble. Replace the Controller PWB. 90 Content EEPROM read/write error (Controller) Detail PCU EEPROM write error Cause EEPROM trouble EEPROM is not initialized. PCU PWB EEPROM access circuit trouble Check and remedy Check that EEPROM is properly inserted. Save the counter/adjustment values with the DIAG simulation. Use DIAG (SIM16) to cancel U2 trouble. Replace the Controller PWB. 91 Content Memory check sum error (PCU) Detail PCU memory check sum error Cause EEPROM trouble EEPROM is not initialized. PCU PWB EEPROM access circuit trouble uninitialized E2PROM installed. Check and remedy Check that EEPROM is properly inserted. Save the counter/adjustment values with the DIAG simulation. Use DIAG (SIM16) to cancel U2 trouble.				
Use DIAG (SIM16) to cancel U2 trouble. Replace the Controller PWB. 12 Content Adjustment value check sum error (Controller) Detail Adjustment data area check sum error Cause EEPROM trouble Control circuit trouble by noise Controller PWB EEPROM access circuit trouble Check and remedy Check that EEPROM is properly inserted. Save the counter/adjustment values with the DIAG simulation. Use DIAG (SIM16) to cancel U2 trouble. Replace the Controller PWB. 90 Content EEPROM read/write error (Controller) Detail PCU EEPROM write error Cause EEPROM trouble EEPROM is not initialized. PCU PWB EEPROM access circuit trouble Check and remedy Check that EEPROM is properly inserted. Save the counter/adjustment values with the DIAG simulation. Use DIAG (SIM16) to cancel U2 trouble. Replace the Controller PWB. 91 Content Memory check sum error (PCU) Detail PCU memory check sum error Cause EEPROM trouble EEPROM trouble EEPROM is not initialized. PCU PWB EEPROM access circuit trouble Uninitialized E2PROM installed. Check and remedy Check that EEPROM is properly inserted. Save the counter/adjustment values with the DIAG simulation. Use DIAG (SIM16) to cancel U2 trouble.			remedy	
Replace the Controller PWB. 12 Content Adjustment value check sum error (Controller) Detail Adjustment data area check sum error Cause EEPROM trouble Control circuit trouble by noise Controller PWB EEPROM access circuit trouble Check and remedy Check that EEPROM is properly inserted. Save the counter/adjustment values with the DIAG simulation. Use DIAG (SIM16) to cancel U2 trouble. Replace the Controller PWB. 90 Content EEPROM read/write error (Controller) Detail PCU EEPROM write error (Controller) Cause EEPROM trouble EEPROM is not initialized. PCU PWB EEPROM access circuit trouble Check and remedy Check that EEPROM is properly inserted. Save the counter/adjustment values with the DIAG simulation. Use DIAG (SIM16) to cancel U2 trouble. Replace the Controller PWB. 91 Content Memory check sum error (PCU) Detail PCU pWB EEPROM access circuit trouble Uninitialized E2PROM is properly inserted. Save the counter/adjustment values with the DIAG simulation. Use DIAG (SIM16) to cancel U2 trouble.				
Detail				
Detail Adjustment data area check sum error Cause EEPROM trouble Control circuit trouble by noise Controller PWB EEPROM access circuit trouble Check and Check that EEPROM is properly inserted. remedy Save the counter/adjustment values with the DIAG simulation. Use DIAG (SIM16) to cancel U2 trouble. Replace the Controller PWB. 90 Content EEPROM read/write error (Controller) Detail PCU EEPROM write error Cause EEPROM is not initialized. PCU PWB EEPROM access circuit trouble EEPROM is not initialized. PCU PWB EEPROM is properly inserted. Save the counter/adjustment values with the DIAG simulation. Use DIAG (SIM16) to cancel U2 trouble. Replace the Controller PWB. 91 Content Memory check sum error (PCU) Detail PCU memory check sum error Cause EEPROM trouble EEPROM is not initialized. PCU PWB EEPROM access circuit trouble Uninitialized E2PROM installed. Check and remedy Save the counter/adjustment values with the DIAG simulation. Use DIAG (SIM16) to cancel U2 trouble.	-	12	Content	
Cause EEPROM trouble Control circuit trouble by noise Controller PWB EEPROM access circuit trouble Check and remedy Check that EEPROM is properly inserted. Save the counter/adjustment values with the DIAG simulation. Use DIAG (SIM16) to cancel U2 trouble. Replace the Controller PWB. 90 Content EEPROM read/write error (Controller) Detail PCU EEPROM write error Cause EEPROM trouble EEPROM is not initialized. PCU PWB EEPROM access circuit trouble Check and remedy Save the counter/adjustment values with the DIAG simulation. Use DIAG (SIM16) to cancel U2 trouble. Replace the Controller PWB. 91 Content Memory check sum error (PCU) Detail PCU memory check sum error Cause EEPROM trouble EEPROM is not initialized. PCU PWB EEPROM access circuit trouble Uninitialized E2PROM installed. Check and Check that EEPROM is properly inserted. Save the counter/adjustment values with the DIAG simulation. Use DIAG (SIM16) to cancel U2 trouble.				·
Control circuit trouble by noise Controller PWB EEPROM access circuit trouble Check and remedy Check that EEPROM is properly inserted. Save the counter/adjustment values with the DIAG simulation. Use DIAG (SIM16) to cancel U2 trouble. Replace the Controller PWB. 90 Content EEPROM read/write error (Controller) Detail PCU EEPROM write error Cause EEPROM trouble EEPROM is not initialized. PCU PWB EEPROM access circuit trouble Check and remedy Check that EEPROM is properly inserted. Save the counter/adjustment values with the DIAG simulation. Use DIAG (SIM16) to cancel U2 trouble. Replace the Controller PWB. 91 Content Memory check sum error (PCU) Detail PCU memory check sum error Cause EEPROM trouble EEPROM is not initialized. PCU PWB EEPROM access circuit trouble Uninitialized E2PROM installed. Check and Check that EEPROM is properly inserted. Save the counter/adjustment values with the DIAG simulation. Use DIAG (SIM16) to cancel U2 trouble.			Detail	Adjustment data area check sum error
Controller PWB EEPROM access circuit trouble Check and Check that EEPROM is properly inserted. Save the counter/adjustment values with the DIAG simulation. Use DIAG (SIM16) to cancel U2 trouble. Replace the Controller PWB. 90 Content EEPROM read/write error (Controller) Detail PCU EEPROM write error Cause EEPROM trouble EEPROM is not initialized. PCU PWB EEPROM access circuit trouble Check and remedy Save the counter/adjustment values with the DIAG simulation. Use DIAG (SIM16) to cancel U2 trouble. Replace the Controller PWB. 91 Content Memory check sum error (PCU) Detail PCU memory check sum error Cause EEPROM trouble EEPROM is not initialized. PCU PWB EEPROM access circuit trouble Uninitialized E2PROM installed. Check and remedy Check that EEPROM is properly inserted. Save the counter/adjustment values with the DIAG simulation. Use DIAG (SIM16) to cancel U2 trouble.			Cause	
trouble Check and Check that EEPROM is properly inserted. Save the counter/adjustment values with the DIAG simulation. Use DIAG (SIM16) to cancel U2 trouble. Replace the Controller PWB. 90 Content EEPROM read/write error (Controller) Detail PCU EEPROM write error Cause EEPROM trouble EEPROM is not initialized. PCU PWB EEPROM access circuit trouble Check and Check that EEPROM is properly inserted. Save the counter/adjustment values with the DIAG simulation. Use DIAG (SIM16) to cancel U2 trouble. Replace the Controller PWB. 91 Content Memory check sum error (PCU) Detail PCU memory check sum error Cause EEPROM trouble EEPROM is not initialized. PCU PWB EEPROM access circuit trouble Uninitialized E2PROM installed. Check and Check that EEPROM is properly inserted. Save the counter/adjustment values with the DIAG simulation. Use DIAG (SIM16) to cancel U2 trouble.				•
remedy Save the counter/adjustment values with the DIAG simulation. Use DIAG (SIM16) to cancel U2 trouble. Replace the Controller PWB. 90 Content EEPROM read/write error (Controller) Detail PCU EEPROM write error Cause EEPROM trouble EEPROM is not initialized. PCU PWB EEPROM access circuit trouble Check and remedy Save the counter/adjustment values with the DIAG simulation. Use DIAG (SIM16) to cancel U2 trouble. Replace the Controller PWB. 91 Content Memory check sum error (PCU) Detail PCU memory check sum error Cause EEPROM trouble EEPROM is not initialized. PCU PWB EEPROM access circuit trouble Uninitialized E2PROM installed. Check and remedy Check that EEPROM is properly inserted. Save the counter/adjustment values with the DIAG simulation. Use DIAG (SIM16) to cancel U2 trouble.				
DIAG simulation. Use DIAG (SIM16) to cancel U2 trouble. Replace the Controller PWB. 90 Content EEPROM read/write error (Controller) Detail PCU EEPROM write error Cause EEPROM trouble EEPROM is not initialized. PCU PWB EEPROM access circuit trouble Check and Check that EEPROM is properly inserted. Save the counter/adjustment values with the DIAG simulation. Use DIAG (SIM16) to cancel U2 trouble. Replace the Controller PWB. 91 Content Memory check sum error (PCU) Detail PCU memory check sum error Cause EEPROM trouble EEPROM is not initialized. PCU PWB EEPROM access circuit trouble Uninitialized E2PROM installed. Check and remedy Check that EEPROM is properly inserted. Save the counter/adjustment values with the DIAG simulation. Use DIAG (SIM16) to cancel U2 trouble.			Check and	Check that EEPROM is properly inserted.
Use DIAG (SIM16) to cancel U2 trouble. Replace the Controller PWB. 90 Content EEPROM read/write error (Controller) Detail PCU EEPROM write error Cause EEPROM trouble EEPROM is not initialized. PCU PWB EEPROM access circuit trouble Check and Check that EEPROM is properly inserted. Save the counter/adjustment values with the DIAG simulation. Use DIAG (SIM16) to cancel U2 trouble. Replace the Controller PWB. 91 Content Memory check sum error (PCU) Detail PCU memory check sum error Cause EEPROM trouble EEPROM is not initialized. PCU PWB EEPROM access circuit trouble Uninitialized E2PROM installed. Check and remedy Check that EEPROM is properly inserted. Save the counter/adjustment values with the DIAG simulation. Use DIAG (SIM16) to cancel U2 trouble.			remedy	•
Replace the Controller PWB. 90 Content EEPROM read/write error (Controller) Detail PCU EEPROM write error Cause EEPROM trouble				
90 Content EEPROM read/write error (Controller) Detail PCU EEPROM write error Cause EEPROM trouble EEPROM is not initialized. PCU PWB EEPROM access circuit trouble Check and Check that EEPROM is properly inserted. Save the counter/adjustment values with the DIAG simulation. Use DIAG (SIM16) to cancel U2 trouble. Replace the Controller PWB. 91 Content Memory check sum error (PCU) Detail PCU memory check sum error Cause EEPROM trouble EEPROM is not initialized. PCU PWB EEPROM access circuit trouble Uninitialized E2PROM installed. Check and remedy Check that EEPROM is properly inserted. Save the counter/adjustment values with the DIAG simulation. Use DIAG (SIM16) to cancel U2 trouble.				
Detail PCU EEPROM write error Cause EEPROM trouble EEPROM is not initialized. PCU PWB EEPROM access circuit trouble Check and remedy Check that EEPROM is properly inserted. Save the counter/adjustment values with the DIAG simulation. Use DIAG (SIM16) to cancel U2 trouble. Replace the Controller PWB. 91 Content Memory check sum error (PCU) Detail PCU memory check sum error Cause EEPROM trouble EEPROM is not initialized. PCU PWB EEPROM access circuit trouble Uninitialized E2PROM installed. Check and remedy Check that EEPROM is properly inserted. Save the counter/adjustment values with the DIAG simulation. Use DIAG (SIM16) to cancel U2 trouble.		90	Content	
EEPROM is not initialized. PCU PWB EEPROM access circuit trouble Check and remedy Check that EEPROM is properly inserted. Save the counter/adjustment values with the DIAG simulation. Use DIAG (SIM16) to cancel U2 trouble. Replace the Controller PWB. 91 Content Memory check sum error (PCU) Detail PCU memory check sum error Cause EEPROM trouble EEPROM is not initialized. PCU PWB EEPROM access circuit trouble Uninitialized E2PROM installed. Check and remedy Check that EEPROM is properly inserted. Save the counter/adjustment values with the DIAG simulation. Use DIAG (SIM16) to cancel U2 trouble.				, ,
PCU PWB EEPROM access circuit trouble Check and remedy Check that EEPROM is properly inserted. Save the counter/adjustment values with the DIAG simulation. Use DIAG (SIM16) to cancel U2 trouble. Replace the Controller PWB. 91 Content Memory check sum error (PCU) Detail PCU memory check sum error Cause EEPROM trouble EEPROM is not initialized. PCU PWB EEPROM access circuit trouble Uninitialized E2PROM installed. Check and remedy Check that EEPROM is properly inserted. Save the counter/adjustment values with the DIAG simulation. Use DIAG (SIM16) to cancel U2 trouble.			Cause	EEPROM trouble
Check and remedy Check that EEPROM is properly inserted. Save the counter/adjustment values with the DIAG simulation. Use DIAG (SIM16) to cancel U2 trouble. Replace the Controller PWB. 91 Content Memory check sum error (PCU) Detail PCU memory check sum error Cause EEPROM trouble EEPROM is not initialized. PCU PWB EEPROM access circuit trouble Uninitialized E2PROM installed. Check and remedy Check that EEPROM is properly inserted. Save the counter/adjustment values with the DIAG simulation. Use DIAG (SIM16) to cancel U2 trouble.				
remedy Save the counter/adjustment values with the DIAG simulation. Use DIAG (SIM16) to cancel U2 trouble. Replace the Controller PWB. 91 Content Memory check sum error (PCU) Detail PCU memory check sum error Cause EEPROM trouble EEPROM is not initialized. PCU PWB EEPROM access circuit trouble Uninitialized E2PROM installed. Check and remedy Check that EEPROM is properly inserted. Save the counter/adjustment values with the DIAG simulation. Use DIAG (SIM16) to cancel U2 trouble.				
DIAG simulation. Use DIAG (SIM16) to cancel U2 trouble. Replace the Controller PWB. 91 Content Memory check sum error (PCU) Detail PCU memory check sum error Cause EEPROM trouble EEPROM is not initialized. PCU PWB EEPROM access circuit trouble Uninitialized E2PROM installed. Check and remedy Check that EEPROM is properly inserted. Save the counter/adjustment values with the DIAG simulation. Use DIAG (SIM16) to cancel U2 trouble.				
Replace the Controller PWB. 91 Content Memory check sum error (PCU) Detail PCU memory check sum error Cause EEPROM trouble EEPROM is not initialized. PCU PWB EEPROM access circuit trouble Uninitialized E2PROM installed. Check and remedy Check that EEPROM is properly inserted. Save the counter/adjustment values with the DIAG simulation. Use DIAG (SIM16) to cancel U2 trouble.			Torricus	•
91 Content Memory check sum error (PCU) Detail PCU memory check sum error Cause EEPROM trouble EEPROM is not initialized. PCU PWB EEPROM access circuit trouble Uninitialized E2PROM installed. Check and remedy Check that EEPROM is properly inserted. Save the counter/adjustment values with the DIAG simulation. Use DIAG (SIM16) to cancel U2 trouble.				
Detail PCU memory check sum error Cause EEPROM trouble EEPROM is not initialized. PCU PWB EEPROM access circuit trouble Uninitialized E2PROM installed. Check and remedy Check that EEPROM is properly inserted. Save the counter/adjustment values with the DIAG simulation. Use DIAG (SIM16) to cancel U2 trouble.			_	'
Cause EEPROM trouble EEPROM is not initialized. PCU PWB EEPROM access circuit trouble Uninitialized E2PROM installed. Check and Check that EEPROM is properly inserted. Save the counter/adjustment values with the DIAG simulation. Use DIAG (SIM16) to cancel U2 trouble.		91		` ,
EEPROM is not initialized. PCU PWB EEPROM access circuit trouble Uninitialized E2PROM installed. Check and Check that EEPROM is properly inserted. Save the counter/adjustment values with the DIAG simulation. Use DIAG (SIM16) to cancel U2 trouble.				
PCU PWB EEPROM access circuit trouble Uninitialized E2PROM installed. Check and Check that EEPROM is properly inserted. Save the counter/adjustment values with the DIAG simulation. Use DIAG (SIM16) to cancel U2 trouble.			Cause	
Uninitialized E2PROM installed. Check and remedy Check that EEPROM is properly inserted. Save the counter/adjustment values with the DIAG simulation. Use DIAG (SIM16) to cancel U2 trouble.				
remedy Save the counter/adjustment values with the DIAG simulation. Use DIAG (SIM16) to cancel U2 trouble.				
DIAG simulation. Use DIAG (SIM16) to cancel U2 trouble.				
Use DIAG (SIM16) to cancel U2 trouble.			remedy	

MAIN	SUB		
U7	U7 00 Cd		RIC communication trouble
		Detail	RIC communication trouble
			Communication cable test error after turning on the power or exiting DIAG.
		Cause	Disconnection of connector and harness
			RTC control PWB trouble Control PWB (Controller) trouble
			Malfunction by noise
		Check and	Canceled by turning OFF/ON the power.
		remedy	Check connector and harness in the
		_	communication line.
PF	00	Content	RIC copy inhibit signal is received.
		Detail	Copy inhibit command from RIM (host) is received.
		Cause	Judged by the host.
		Check and	Inform to the host.
		remedy	

3. Halt of operation in trouble

A. Troubles where the machine can be operated depending on the conditions (Include Multi Function)

	Judgment	Trouble	Operation-possible mode							
Irouble		code	Copy read (interruption, etc.)	FAX send	Email send	FAX print	Print	List print		
(SPF trouble)	SCANNER	U5	△1	△1	△1	0	0	0		
Scanner section troubles (Mirror motor, lens, copy lamp)	SCANNER	L1,L3,U2 (80,81)	X	Х	Х	0	0	0		
(AE trouble)	-	L9	△2	△2	△2	0	0	0		
(ADU trouble)	PCU	U4	∆3	0	0	∆3	∆3	∆3		
FAX board trouble	Controller/ FAX	F6,F7	0	Х	0	Х	0	0		
FAX power OFF	Controller		0	X	0	Х	0	0		
Staple trouble	PCU	F1(10)	△4	0	0	∆4	△4	△4		
Paper feed tray trouble	PCU	F3, U6 (Desk)	△5	0	0	△5	△5	△5		
(Process control trouble)	PCU		△6	0	0	△6	△6	△6		
PCU section troubles (Motor, fusing, etc.)	PCU		X	0	0	Х	Х	Х		
After-work trouble	PCU		△9	0	0	∆9	△9	△9		
Laser trouble	PCU	E7 (02 only), L6	Х	0	0	Х	Х	Х		
HDD trouble	Controller	E7 (03)	X	Х	Х	Х	Х	Х		
CCD troubles (Shading, etc.)	SCANNER	E7 (10, 11, 13)	X	Х	Х	0	0	0		
Scanner communication trouble	Controller	E7 (80)	X	Х	Х	0	0	0		
PCU communication trouble	Controller	E7 (90)	X	0	0	Х	Χ	Х		
Printer port trouble	Controller	F9	0	0	△11	0	△11	0		
Backup battery voltage fall	Controller	U1 (01)	0	Χ	Х	0	0	0		
Memory trouble (Expansion RAM not installed, etc.)	Controller	U2 (00, 11, 12)	X	Х	Х	Х	Х	Х		
External communication invalid (RIC)	Controller	U7, PF	X	Х	Х	Х	Х	Х		
Image memory trouble, decode error	Controller	E7(01, 06)	X	Χ	Х	Х	Х	X		

- O: Operation possible X: Operation impossible \triangle : Operation possible depending on conditions
- \triangle 1 :Operation possible in the OC mode
- ∆2 :Operation possible in the manual mode
- △3 :Single mode only
- $\triangle 4$:Operation possible except for the staple mode
- $\triangle 5$:Operation possible except for the trouble tray
- $\triangle 6$:Operation possible if the image can be limited
- $\triangle 8$:Original/list print possible after reception
- △9 :Operation possible except for the trouble paper exit section
- \triangle 10 :Operation possible by use of memory only
- \triangle 11 :Operation possible if the used port (NIC, Centro) is normal

B. Trouble mode process

Machine operation possible	Operations except for the trouble mode are possible (READY).
depending on conditions	For the mode where operations are impossible, only setup can be allowed, and the message is provided to show
	that operations are impossible. (NOT READY in this case.)
	(Display)
	A dialog is shown in case of a trouble. For the mode where operations are possible, the OK button is added to the
	message. For the mode where operations are impossible, the OK button is not shown, and the process to cancel is
	indicated.
Machine operation is impossible	The trouble display is always shown, and all setup operations are invalid.

C. Writing to the trouble memory

In this series, the simulation (diag) allows to select whether the same trouble is written to the trouble memory when it occurs. If the DIAG simulation is set as above, when any trouble occurs, its hysteresis is written to the trouble memory. DIAG(SIM 26-35)

- 0: The same trouble as the previous one is not recorded. (Default)
- 1: When a trouble occurs, it is written to the trouble memory without exception.

CAUTION FOR BATTERY REPLACEMENT

(Danish)

ADVARSEL!

Lithiumbatteri – Eksplosionsfare ved fejlagtig håndtering. Udskiftning må kun ske med batteri af samme fabrikat og type.

Levér det brugte batteri tilbage til leverandoren.

(English)

Caution!

Danger of explosion if battery is incorrectly replaced.
Replace only with the same or equivalent type
recommended by the manufacturer.

Dispose of used batteries according to manufacturer's instructions.

(Finnish)

VAROITUS

Paristo voi räjähtää, jos se on virheellisesti asennettu. Vaihda paristo ainoastaan laitevalmistajan suosittelemaan tyyppiin. Hävitä käytetty paristo valmistajan ohjeiden mukaisesti.

(French)

ATTENTION

Il y a danger d'explosion s' il y a remplacement incorrect de la batterie. Remplacer uniquement avec une batterie du même type ou d'un type équivalent recommandé par le constructeur.

Mettre au rebut les batteries usagées conformément aux instructions du fabricant.

(Swedish)

VARNING

Explosionsfara vid felaktigt batteribyte.
Använd samma batterityp eller en ekvivalent
typ som rekommenderas av apparattillverkaren.
Kassera använt batteri enligt fabrikantens
instruktion.

(German)

Achtung

Explosionsgefahr bei Verwendung inkorrekter Batterien.
Als Ersatzbatterien dürfen nur Batterien vom gleichen Typ oder vom Hersteller empfohlene Batterien verwendet werden.
Entsorgung der gebrauchten Batterien nur nach den vom Hersteller angegebenen Anweisungen.



COPYRIGHT © 2001 BY SHARP CORPORATION

All rights reserved. Printed in Japan. No part of this publication may be reproduced, stored in a retrieval system, or transmitted, in any form or by any means, electronic, mechanical, photocopying, recording, or otherwise, without prior written permission of the publisher.

Trademark acknowledgments

Windows and Windows NT are trademarks of Microsoft Corporation in the U.S.A. and other countries.

IBM and PC/AT are trademarks of International Business Machines Corporation. PCL is a trademark of Hewlett-Packard Company.

Pentium is a registered trademark of Intel Corporation.


All other trademarks and copyrights are the property of their respective owners.

SHARP CORPORATION **Digital Document System Group Quality & Reliability Control Center** Yamatokoriyama, Nara 639-1186, Japan

SHARP

PARTS GUIDE

CODE:00ZARM450/P1E



LASER PRINTER (MULTI FUNCTION)

AR-M350 AR-M450 OPTION: AR-EF1 AR-M11

AR-RK1

MODEL

CONTENTS -

- 1 Exteriors
- 12 Controller BOX unit
- Packing material & Accessories
- 26 MFP Control PWB (ARM350/M450/350M/450M/ARM11)
- 27 Exteriers[AR-EF1]
- Original detect unit[AR-EF1]
- Operation panel unit[AR-EF1]
- 30 Optical unit 1[AR-EF1]
- 31 Optical unit 2[AR-EF1]
- 32 Lamp unit[AR-EF1]
- 33 DSPF Assembly section[AR-EF1]

- 34 DSPF Paper feed unit[AR-EF1]
- 35 DSPF Upper transfer unit[AR-EF1]
- 36 DSPF CIS unit[AR-EF1]
- Packing Material & Accessories[AR-EF1]
- 38 MFP OPE PWB[AR-EF1]
- 39 Scanner control PWB[AR-EF1]
- 40 CIS Control PWB[AR-EF1]
- 41 MFP Controler PWB[AR-M11]
- 42 Packing material & Accessories[ARM11]
- 43 Packing Material & Accessories[AR-RK1]
- Index

The AR-M350 / AR-M450 Parts Guide describes only the parts change from AR-P350 / AR-P450 Parts Guide. for the common parts,please refer to the AR-P350 / AR-P450(CODE: 00ZAR350LPP1/) Parts Guide.

DEFINITION

The definition of each Rank is as follows and also noted in the list

A: Parts necessary to be stocked as High usage parts.

B: Parts necessary to be stocked as Standard usage parts.

C: Low usage parts.

D: Parts necessary for refurbish.

E: Unit parts recommended to be stocked for efficient after sales service.

Please note that the lead time for the said parts may be longer than normal parts.

S: Consumable parts.

Please note that the following parts used in Copier under the same description are classified into A or B Rank depending upon the place used.

Example: Gear made of Metal, Sprocket, Bearing, Belt made of Rubber, Spring clutch mechanism.

A Rank : The parts which may be with the revolution or loading.

B Rank: Parts similar to A Rank parts, but are not included in Rank A.

Because parts marked with "A" is indispensable for the machine safety maintenance and operation, it must be replaced with the parts specific to the product specification.

- O Other than this Parts Guide, please refer to documents Service Manual (including Circuit Diagram) of this model.
- O Please use the 13 digit code described in the right hand corner of front cover of the document, when you place an order.
- O For U.S. only-Use order codes provided in advertising literature. Do not order from parts department.

[Note] * These parts are supplied by SMF.


1 Exteriors

NO.	PARTS CODE	PRICE RANK	NEW MARK	PART RANK	DESCRIPTION	
5	GCAB-0940FCZ2	BA	N	D	Paper exit tray exterior	
11	HPNLC0243FCZ1	AP	N	D	Operation cabinet	
	CPNLH0020QS12	AK	N	D	Model panel M350 [ARM3	350]
200	CPNLH0020QS13	AK	N	D	Model panel M450 [ARM4	450]
20	CPNLH0020QS22	AK	N	D	Model panel 350M [AR35	[M0
	CPNLH0020QS23	AK	N	D	Model panel 450M [AR45	OM]

12 Controller BOX unit

NO.	PARTS CODE	PRICE RANK	NEW MARK	PART RANK	DESCRIPTION
	L X - B Z 0 9 2 1 F C Z 1	ΑE	N	С	Scanner Screw
	XBPSD26P06000	AA		С	Screw (2.6×6)
	LPLTM5765FCZ1	AH	N	С	Control joint plate
	PCŌVP1560FCZZ	AC	N	С	FAX I/F cover
	PCŌVP1557FCZZ	AC		С	LAN/option cover
	XBPSD30P06000	AA		С	Screw (3×6)
50	XHBSE30P06000	AA		С	Screw (3×6)
51	XBBSD30P06000	AA		С	Screw (3×6)
54	V H i 2 8 F 3 2 2 L 0 1 F V H i 2 8 F 3 2 2 L 0 3 F	BE	N	В	MFP flash ROM A J (28F322L01F) [Japan]
34		BF	N	В	MFP flash ROM A EX (28F322L03F) [except Japan]
55	VHi28F322L02F	BF	N	В	MFP flash ROM B J (28F322L02F) [Japan]
	VHi28F322L04F	BL	N	В	MFP flash ROM B EX (28F322L04F) [except Japan]
56	L X - B Z 0 8 2 8 F C Z Z	AD		С	Handle fixing screw

12 Controller BOX unit



17 Packing material & Accessories

	DARTS CODE	PRICE		PART	DECODIDEION	
NO.	PARTS CODE	RANK	MARK	RANK	DESCRIPTION	INTERVOTOR CT CT CT CT
	SPAKC6122DS18	AU	N	D		M350][STCL,SRS,SRSSC]
	SPAKC6122DS19	AU	N	D	Packing case	[ARM350][China]
	SPAKC6122DS17	AU	N	D		[ARM350][other countries]
5	SPAKC6122DS21 SPAKC6122DS22	AU	N	D D		M450][STCL,SRS,SRSSC]
	SPAKC6122DS22 SPAKC6122DS20	AU	N N	D	Packing case	[ARM450][China]
	SPAKC6122D520 SPAKC6118DS12	AU	N N	D		[ARM450][other countries]
	SPAKC6118DS12	AU	N	D	Packing case Packing case	[AR350M][Japan] [AR450M][Japan]
	PSHEP4927FCZZ	AM	N	D	Key sheet	[AIX430M][Japan] [French]
	PSHEP4927FCZ1	AR	N	D	Key sheet	[Germany]
	PSHEP4927FCZ2	AM	N	D	Key sheet	[Spanish]
	PSHEP4927FCZ3	AR	N	D	Key sheet	[Italian]
	PSHEP4927FCZ4	AR	N	D	Key sheet	[Dutch]
40	PSHEP4927FCZ5	AR	N	D	Key sheet	[Swedish]
13	PSHEP4927FCZ6	AR	N	D	Key sheet	[Norwegian]
	PSHEP4927FCZ7	AR	N	D	Key sheet	[Finnsh]
	PSHEP4927FCZ8	AR	N	D	Key sheet	[Danish]
	PSHEP4927FCZ9	AR	N	D	Key sheet	[Hungarian]
	PSHEP4927FC10	AR	N	D	Key sheet	[Czechoslovakia]
	PSHEP4927FC11	AR	N	D	Key sheet	[Polish]
	TiNSE2181FCZZ	ΑT	N	D	Operation manual	[USA]
	TiNSJ2076FCZZ	AQ	N	D	Operation manual COPY	[Japan]
	T i N S E 2 O 7 7 F C Z Z	AQ	N	D	Operation manual COPY	[USA]
	T i NSE2078FCZZ	AW	N	D	Operation manual COPY	[English]
	TiNSF2079FCZZ	AW	N	D	Operation manual COPY	[French]
	TiNSG2080GHZZ	AS	N	D	Operation manual COPY	[German]
	T i N S E 2 0 8 1 G H Z Z	AS	N	D	Operation manual COPY	[U Kingdom]
	T i N S S 2 0 8 2 F C Z Z T i N S i 2 0 8 3 G H Z Z	AW	N	D	Operation manual COPY	[Spanish]
	TiNSH2084GHZZ	AS	N N	D D	Operation manual COPY Operation manual COPY	[Italian] [Dutch]
	C i NSR 2 0 8 5 F C 5 1	AS	N	D	Operation manual COPY	[Russian]
	C i NSZ 2 0 8 6 F C 5 1	AS	N	D	Operation manual COPY	[Arabic]
	T i N S E 2 0 8 7 F C Z Z	AX	N	D	Operation manual COPY	[Hong Kong]
	TiNSW2089GHZZ	AS	N	D	Operation manual COPY	[Swedish]
	TiNSZ2090GHZZ	AS	N	D	Operation manual COPY	[Norwegian]
	TiNSZ2091GHZZ	AS	N	D	Operation manual COPY	[Finnsh]
	TiNSD2092GHZZ	AS	N	D	Operation manual COPY	[Danish]
	T i N S Z 2 0 9 3 G H Z Z	AS	N	D	Operation manual COPY	[Hungarian]
	TiNSZ2094GHZZ	AS	N	D	Operation manual COPY	[Czechoslovakia]
20	TiNSZ2095GHZZ	AS	N	D	Operation manual COPY	[Polish]
	TiNSJ2118FCZZ	AN	N	D	Operation manual SCANNER	[Japan]
	TiNSE2119FCZZ	AN	N	D	Operation manual SCANNER	[USA]
	TiNSE2120FCZZ	ΑV	N	D	Operation manual SCANNER	[English]
	TiNSF2121FCZZ	AV	N	D	Operation manual SCANNER	[French]
	TiNSG2122GHZZ	AS	N	D	Operation manual SCANNER	[German]
	T i NSE2123GHZZ	AS	N	D	Operation manual SCANNER	[U Kingdom]
	TiNSS2124FCZZ	AV	N	D	Operation manual SCANNER	[Spanish]
	T i N S i 2 1 2 5 G H Z Z	AS	N	D	Operation manual SCANNER	[Italian]
	T i N S H 2 1 2 6 G H Z Z	AS	N	D	Operation manual SCANNER	[Dutch]
	C i NSR 2 1 2 7 F C 5 1	AR	N	D	Operation manual SCANNER	[Russian]
	C i N S Z 2 1 2 8 F C 5 1 T i N S E 2 1 2 9 F C Z Z	AR AV	N	D D	Operation manual SCANNER	[Arabic] [Hong Kong]
	T i N S W 2 1 3 1 G H Z Z	AS	N N	D	Operation manual SCANNER Operation manual SCANNER	[Hong Kong] [Swedish]
	TiNSW2131GHZZ	AS	N	D	Operation manual SCANNER	[Norwegian]
	T i N S Z 2 1 3 3 G H Z Z	AS	N	D	Operation manual SCANNER	[Finnsh]
	T i NSD 2 1 3 4 GH Z Z	AS	N	D	Operation manual SCANNER	[Pinnsh]
	T i N S Z 2 1 3 5 G H Z Z	AS	N	D	Operation manual SCANNER	[Hungarian]
	T i NSZ2133GHZZ	AS	N	D	Operation manual SCANNER	[Czechoslovakia]
	T i N S Z 2 1 3 7 G H Z Z	AS	N	D	Operation manual SCANNER	[Polish]
			i N	_ J	- portation manual CONTRICT	[i olisii]

26 MFP Control PWB (ARM350/M450/350M/450M/ARM11)


20 1111		PRICE		PART	/350W/450W/ARWITT)	
NO.	PARTS CODE	RANK				DESCRIPTION
	CAPH0010GCZZ	AD		D	Jumper (JM-2W-96)	[JP2,3,4,5,6,7]
	CŌVP1468FCZZ	AD		D	FAX battery cover	
	CNCM0041QSZZ	AP AE	N	С	Connector (TX25-100P12)	[CN2,9,12]
	C N C M 1 1 4 6 F C Z Z C N C M 1 1 4 8 F C Z Z	AP	N N	C	Connector (9A12-1034) Connector (TX25100P6ST)	[CN14] [CN16]
	CNCW0946FCZZ	AH	IN	C	Connector (36pin)	[CN10]
	CNCW1147FCZZ	AL	N	C	Connector (TX2450RLTH1)	[CN13]
	CNCW1149FCZZ	AN	N	С	Connector (8AL068S305C)	[CN8]
	F S - D 1 3 2 C Q C Z Z	AG		Α	Fuse (1.25/250T)	[F1]
	FSHB0028FCZZ	AC		С	Fuse holder (TP00351-31)	[F1]
	P i N - 0 0 0 3 G C Z Z	AC		С	Pin (T3B-SQ)	[JP2,3,4,5,6,7,]
	S O C Z 0 0 0 1 Q S Z Z S O C Z 0 0 7 3 F C Z Z	A L		C	Socket (DMM168-FLAA2-3A133) Connector (72pin)	[CN3] [CN4,5.6]
	S O C Z O O 7 9 F C Z Z	AN		C	Connector (100pin)	[AR350M/450M][CN7
	S O C Z 6 4 2 8 A C Z Z	AE		C	IC socket (28pin)	[IC36]
	CRSP6676RCZZ	AG		В	Crystal (32.768KHz)	[X6
	CRUA0005FCZZ	AP		В	Crystal (14.745)	[X7]
	CRUA0007FCZZ	AP		В	Crystal (31.554)	[X4]
	CRUA0008FCZZ	AP		В	Crystal (40.57M)	[X2]
	CRUA0009FCZZ	AP		В	Crystal (66.666MHZ)	[X3,5
	CRUA0012FCZZ FiLN0048FCZZ	AP AC		В	Crystal (66M)	[X1]
	FiLN0048FCZZ FiLN0051FCZZ	AC	N	C	Coil (BLM10B121SB) Coil (MMZ1608D121B)	[L2,3] [L25~30,33,34]
R N	MPTR4100ACZZ	AB		В	Block resistor (10 Ω ×4)	[BR6~13,15~25,28,29]
	MPTR4100ACZZ	AB		В	Block resistor (10 Ω ×4)	[BR33~44,46,48,53~72]
25 R N	MPTR4103ACZZ	AB		В	Block resistor (10KΩ×4)	[BR1~5,14,26,27,30,31,32
H N	MPTR4103ACZZ	AB		В	Block resistor (10KΩ×4)	[BR74,76,78,80~102
	MPTR4330ACZZ	AB	-	В	Block resistor $(33\Omega \times 4)$	[BR47,49,50,51,73,75,77,79]
	MPTR4472ACZZ BATi0014FCZZ	AB		В	Block resistor (4.7KΩ×4)	[BR52,45]
	CCCCZ1HH101J	AN		B C	Battery (CR2477-H01) Capacitor (50WV 100pF)	[BT1] [C7,8,10,17,18,20,22,30,33
	CCCCZ1HH101J	AA		C	Capacitor (50WV 100pF)	[C7,6,10,17,16,20,22,30,35] [C35,38,39,40,43,47,48,51]
	CCCCZ1HH220J	AA		C	Capacitor (50WV 22pF)	[C61
	CEAPH1HC105M	AC		C	Capacitor (50WV 1µF)	[C181,188,205,206
	CEAPS1AC227M	AD		С	Capacitor (10WV 220μF)	[C309,310
	CEAPS1CC106M	AC		С	Capacitor (16WV 10μF)	[C1,6,21,75,94,111,125,165
٧٠	CEAPS1CC106M	AC		С	Capacitor (16WV 10μF)	[C166,169,178,179,223,224
	CEAPS1CC226M	AC		С	Capacitor (16WV 22µF)	[C57,64,90,114,115,136,170,176]
	CEAPS1CC476M CKYCZ1CF104Z	AC AB		C	Capacitor (16WV 47μF) Capacitor (16WV 0.10μF)	[C95,167,168,180] [C3,9,11,12,13,14,23~29]
	CKYCZ1CF104Z	AB		C	Capacitor (16WV 0.10μΓ)	[C31,32,34,36,37,41,42,44,45]
	CKYCZ1CF104Z	AB		C	Capacitor (16WV 0.10µF)	[C46,49,50,52,53,54,55,56]
	CKYCZ1CF104Z	AB		C	Capacitor (16WV 0.10µF)	[C58,59,60,62,63,65,66,67
	CKYCZ1CF104Z	AB		С	Capacitor (16WV 0.10μF)	[C68,70,71,72,73,74,76~82]
	CKYCZ1CF104Z	AB		С	Capacitor (16WV 0.10μF)	[C85,86,87,88,89,91,92,93]
	CKYCZ1CF104Z	AB		С	Capacitor (16WV 0.10μF)	[C96,97,98,99,100,102~108]
	CKYCZ1CF104Z CKYCZ1CF104Z	AB AB		С	Capacitor (16WV 0.10μF) Capacitor (16WV 0.10μF)	[C110,112,113,116~124,126]
	CKYCZ1CF1042	AB		C	Capacitor (16WV 0.10µF)	[C127,128,130,131,132,133] [C134,135,137,139,140~145]
	CKYCZ1CF104Z	AB		C	Capacitor (16WV 0.10μF)	[C149,151,153~164,172,173]
	CKYCZ1CF104Z	AB		C	Capacitor (16WV 0.10μF)	[C177,182,183,185,186,187
VC	CKYCZ1CF104Z	AB		C	Capacitor (16WV 0.10µF)	[C189~199,201,202,204]
	CKYCZ1CF104Z	AB		С	Capacitor (16WV 0.10μF)	[C208~222,235~262
	CKYCZ1CF104Z	AB		С	Capacitor (16WV 0.10μF)	[C264~279,292~303
	CKYCZ1HB102K CKYCZ1HF103Z	AA		С	Capacitor (50WV 1000pF)	[C129]
	HDDAP202U/-1	AB		C B	Capacitor (50WV 0.01μF) Diode (DAP202U)	[C69,109 [D7,10
	HDRB451F//-1	AD		В	Diode (BA451F)	ار براط] D12,14,20,21[
	HDRLS73///-1	AA		В	Diode (RLS73)	[D12,14,20,21
	H i 6 5 9 4 6 P 0 7 - 1	ВА		В	IC (65946P07)	[IC32
	Hi74LCX08MTC	ΑE		В	IC (74LCX08MTC)	[IC46,26
	H i 7 4 L C X 1 4 M T C	AE		В	IC (74LCX14MTC)	[IC43
	H i 7 4 L C X 2 4 4 M T	AG	-	В	IC (74LCX244MT)	[IC12
	H	AE AP	 	B B	IC (74LCX32MTC) IC (74LVX16128)	[IC11 [IC15
	H i 9 0 L V 1 7 A W - 1	AP	 	В	IC (90LV17AW)	[IC18]
	HiDS14C238//	AT		В	IC (DS14C238)	[IC42
	H i E E P 6 4 - 1 2 0 P	AW		В	IC (EEP64-120P)	[IC36
	H i H G 7 3 C 0 9 5 - 1	AY		В	IC (HG73C095)	[IC53
	H i K S 0 U 1 3 4 7 - 1	BN		В	IC (KS0U1347)	[IC19
	H i L C X 1 5 7 M T - 1	AG		В	IC (LCX157MT)	[IC14
	HiLCX16244-1	AM		В	IC (LCX16244)	[IC21,49,50
	H i L C X 1 6 2 4 5 - 1 H i L C X 1 6 3 7 3 - 1	AM AM	-	B B	IC (LCX16245) IC (LCX16373)	[IC16,24,31,51,52 [IC34
	H i L C X 7 4 M T C - 1	AE		В	IC (LCX16373) IC (LCX74MTC)	[IC34] [IC10]
-	H i L M 3 9 3 D + + - 1	AE		В	IC (LM393D)	[IC 10]
	H i L V T 2 4 0 M T - 1	AL		В	IC (LVT240MT)	lics
	H i M 8 7 J 4 8 1 0 - 1	BK		В	IC (M87J4810)	[IC25]
	H i N 2 3 7 0 R 0 4 - 1	AF		В	IC (N2370R04)	[IC23]
62 V F	H i N 2 3 7 0 R 3 3 - 1	AF	1	В	IC (N2370R33)	[IC54]

26 MFP Control PWB (ARM350/M450/350M/450M/ARM11)

20	VIEW COLLINO PAND	<u> </u>			350M/450M/ARM11)	
NO.	PARTS CODE	PRICE RANK	NEW	PART		DESCRIPTION
62	V H i N 2 3 9 1 D 2 5 - 1	AG	MARK	RANK B	IC (N2391D25)	[IC35,33]
	VH i N J M 3 1 7 D L - 1	AK		В	IC (NJM317DL)	[IC2]
	VH i N J U 6 3 5 6 E - 1	AK		В	IC (NJU6356E)	[IC40]
	VHiPi6C2309-1	AR		В	IC (PI6C2309)	[IC9,29]
67	VHiPM2500++-1	BP		В	IC (PM2500)	[IC13]
68	VH i PST 5 9 8 DN - 1	AF		В	IC (PST598DN)	[IC47]
	VH i P S T 5 9 8 i N - 1	AF		В	IC (PST598I)	[IC48]
	VH i SD 4 M 1 6 L 1 - 1	ΑZ		В	IC (SD4M16L1)	[IC22]
	VH i SD 8 M 1 6 L 1 - 1	BB		В	IC (SD8M16L1)	[IC4,5,6,7,27]
72	V H i S R 1 0 2 4 - 7 L L V H i T 4 9 5 5 A 2 0 - 1	AU BF		В	IC (SR1024-7LL)	[IC55,56]
	VH i TD 6 2 5 0 3 F - 1	AF		B B	IC (T4955A20) IC (TD62503F)	[IC20] [IC38,41,44,45]
	VHP1LHEE-002A	AC		В	LED (Red) (1LHEE-002A)	[D13]
	VHV1608C080-1	AC		В	Varistor (1608C080)	[RV1~6]
77	VHViCPS1.2/-1	AF		В	IC protecrot (ICPS1.2)	[Q1]
	VRS-CZ1JD000J	AA		С	Resistor (1/16W $0\Omega \pm 5\%$)	[R1,3,32,33,49,77,94,97,106]
	VRS-CZ1JD000J	AA		С	Resistor (1/16W $0\Omega \pm 5\%$)	[R108,120,141,166,198,220,222]
78		AA		С	Resistor (1/16W $0\Omega \pm 5\%$)	[R225,229,232,233,290~307]
	VRS-CZ1JD000J	AA		С	Resistor (1/16W $0\Omega \pm 5\%$)	[R310~348,399,400,406]
	VRS-CZ1JD000J VRS-CZ1JD100J	AA		С	Resistor (1/16W 0Ω ±5%)	[R407,409,410,413,414] [R36,59,64,65,96,116,118,126]
79	VRS-CZ1JD100J	AA		C	Resistor (1/16W $10\Omega \pm 5\%$) Resistor (1/16W $10\Omega \pm 5\%$)	[R36,39,64,65,96,116,116,126] [R127,136,137,149,161,170,177,185]
	VBS-C71.ID101.I	AA		C	Resistor (1/16W 1002 \pm 5%) Resistor (1/16W 1000 \pm 5%)	[R127,136,137,149,161,170,177,165] [R9,10,101,102,109,180]
80	VRS-CZ1JD101J	AA		C	Resistor (1/16W 100Ω ±5%)	[R181,183,235,236]
	VBS-C71JD102J	AA		C	Resistor (1/16W 1.0KΩ ±5%)	[R11,129,130,134,151,204]
81	VRS-CZ1JD102J	AA		C	Resistor (1/16W 1.0K Ω ±5%)	[R205,243,244,253,268,279]
	VRS-CZ1JD103J	AA		С	Resistor (1/16W 10KΩ ±5%)	[R12,13,15,16,18,20,44,45]
	VRS-CZ1JD103J	AA		С	Resistor (1/16W 10K Ω ±5%)	[R60,61,62,70,72,73,86,91]
	VRS-CZ1JD103J	AA		С	Resistor (1/16W 10K Ω ±5%)	[R93,112,115,123,131,139]
	VRS-CZ1JD103J	AA		С	Resistor (1/16W 10KΩ ±5%)	[R144,154,158,159,160,163]
82	VRS-CZ1JD103J VRS-CZ1JD103J	AA		С	Resistor (1/16W 10KΩ ±5%)	[R165,167,168,203,207,208]
	VRS-CZ1JD103J	AA		C	Resistor (1/16W 10K Ω ±5%) Resistor (1/16W 10K Ω ±5%)	[R213,216,217,230,237,238] [R239,240,241,242,245,246]
	VRS-CZ1JD1030	AA		C	Resistor (1/16W 10K Ω ±5%)	[R249,254,259,260,261,263]
	VRS-CZ1JD103J	AA		C	Resistor (1/16W 10KΩ ±5%)	[R264,267,269,271,272,273]
	VRS-CZ1JD103J	AA		Č	Resistor (1/16W 10K Ω ±5%)	[R274,282,283,284,285]
83	VRS-CZ1JD183J	AA		С	Resistor (1/16W 18K Ω ±5%)	[R275,280]
	VRS-CZ1JD220J	AA		С	Resistor (1/16W 22Ω ±5%)	[R14,17,19,24,27,30,31,34]
84	VRS-CZ1JD220J	AA		С	Resistor (1/16W 22Ω ±5%)	[R35,37,39,40,43,46,51,54]
	VRS-CZ1JD220J	AA		С	Resistor (1/16W 22 Ω ±5%)	[R57,247,252]
85	VRS-CZ1JD221J	AA		С	Resistor (1/16W 220Ω ±5%)	[R403,404]
86	VRS-CZ1JD222J	AA		C	Resistor (1/16W 2.2KΩ ±5%)	[R199,200,209,210,211,212]
	VRS-CZ1JD222J VRS-CZ1JD330J	AA		С	Resistor (1/16W 2.2KΩ ±5%)	[R218,223,248,265,266,276]
	VRS-CZ1JD330J	AA		C	Resistor (1/16W $33\Omega \pm 5\%$) Resistor (1/16W $33\Omega \pm 5\%$)	[R25,38,41,47,48,52,56,58,66] [R67,68,69,92,117,138,142]
87		AA		C	Resistor (1/16W 33Ω ±5%)	[R143,147,148,152,153,173]
0,	VRS-CZ1JD330J	AA		C	Resistor (1/16W 33Ω ±5%)	[R174,175,176,187,188,]
	VRS-CZ1JD330J	AA		C	Resistor (1/16W 33 Ω ±5%)	[R214,288,289]
88	VRS-CZ1JD332J	AA		С	Resistor (1/16W 3.3KΩ ±5%)	[R215,119]
89	VRS-CZ1JD333J	AA		С	Resistor (1/16W 33K Ω ±5%)	[R179,107]
90	VRS-CZ1JD470J	AA		С	Resistor (1/16W 47 Ω ±5%)	[R53,55,308,309]
	VRS-CZ1JD472J	AA		С	Resistor (1/16W 4.7KΩ ±5%)	[R63,71,74,76,87,100,111,121]
91	VRS-CZ1JD472J	AA		С	Resistor (1/16W 4.7KΩ ±5%)	[R122,124,128,133,146,162,164]
	VRS-CZ1JD472J VRS-CZ1JD472J	AA		C	Resistor (1/16W 4.7KΩ ±5%)	[R184,206,221,224,226,227,228] [R231,250,251,262,270,277]
92	VRS-CZ1JD472J	AA		C	Resistor (1/16W 4.7K Ω ±5%) Resistor (1/16W 510 Ω ±5%)	[R231,250,251,262,270,277] [R278]
	VRS-CZ1JD750J	AA		C	Resistor (1/16W 75 Ω ±5%)	[R276] [R114,145]
	VRS-CZ1JD823J	AA		C	Resistor (1/16W 82KΩ ±5%)	[R202]
	VSDTC114EK/-1	AB		В	Transistor (DTC114EK)	[Q3]
	VSDTC114YK/-1	AC		В	Transistor (DTC114YK)	[Q4]
97	VSUPA502T//-1	AD		В	Transistor (UPA502T)	[Q5,6,7]
-						
—						
<u> </u>						
-						
1	+					

27 Exteriers[AR-EF1]


NO.	PARTS CODE	PRICE RANK	NEW MARK	PART RANK	DESCRIPTION
1	GCAB-0943FCZZ	AK	N	D	Rear lower cabinet
2	XHBSE40P08000	AA		С	Screw (4×8)
3	PCŌVP1566FCZZ	AS	N	D	Upper cabinet rear cover
4	L X - B Z 0 8 4 2 F C Z Z	AG		С	SPF screw
5	GCAB-0942FCZZ	AP	N	D	Upper cabinet rear
	L X - B Z 0 7 7 6 F C Z Z	AG		С	Screw R
7	GCAB-0945FCZZ	AR	N	D	Upper cabinet right
8	DUNT-7133DSZZ	CZ	N	Е	DSPF unit
_	DUNT-7132DSZZ	CY	N	Е	SPF unit
9	LFiX-0544FCZZ	AG	N	D	Glass fixing right
10	CGLSP0003RS51	ВС	N	В	Table glass (Japan)
	CGLSP0003RS52	BF	N	В	Table glass EX (Except Japan)
	XBTSC50P16000	AA		С	Screw (5×16)
	LFiX-0543FCZZ	AG	N	D	Glass fixing left
	CGLSP0102DS51	BF	N	В	White datum glass unit
	XHBSD30P06000	AA		С	Screw (3×6)
	XBTSE40P06000	AA		С	Screw (4×6)
	PGiDM1900FCZZ	AR	N	С	Delivery upper PG SPF
	PGiDM1901FCZZ	AQ	N	С	Delivery lower PG
	NRŌLP0011QSZZ	AD		С	Delivery support roller
	PSPŌ-0001QSZZ	AB		С	Sponge
	NSFTZ2601FCZZ	AH	N	С	Delivery support roller shaft 1
	MSPRC2865FCZ1	AB	N	С	Delivery support spring
	XEBSE30P08000	AA		С	Screw (3×8)
	PCŌVP1624FCZZ	AC	N	D	Stanp cover
	L X - B Z 0 4 6 5 F C Z Z	AA		С	Screw (4×6)
25	XHBSD30P08000	AA		С	Screw (3×8)
26	CPNLC0244DS51	CV	N	D	MFP operation panel (Japan)
	CPNLC0244DS52	СТ	N	D	MFP operation panel (Except Japan)
	LDAiU0627FCZZ	ΑZ	N	D	Operation base
	XEBSE40P08000	AA		С	Screw (4×8)
	PMLT-1256FCZZ	AC	N	С	Dustproof cushion 1
	PMLT-1257FCZZ	AB	N	С	Dustproof cushion 2
31	RCORF0041FCZZ	AH	N	С	Core (UFR25-12-15)



28 Original detect unit[AR-EF1]

NO.	PARTS CODE	PRICE RANK	NEW MARK	PART RANK	DESCRIPTION
1	MARMP0148FCZ2	AK	N	С	Original detect arm lower
2	XBPSD30P06KS0	AA		С	Screw (3×6KS)
3	LBSHZ1102CCZZ	AC		С	Rubber roller bushing 1
4	PSLDH0178FCZZ	AD		С	Original detect shield plate
5	NSFTZ1805FCZZ	ΑE		C	Original detect fulcrum shaft
6	XRESP30-06000	AA		С	E type ring
7	MSPRT1563FCZZ	AC		С	Original detect spring
8	LHLDZ1085FCZ2	AD	N	С	Original detect fulcrum TIG
9	CPWBF1453FCE1	BN	N	Е	ORS emission PWB
10	MARMP0147FCZ2	AK	N	С	Original detect arm upper
11	XEPSD30P05000	AA		С	Screw (3×5)
12	GCAB-0942FCZZ	AP	N	D	Upper cabinet rear
501	CARMP0147DS51	BA	N	Е	ORS emission unit


28 Original detect unit[AR-EF1]



29 Operation panel unit[AR-EF1]


NO.	PARTS CODE	PRICE RANK	NEW MARK	PART RANK	DESCRIPTION
1	CPWBN1471FCE1	BF	N	E	LVDS PWB
	MSPRP3009FCZZ	AD	N	C	LCD earth plate spring
_	XEPSD30P08000	AA	IN	C	
	CPWBF1470DS51	BN	N.	E	Screw (3×8)
		AD	N		Inverter PWB
	DHA: 01015077		N	С	INV interface harness
	DHA i - 3 1 9 1 F C Z Z	AF	N	С	ORS PD harness
	LHLDZ1459FCZZ	AE	N	С	LCD holder B
	V V L L M 0 6 5 H B 1 - 1	СВ	N	В	LCD mojule
	LHLDZ1458FCZZ	AF	N	С	LCD holder A
	HPNLH0246FCZZ	BF	N	D	Touch panel
	CPWBF1469FCE1	BN	N	Е	MFP OPE PWB
	CBTN-0253FC01	AN	N	Е	Change key Assy
	CBTN-0252FC01	AP	N	E	Ten key Assy
	CFiLW0284FC01	AF	N	D	C key smoke Assy
	CBTN-0251FC01	AF	N	E	C key Assy
	CFiLW0282FC01	AF	N	D	Copy key smoke Assy
17	CFiLW0283FC01	ΑF	N	D	CA key smoke Assy
	CBTN-0250FC01	AH	N	Е	Copy key Assy
19	HPNLC0244FCZZ	ΑZ	N	D	Operation panel A
20	CPNLC0245FC01	ΑY	N	D	Operation panel B (Japan)
20	CPNLC0245FC02	ΑY	N	D	Operation panel B EX-E (Except Japan)
21	LPiNS0014QSGZ	AC	N	С	Fixing pin C
22	DHA i - 3 1 9 3 F C Z Z	AC	N	С	Panel earth harness
24	PSHEZ4906FCZZ	AC	N	С	Touch panel sheet
25	QCNW-0166FCZZ	AE	N	С	LCD interface FFC


29 Operation panel unit[AR-EF1]



30 Optical unit 1[AR-EF1]


NO.	PARTS CODE	PRICE RANK	NEW MARK	PART RANK	DESCRIPTION
1	PCŌVP1599FCZZ	AG	N	D	Harness cover B
2	XHBSD30P04000	AA		С	Screw (3×4)
	LHLDW1115FCZZ	AD		С	Edge bushing
	QCNW-0168FCZZ	ΑE	N	C	CL interface FFC
	QCNW-0167FCZZ	AM	N	C	CCD interface FFC
	PCŌVP1600FCZZ	ΑF	N	D	Harness cover C
	PSHEP4932FCZZ	AD	N	C	Harness fixing sheet 4
	XBBSE30P06000	AA		С	Screw (3×6)
	LPLTM5723FCZZ	AG	N	C	SCN PWB fixing plate
11	XHBSE40P08000	AA		С	Screw (4×8)
	VHi28F081L02C	BB	N	В	Scanner flash unit
	CPWBN1450FCE1	BF	N	E	Scanner control PWB
	LHLDW1115FCZZ	AD		С	Edge bushing
	QCNW-0165FCZZ	AH	N	С	MFPOP interface FFC
	QCNW-0181FCZZ	AH	N	С	LVDS interface FFC
	XBBSD40P06000	AA		С	Screw (4×6)
	CPWBN1451DS51	BF	N	Е	Scanner interface PWB
	DHA i - 3 1 5 2 F C Z Z	AF	N	С	Stanp interface harness
	LPLTM5720FCZZ	AK	N	С	OC fixing plate
	LPLTM5927FCZZ	AF	N	С	Dry heater fixing plate
	LPLTM5877FCZZ	ΑE	N	С	Base rainforce plate
	XHBSD30P06000	AA		С	Screw (3×6)
	PCŌVP1598FCZZ	AL	N	D	Harness cover A
	PSHEZ4842FCZZ	AD	N	С	Harness fixing sheet 2
	DHA i - 3 3 0 3 F C Z Z	ВС	N	С	MFP interface cable
	PGUMS0283FCZ1	AA	N	С	Table glass cushion
	LDAiU0610FCZZ	ΑE		D	Harness fixing base
	LRALM0183FCZZ	AG	N	С	MB-B rail F
	PSHEZ4843FCZZ	AC	N	С	Harness fixing sheet 3
	LHLDW1007LCZZ	AD		С	Mini clamp (MN-1)
	LHLDW0595FCZZ	AC		С	Edge holder (EDS2)
	LHLDW1264FCZZ	AD		С	Wire holder (LWS-8S-2.5W)
	L B N D J O O 4 3 F C Z Z	AA		С	Snap band (SG-130)
	DHA i - 3 1 5 3 F C Z Z	AC	N	С	PNC harness
	LFiX-0537FCZZ	AD		С	Harness fixing plate
	PSHEZ4841FCZ1	AD	N	С	Harness fixing sheet 1
	LRALM0184FCZZ	AG	N	С	MB-B rail R
	L X - B Z 0 0 0 4 Q S Z Z	AB		С	Screw
	PSHEZ4836FCZZ	AB	N	С	Screw protect sheet
	LPLTP5960FCZZ	AE	N	С	SCN cable fixing plate
	L H L D W 1 2 0 1 C C Z Z	AA		С	SK holder
	LFiX-0569FCZZ	AD	N	С	SCN fixing cable
47	PMLT-1282FCZZ	ΑE	N	С	FFC fixing cushion





31 Optical unit 2[AR-EF1]


<u> </u>	<u> </u>	Optical unit 2[AR-E				
	NO.	PARTS CODE	PRICE	NEW	PART	DESCRIPTION
٨		CDA i U 0 6 1 9 D S 5 1	RANK BF	MARK		
⚠		LHLDZ1505FCZZ	AC	N N	E C	Lamp unit Wire holder
H		XBBSD40P06000	AA	IN	C	Screw (4×6)
H		LBSHC0161FCZZ	AB		C	Bushing
F		CCOVP1541FC02	AT	N	D	Dark box Assy
H		XHBSD30P04000	AA	IN	C	Screw (3×4)
H		PCUSU0203FCZZ	AE		C	Protection cushion
F		PG i DM1890FCZZ	AC	N	C	CL guide
F		NPLYZ0399FCZZ	AG	N	C	W pulley T
H		XBPSD40P06KS0	AA	IN	C	Screw (4×6KS)
F		LF i X - 0 2 8 4 F C Z Z	AC		C	2nd,3rd mirror fixing plate F
F		PM i R - 0 1 6 5 F C Z Z	AP	N	В	2nd,3rd mirror lixing plate F
F		MSL i - 0 1 3 8 F C Z Z	AC	IN	С	Slider
F		PW i R - 0 1 9 2 F C Z Z	AQ	N	В	MB wire F
F	17	PW i R - 0 1 9 1 F C Z Z	AQ	N	В	MB wire R
F		NBLTH0329FCZZ	AG	N	В	Winding drive belt
F		L X - B Z O O 4 9 F C Z Z	AB	IN	C	Screw
H		NPLYZ0338FCZZ	AN		C	Pulley (36T)
H		XRESP70-08000	AA		C	E type ring
		L X - B Z 0 3 2 4 F C Z Z	AA		C	Screw
ŀ		NPLYZ0013QSZZ	AL		C	Winding pully PAN
ŀ		NPLYZ0013Q3ZZ	AG		C	Pulley
ŀ		NSFTZ2586FCZZ	AS	N	C	Winding drive shaft
ŀ		NPLYZ0006QSZZ	AD	IN	C	L pulley
ŀ	20	RMŌTS0857FCZZ	AZ	N	В	Scanner motor
ŀ		XBPSD30P05K00	AA	IN	С	Screw (3×5K)
ŀ		XBPSD40P16KS0	AA		C	Screw (4×16KS)
ŀ		MSPRT2846FCZZ	AC	N	C	
ŀ		CPLTM5719FC01	AG	N N	C	Belt tenshion spring Mirror motor fixing plate
ŀ		PGUMS0002QSZZ	AL	IN	C	Protection rubber
F		NGERH0027QSZZ	AH		C	Mirror motor idle gear
F		XRESP70-08000	AA		C	
H		L X - W Z O 1 1 9 F C Z Z	AA		C	E type ring Washer
F		VHPGP3A38//-1	AH		В	Photo transistor (GP3A38)
F		XBBSD40P14000	AA		С	Screw (4×14)
F		VHPGP1A22LC-1	AK		В	Photo interupter (GP1A22LC)
F		XBBSD40P10000	AA		С	Screw (4×10)
F		DHA i - 3 1 5 0 F C Z Z	AD	N	C	MHPS interface harness
H		CPLTM0031RS51	BS	N	E	CCD unit
F		NBRGC0133FCZ1	AC	IN	C	PF bearing (M8)
F		XRESP40-05000	AA		C	
-		LHLDZ1381FCZZ	AL		C	E type ring ORS PWB holder
		CPWBF1454FCE1	BN	N	E	ORS PD PWB
		XHBSD40P06000	AA	IN	C	Screw (4×6)
H		XEPSD40P06000	AA		C	Screw (4×6)
H		XHBSD30P06000	AA		C	Screw (3×6)
F		MSPRD3020FCZ1	AG	N	C	Wire stopper spring
ŀ		PG i DM 1 9 6 4 F C Z Z	AC	N	C	Rack adjusting guide
F		CHLDZ1446FC31	BC	N	E	2,3 Mirror unit
		CSFTZ2586FC31	AZ	N	E	Winder drive shaft unit
F	002					Trindor divo didit dint
ŀ						
ı						
ı						
ľ						
ı						
ı						
ı						
ŀ						
ľ						
ı						
ı						
Ī						
Ī						
Ī						
Ī						
-					1	



32 Lamp unit[AR-EF1]

	NO.	PARTS CODE	PRICE RANK	NEW MARK	PART RANK	DESCRIPTION
\triangle		RLMPD0658FCZZ	BA	Ν	В	Lamp
		XEBSD30P08000	AA		С	Screw (3×8)
	-	PREFL0172FCZZ	AK		В	Reflector
		XBBSD30P12000	AA		С	Screw (3×12)
		LDAiU0619FCZZ	ΑT	N	С	Lamp base
	6	PCUSU0203FCZZ	ΑE		С	Protection cushion
	7	QCNW-0168FCZZ	ΑE	N	С	CL interface FFC
	8	MSL i - 0 1 3 8 F C Z Z	AC		С	Slider
	9	CPWBF1449FC31	BH	N	Е	Inverter PWB
		PCUSF0334FCZZ	AP		C	Mirror cushion
		LSTYM0261FCZZ	AB	Ν	C	Wire support plate
		LFiX-0545FCZZ	AC	Ν	С	CL read harness fixing
		PM i R - 0 1 6 4 F C Z Z	AP	N	В	1st mirror
	14	MSPRP2825FCZZ	AC	N	С	Mirror spring
	15	TLABZ4335FCZZ	AB		D	HV caution label
		(Unit)				
\triangle	901	CDA i U 0 6 1 9 D S 5 1	BF	N	Е	Lamp unit
L						

32 Lamp unit[AR-EF1]




33 DSPF Assembly section[AR-EF1]

	Joi i Assembly se				
NO.	PARTS CODE	PRICE RANK	NEW MARK	PART RANK	DESCRIPTION
1	PSHEZ4845FCZZ	ΑV	N	С	OC mat
2	PMLT-1286FCZZ	AD	N	С	OC cushion
	PCŌVP1595FCZZ	AG	N	D	Rack cover
4	XHBSE30P06000	AA		С	Screw (3×6)
5	PCŌVP1615FCZZ	ΑE	N	D	Length detect cover N
6	XEBSE40P10000	AA		С	Screw (4×10)
	MHNG-0208FCZZ	BA	N	С	SPF hinge R
9	PCŌVP1518FCZZ	ΑE		D	ICU ROM cover
10	LPLTM5887FCZZ	ΑL	N	С	Hinge joint plate
11	XHBSE40P08000	AA		С	Screw (4×8)
12	LFiX-0568FCZZ	AC	N	С	Original detect fixing
13	PTPE-0265FCZZ	AC	N	С	Cover tape
14	PCŌVP1644FCZZ	AD	N	С	F cover L
15	PGUMS0298FCZZ	AC	N	С	Cover rubber L
16	CPWBF1501DS51	BN	N	Е	SPF VR PWB
17		AF		С	Width detect fixing plate
18	XEBSD30P08000	AA		С	Screw (3×8)
19	MSPRP2830FCZZ	AA		С	Width detect spring
20	PGUMS0296FCZZ	AD	N	С	Cushion
21	NGERR1386FCZZ	ΑE		С	Width detect rack
22	NGERP1385FCZZ	AF		С	Width detect pinion
	XEPSD30P06X00	AA		С	Screw (3×6X)
	PCŌVP1645FCZZ	AH	N	С	F cover R
25	PGUMS0299FCZZ	AH	N	С	Cover rubber R
26	CPWBF1459DS51	BN	N	Е	SPF PWB

33 DSPF Assembly section[AR-EF1]


	· · · · · · · · · · · · · · · · · · ·					$\overline{}$
NO.	PARTS CODE	PRICE RANK	NEW MARK	PART RANK	DESCRIPTION	
	DHA i - 3 1 6 6 F C Z Z	AY	N	С	DSPF body interface harness	
	XESSE30P08000	AA		С	Screw (3×8)	
	DHA i - 3 1 6 1 F C Z Z	AK	N	С	SPF size detect harness	
	XEBSE30P10000	AA		С	Screw (3×10)	
	VHPGP1A73A+-1	AG		В	Photo sensor (GP1A73A)	
34	MLEVP0794FCZZ	AC	N	С	Length detect actuator	
35	XEBSD40P16000	AA		С	Screw (4×16)	
37	LPLTP5778FCZZ	AG	N	D	Adjust plate R	
38	LPLTP5777FCZZ	AG	N	D	Adjust plate F	
	PCŌVP1549FCZZ	ΑU	N	D	Upper cover	
	XEBSE30P08000	AA		С	Screw (3×8)	
41	MARMP0243FCZZ	AD		С	Manual feeding tray arm	
42	PRNGP0090FCZZ	AA		С	Ring (E5)	
43	LPLTM2573FCZ1	AD		С	ADF MG plate	
44	LPLTP5938FCZZ	AC	N	С	Shading plate N	
45	TLABH4440FCZZ	ΑF		D	Original read label (Japa	an)

33 DSPF Assembly section[AR-EF1]



34 DSPF Paper feed unit[AR-EF1]


34	DSPF Paper feed u				
NO.	PARTS CODE	PRICE RANK	NEW MARK	PART RANK	DESCRIPTION
1	PCŌVP1594FCZZ	AG	N	D	Roller cover
	XHBSE30P06000	AA	- 11	C	Screw (3×6)
	PMLT-1272FCZZ	AB	N	С	Damper cushion 3
	PGiDM1953FCZZ	AS	N	С	Paper feed PG SPF
	PSHEP4915FCZZ	AE	N	С	PS rear mylar
	PCLR-0471FCZZ	AG AM	N	С	PS support roller
	NSFTZ2600FCZZ MSPRP2878FCZZ	AC	N N	C	PS support shaft PS support plate spring
	XEBSD30P08000	AA	IN	C	Screw (3x8)
	NSFTZ2599FCZ1	AW	N	C	Separate roller shaft SPF
11	XRESP40-06000	AA		C	E type ring
	NBRGC0136FCZZ	AC		С	Bearing (M6)
	LHLDZ1483FCZZ	AF		С	Paper feed rotation plate
	PCLC-0303FCZZ NSFTZ2678FCZZ	AT AL	N N	B C	Separate clutch
	NPLYZ0398FCZZ	AC	IN	C	Pick up shaft Pick up roller pulley (22P)
	NBRGM0096FCZ1	AB		C	Bearing
	NBLTH0363FCZZ	AG	N	В	Belt (S2M120)
	NRŌLR1312FCZZ	AN		С	Pick up roller
	NPLYZ0397FCZZ	AK		С	Paper feed roller pulley (28P)
	NRŌLR1317FCZZ	AP		С	Separate roller
	PCLC-0302FCZZ LPLTM5928FCZZ	AT AG	N N	B C	PS clutch SPF Paper feed base plate SPF
	XBBSD30P06000	AA	IN	C	Screw (3×6)
	RPLU-0336FCZZ	AS	N	В	Pick up solenoid
26	MARMP0284FCZZ	AC	N	C	Pick up joint arm N
	XRESP50-06000	AA		С	E type ring
	NRŌLP1364FCZZ	AC		С	Delivery roller M
	XRESP70-08000	AA	N.	С	E type ring
	NRŌLR1318FCZZ LSTYM0288FCZZ	AR AK	N N	C	PS roller SPF CIS stay
	L H L D Z 1 4 8 5 F C Z Z	AC	N	C	SP holder F
	MSPRD3002FCZZ	AC	N	C	Spring N
	MHNG-0209FCZZ	ВС	N	С	DSPF hinge L
	RMŌTS0876FCZZ	BD	N	В	SPF motor N
	LFRM-1022FCZZ	AK	N	D	Drive frame
	NGERH1477FCZZ	AC	N	С	Gear (24T)
	PSHEZ4949FCZZ MSPRP3011FCZZ	AE AC	N N	C	Motor sheet
	LHLDW1009ACZZ	AA	IN	C	Earth plate spring Clamp
	XHBSE40P08000	AA		C	Screw (4×8)
	NGERH1476FCZZ	AD	N	C	Gear (35T/18T)
	NGERH1478FCZZ	AE	N	С	Gear (55T/28T/18P)
	NBLTH0364FCZZ	AG	N	В	Belt (S2M130)
	L H L D Z 1 4 8 6 F C Z Z N P L Y Z 0 3 7 5 F C Z Z	AC AC	N	C	SP holder R
	CPLTM5882FC02	AN	N	O	Pulley (22T) Drive plate
	LPINS1031HCZZ	AA	IN	C	Spring pin
	PCLR-0426FCZZ	AD		C	Slide roller
50	NRŌLR1320FCZZ	AQ	N	С	Delivery roller SPF
	LPLTM5884FCZZ	AW	N	С	Base tray reinforce plate N
	L H L D W O 4 2 9 F C Z Z	AB		С	Wire holder (WS-2NS)
	LPLTM5785FCZZ	AC	N	С	MG plate
	XRESP20-04000 PMLT-1270FCZZ	AA AB	N	C	E type ring Damper cushion 1
	JKNBZ0141FCZZ	AH	N	0	Jam release knob
	LPLTM5889FCZZ	AC	N	C	Datum plate
58	PSHEP4846FCZZ	AD	N	С	OC mat mylar R
	LHLDW2101SCZZ	AB		С	Cable clamp
	L H L D W 1 0 0 9 A C Z Z	AA		С	Clamp
	LPLTM5929FCZZ	AR	N	С	Delivery roller fixing plate
	DHA i - 3 2 8 1 F C Z Z Q S W - Z 0 5 3 1 F C Z Z	AH AL	N	C B	SPF delivery sensor harness Delivery jam sensor
	PCUSS0372FCZZ	AD	N	С	CIS cushion 1
	LSTPP0359FCZZ	AE	N	C	PS fornt stopper
66	XHBSD30P14000	AA		С	Screw (3×14)
	LHLDZ1484FCZZ	AC	N	С	Open/close holder
	VHPGP1A73A+-1	AG		В	Photo sensor (GP1A73A)
	MSPRC3001FCZZ	AB	N	С	Open/close detect spring N
	MLEVP0837FCZZ XHBSE30P10000	AC	N	C	Open/close actuator N Screw (3x10)
72	PCUSS0373FCZZ	AB	N	C	CIS cushion 2
73	PSHEP4916FCZ1	AF	N	C	White mylar
74	PGiDH1897FCZZ	ΑT	N	С	CIS paper guide
	PGLSP0103FCZZ	AV	N	С	CIS glass
	LX-BZ0931FCZZ	AC	N	С	Screw (M3)
	PBRSS0209FCZZ	AG	N	В	Discharger blass SPF
	P S H E Z 4 9 5 7 F C Z Z D H A i - 3 3 3 6 F C Z Z	AC AB	N N	C	Delivery sheet ESD harness DSPF
19	DIAI 3330FUZZ	A D	IN	U	LOD HAIHESS DOFT
	1	1	1		



35 DSPF Upper transfer unit[AR-EF1]

NO.	PARTS CODE	PRICE RANK		PART RANK	DESCRIPTION
1	LPLTM5891FCZZ	ΑE	N	С	Upper delivery rainforce plate
2	PMLT-1272FCZZ	AB	N	С	Damper cushion 3
3	LSTPP0353FCZZ	ΑE	N	С	Original stopper
5	LPLTM5930FCZZ	AD	N	С	Separate pad rainforce plate
6	XEBSD30P08000	AA		С	Screw (3×8)
7	CPLTM5746FC01	ΑE	N	С	Separate pad fixing plate AS
	LPLTP5747FCZZ	AC	N	С	Separate plate
	MSPRT2864FCZZ	AC	N	С	Pressure spring
	VHPGP1A73A+-1	AG		В	Photo sensor (GP1A73A)
	PMAGT0072FCZZ	AF		С	Magnet catch
	RPLU-0347FCZZ	AQ	N	В	Gate solenoid
	DHA i - 3 1 6 2 F C Z Z	AK	N	С	SPF paper feed harness
	MLEVP0796FCZZ	AC	N	С	Set detect actuator
	MARMP0248FCZZ	ΑE		С	MF gate joint arm
	MLEVP0804FCZZ	AC	N	С	Stopper lever
	MSPRP2832FCZZ	AC	N	С	Separate assistance plate spring
	PSHEZ4878FCZZ	AC	N	С	Separate mylar upper
	PSHEZ4847FCZZ	ΑL	N	С	Separate sheet
20	PSHEP4848FCZZ	AB	N	С	Separate mylar lower
	LSTPP0314FCZZ	AA		С	E3 stopper
	MSPRD2870FCZ1	AC	N	С	Stopper spring
	NSFTZ2659FCZZ	AR	N	С	Fulcrum shaft
	LPLTM5932FCZZ	AC		С	Tray 2 sensor fixing plate
	XEBSE40P10000	AA		С	Screw (4×10)
	MLEVP0797FCZZ	AC	N	С	PS front actuator
	MSPRD2879FCZZ	AB	N	С	PS front actuator spring
	PMLT-1271FCZZ	AB	N	С	Damper cushion 2
	PSHEP4937FCZZ	AB	N	С	Fixing mylar
	PGiDM1899FCZZ	AY	N	С	Upper delivery PG
	MSPRT2863FCZZ	AB	N	С	Paper feed plate spring
32	LPLTP5748FCZZ	AD	N	С	Paper feed plate
	XHBSE30P06000	AA		С	Screw (3×6)
35	XBBS230P10000	AA		С	Screw (3×10)
<u> </u>					


35 DSPF Upper transfor unit[AR-EF1]



36 DSPF CIS unit[AR-EF1]

NO.	PARTS CODE	PRICE RANK	NEW MARK	PART RANK	DESCRIPTION
1	CPWBN1458FCE1	BF	N	Е	CIS control PWB
	XBBSD30P06000	AA		С	Screw (3×6)
3	PCŌVP1593FCZZ	ΑF	N	D	CIS PWB cover N
4	DUNT-7079FCZZ	CC	N	Е	CIS unit
5	L X - B Z 0 6 8 0 F C Z Z	AB		С	Screw
6	QCNW-0170FCZZ	AH	N	С	CIS interface FFC
7	XBBSD40P08000	AA		С	Screw (4×8)
8	PMLT-1284FCZZ	ΑE	N	С	Interface FFC fixing cushion


36 DSPF CIS unit[AR-EF1]



37 Packing Material & Accessories[AR-EF1]

					-
NO.	PARTS CODE	PRICE RANK	NEW MARK	PART RANK	DESCRIPTION
1	SPAKA6075DSZZ	AA	N	D	RSPF protect sheet 1
0	LSŌU-0177FCGZ	AP		D	Delivery tray T
2	L S O U - 0 1 7 9 F C Z Z	AR		D	Delivery tray 1
3	SPAKA0307QSZZ	AD		D	Protect sheet FN5
4	TCADZ1178FCZZ	AB		D	Screw caution card
5	L X - B Z 0 7 8 7 F C Z Z	AH		С	Screw for 2/3 mirror lock
6	SPAKA6132FCZZ	ΑT	N	D	Packing add upper EF1
7	SSAKZ0003QSZZ	AF		D	Body vinyl bag
8	SPAKA6133FCZZ	ΑU	N	D	Packing add botom EF1
_	SPAKC6131DSZZ	AF	N	D	Packing case (Japan)
9	SPAKC6131DS11	ΑF	N	D	Packing case (Except Japan)
10	SPAKA6265FCZZ	AC	N	D	Fusing protect add

37 Packing Material & Accessories[AR-EF1]



38 MFP OPE PWB[AR-EF1]

	<u> </u>					
NO.	PARTS CODE	PRICE RANK	NEW MARK	PART RANK	С	DESCRIPTION
1	QCNCM1171FCZZ	ΑE	N	С	Connector (6pin)	[CN2]
2	QCNCW1134FCZZ	AH		С	Connector (24pin)	[CN1]
	QSW-P0005QSZZ	AC		В	Tact switch (B3F-6102)	[PRK,FAK,COK,JOK,CUK,1K,2K]
3	QSW-P0005QSZZ	AC		В	Tact switch (B3F-6102)	[3K,4K,5K,6K,7K,8K,9K]
	QSW-P0005QSZZ	AC		В	Tact switch (B3F-6102)	[*K,K,#K,CLK,CAK,PSW]
4	RALMB1002LCZZ	ΑE		В	Alarm (PKM13EPY-4000-TF01)	[BZ1]
5	RC-KZ0008QCZZ	AB	N	С	Capacitor (UP050F ZABZ)	[C6]
	RCRS-0007FCZZ	AD		В	Crystal (CSB480EB)	[X1]
	RH-DZ0016FCZZ	AB		В	Diode (MA700)	[D1]
	VCEAJU1CW476M	AB		С	Capacitor (16WV 47μF)	[C1]
9	VCKYPU1EB223Z	AB		С	Capacitor (25WV 0.022µF)	[C2,3]
10	VCKYPU1HB101K	AA		С	Capacitor (50WV 100PF)	[C4,5]
11	VHD1SS133//-1	AA		В	Diode (1SS133)	[D2,3]
12	VH i S 1 3 4 0 A F + - 1	AH		В	IC (S1340AF)	[IC1]
13	VHP1LHLE-002A	AC		В	LED(Green) (LTL-1LHLE-002A)	[PRT,FAX,COPY,JOB,PONL]
13	VHP1LHLE-002A	AC		В	LED(Green) (LTL-1LHLE-002A)	[PDATA,FCM,FDATA]
14	VHPLT9400E/-1	AK		В	LED (LT9400E)	[RPL]
	VRD-HT2EY101J	AA		С	Resistor (1/4W 100Ω ±5%)	[R1]
	VRD-HT2EY102J	AA		С	Resistor (1/4W 1.0KΩ ±5%)	[R8]
17	VRD-HT2EY302J	AA		С	Resistor (1/4W 3.0KΩ ±5%)	[R2]
18	VRD-HT2EY331J	AA		С	Resistor (1/4W 330Ω ±5%)	[R3]
	VRD-HT2EY471J	AA		С	Resistor (1/4W 470Ω ±5%)	[R4,5,6,7]
20	VS2SC1740SR-1	AB		В	Transistor (2SC1740SR)	[Q2]
21	VSDTC114YS/-1	AB		В	Transistor (DTC114YS)	[Q1]
	(Unit)					
901	CPWBF1469FCE1	BN	N	E	MFP OPE PWB	

39 Scanner control PWB[AR-EF1]

NO.	PARTS CODE	PRICE RANK	NEW MARK	PART RANK		DESCRIPTION
1	QCNCM0828FCZZ	ΑE		С	Connector (26pin)	[CN13]
2	QCNCM0829FCZZ	AG		C	Connector (28pin)	[CN12]
3	QCNCM1166FCZZ	AK	N	С	Connector (20pin)	[CN18]
4	QCNCM1167FCZZ	AP	N	С	Connector (50pin)	[CN19]
5	QCNCM7014SC1C	AC		С	Connector (13pin)	[CN5]
6	QCNCM7022SC0C	AB		С	Connector (3pin)	[CN10]
	QCNCM7022SC0E	AB		С	Connector (5pin)	[CN6]
	QCNCM7022SC0F	AB		С	Connector (6pin)	[CN7]
	QCNCW0885FCZZ	AG		С	Connector (12pin)	[CN14]
10	QCNCW7040XC8J	AP		С	Connector (80pin)	[CN16]
11	QSŌCZ0002QSZZ	AD		С	IC socket (8pin)	[IC13]
	QSŌCZ0071FCZZ	AP		С	Socket (72pin)	[SOCKET1]
	QSŌCZ6428ACZZ	ΑE		С	IC socket (28pin)	[IC14]
	RCRMZ6007RCZZ	AD		В	Resonator (4.19MHz)	[X1]
15	RCRSZ0001QSZZ	AG		В	Crystal (19.6608MHz)	[X2]
	RFiLN0049FCZZ	ΑE	N	С	Filter	[NF5,NF6,NF7,NF8,NF9,NF10]
	RFiLN6012RCZZ	AB		С	EMI filter	[NF1,NF4]
	RFiLZ1005LCZZ	AB		С	EMI filter	[NF3]
19	RH-iX2196SCZZ	AG		В	Regulator	[IC5]
	RMPTR4103ACZZ	AB		В	Block resistor (10KΩ×4)	[BR9,BR3,BR4,BR7,BR8,BR10]
	RMPTR4103ACZZ	AB		В	Block resistor (10KΩ×4)	[BR12,BR11,BR6,BR13,BR14,BR15]
20	RMPTR4103ACZZ	AB		В	Block resistor (10KΩ×4)	[BR16,BR17,BR18,BR20,BR21,BR22]
	RMPTR4103ACZZ	AB		В	Block resistor (10KΩ×4)	[BR23,BR24,BR25,BR26,BR27,BR28]
	RMPTR4103ACZZ	AB		В	Block resistor (10KΩ×4)	[BR29,BR30,BR5,BR19,BR1]
	VCCCCZ1HH220J	AA		С	Capacitor (50WV 22pF)	[C58,C60]
	VCEAGA1AW476M	AA		С	Capacitor (10WV 47µF)	[C46,C36]
	VCEAGA1AW477M	AB		С	Capacitor (10WV 470μF)	[C20,C24]
	VCEAGA1CW477M	AB		С	Capacitor (16WV 470μF)	[C10]
	VCEAGA1HW224M	AA		С	Capacitor (50WV 0.22µF)	[C73,C74]
	VCEAGA1VW476M	AB		С	Capacitor (35WV 47uF)	[C63]
	VCEAZU1VW477M	AD		С	Capacitor (35WV 470μF)	[C16]
28	VCKYCZ1CB103K	AA		С	Capacitor (16WV 0.010μF)	[C76,C77,C78,C80]
	VCKYCZ1EF223Z	AA		С	Capacitor (25WV 0.022μF)	[C1,C11,C13,C14,C22,C23]
	VCKYCZ1EF223Z	AA		С	Capacitor (25WV 0.022μF)	[C26,C19,C12,C37,C40,C41]
29		AA		С	Capacitor (25WV 0.022µF)	[C42,C47,C48,C49,C51,C57]
	VCKYCZ1EF223Z	AA		С	Capacitor (25WV 0.022μF)	[C59,C61,C65,C66,C67,C68]
	VCKYCZ1EF223Z	AA		С	Capacitor (25WV 0.022μF)	[C69,C71,C72,C21,C35,C50,C82]
	VCKYCZ1HB102K	AA		С	Capacitor (50WV 1000pF)	[C2,C3,C4,C5,C6,C7]
30	VCKYCZ1HB102K	AA		С	Capacitor (50WV 1000pF)	[C8,C9,C25,C27,C28,C29]
30	VCKYCZ1HB102K	AA		С	Capacitor (50WV 1000pF)	[C30,C31,C32,C33,C34,C39]
	VCKYCZ1HB102K	AA		С	Capacitor (50WV 1000pF)	[C43,C44,C53,C64,C75,C79,C84]
	VCKYCZ1HB222K	AA		С	Capacitor (50WV 2200pF)	[C45,C54,C55,C62]
	VCKYCZ1HF103Z	AA		С	Capacitor (50WV 0.01μF)	[C15,C18,C70,C81,C83]
33	VCQYNA1HM103K	AA		С	Capacitor (50WV 0.01μF)	[C56]
34	V H D D A N 2 0 2 K / - 1	AB		В	Diode (DAN202K)	[D1,D3,D4,D18,D19,D20]
	V H D D A N 2 0 2 K / - 1	AB		В	Diode (DAN202K)	[D22,D23,D15,D14]

39 Scanner control PWB[AR-EF1]

NO.	PARTS CODE	PRICE RANK	NEW MARK	PART RANK		DESCRIPTION
35	VHDDAP202K/-1	AB		В	Diode (DAP202K)	[D5,D16,D17,D24,D25,D26
35	VHDDAP202K/-1	AB		В	Diode (DAP202K)	[D13,D12
36	VHDDSM1D1//-1	AB		В	Diode (DSM1D1)	[D21,D6
37	V H D M 1 F L 2 0 U + - 1	AC	N	В	Diode (M1FL20U)	[D8,D9,D10,D11
	VHDMA704A//-1	AC		В	Diode (MA704A)	[D2
	VHEHZS3B3//-1	AB		В	Zener diode (HZS3B3)	[D7
	VH i 7 4 VHC 0 4 M - 1	ΑE	N	В	IC (74VHC04M)	[IC8,IC18
	VH i 7 4 VHC 3 2 M - 1	AD	N	В	IC (74VHC32M)	[ICe
	VH i 9 0 L V 1 7 A W - 1	AP		В	IC (90LV17AW)	[IC2 ⁻
	VHiD65943GJ-1	AY	N	В	IC (D65943GJ)	[IC
	VHIEES04L400P	AG		В	IC (EES04L400P)	[IC1:
	VH i H 8 S 2 3 2 2 R - 1	AZ		В	IC (H8S2322R)	[IC1
	VH i HN 5 8 V 6 5 A - 1	AW		В	IC (HN58V65A)	[IC14
	V H i L M 3 2 4 D + + - 1	AE		В	IC (LM324D)	[IC
	VH i LM3 3 9 D + + - 1	AE		В	IC (LM339D)	[IC10
	VH i L V 2 5 6 1 2 J - 1	AQ		В	IC (LV25612J)	[IC19
	VH i MTD 1 3 6 1 F - 1	AR		В	IC (MTD1361F)	[10]
	VHiTD62003AP1 VHiTD62503F/-	AG AG		В	IC (TD62003AP1)	[IC4,IC15,IC2
	VH i VHC 2 4 4 S J - 1		N.	В	IC (TD62503F)	[IC12,IC1]
	VRD-HT2EY163J	AG	N	B C	IC (VHC244SJ)	[IC2,IC:
	VRD-HT2EY911J	AA		C	Resistor (1/4W 16K Ω ±5%) Resistor (1/4W 910 Ω ±5%)	
	VRS-CZ1JD000J	AA		C	Resistor (1/16W $0\Omega \pm 5\%$)	[R3
	VRS-CZ1JD101J	AA		C	Resistor (1/16W 022 $\pm 5\%$)	
	VRS-CZ1JD1013	AA		C	Resistor (1/16W 1.0KΩ ±5%)	[R7,R21,R47,R5
	VRS-CZ1JD1025	AA		C	Resistor (1/16W 1.0K Ω ±1%)	[R46.R
33	VRS-CZ1JD103J	AA		C	Resistor (1/16W 10KΩ ±5%)	[R5,R31,R29,R3,R6,R2
60		AA		C	Resistor (1/16W 10KΩ ±5%)	[R24,R25,R30,R41,R4,R5]
00	VRS-CZ1JD103J	AA		C	Resistor (1/16W 10KΩ ±5%)	[R28.R6:
61	VRS-CZ1JD122J	AA		C	Resistor (1/16W 1.2K Ω ±5%)	[R16,R13,R19,R33,R52,R5
62	VRS-CZ1JD151J	AA		C	Resistor (1/16W 150Ω ±5%)	[R2
	VRS-CZ1JD203J	AA		Č	Resistor (1/16W 20KΩ ±5%)	[R48,R59,R62,R6
	VRS-CZ1JD222J	AA		C	Resistor (1/16W 2.2K Ω ±5%)	[R12,R14,R15,R17,R18,R3
64	VRS-CZ1JD222J	AA		C	Resistor (1/16W 2.2K Ω ±5%)	[R54,R1
65	VRS-CZ1JD303F	AA		C	Resistor (1/16W 30KΩ ±1%)	[R
	VRS-CZ1JD303J	AA	N	Č	Resistor (1/16W 30KΩ ±5%)	[R5:
	VRS-CZ1JD561J	AA		Č	Resistor (1/16W 560Ω ±5%)	[R3
	VRS-CZ1JD562J	AA		C	Resistor (1/16W 5.6KΩ ±5%)	[R57,R58,R60,R61,R63,R6
69	VRS-CZ1JD621J	AA		C	Resistor (1/16W 620Ω ±5%)	[R3
70	VRS-CZ1JD624J	AA	N	С	Resistor (1/16W 620KΩ ±5%)	[R2
71	VRS-CZ1JD681J	AA		С	Resistor (1/16W 680Ω ±5%)	
72	VRS-CZ1JD752J	AA		С	Resistor (1/16W 7.5KΩ ±5%)	[R26,R43,R4
73	VRS-CZ1JD911J	AA	N	С	Resistor (1/16W 910Ω ±5%)	[R38,R3
74	VRS-RE3DA1R0J	AB		С	Resistor (2W 1.0Ω ±5%)	[R20,R42
75	VS2SB1197//-1	AC		В	Transistor (2SB1197)	[Q8,Q9,Q10
	VS2SK3065++-1	AG	N	В	Transistor (2SK3065)	[Q1:
	VSDTA114YK/-1	AC		В	Transistor (DTA114YK)	[Q2,Q3,Q6
78	VSDTC114YK/-1	AC		В	Transistor (DTC114YK)	[Q4,Q5,Q
79	VSUPA502T//-1	AD		В	Transistor (UPA502T)	[Q
	(Unit)					
901	CPWBN1450FCE1	BF	N	Е	Scanner control PWB	
			1			

40 CIS Control PWB[AR-EF1]

	5.6 66					
NO.	PARTS CODE	PRICE RANK	NEW MARK	PART RANK	DESCRIPTION	
1	QCNCM0880FCZZ	AF		С	Connector (26pin)	[CN100]
2	QCNCM0923FC12	ΑE		С	Connector (12pin)	[CN1]
3	QCNCW1160FCZZ	AD	N	С	Connector (FFC9604S35F)	[CN2]
4	RFiLN6012RCZZ	AB		С	EMI filter (E103)	[NF2,11]
5	RFiLZ1005LCZZ	AB		С	EMI filter (EXC-EMT103DT)	[NF100,4,10,12,13]
	VCCCCZ1HH101J	AA		С	Capacitor (50WV 100pF)	[C4,5,8,9,10,11,22]
6	VCCCCZ1HH101J	AA		С	Capacitor (50WV 100pF)	[C23,24,25,31,32,33,34]
	VCCCCZ1HH101J	AA		С	Capacitor (50WV 100pF)	[C40,48,49,51,52,53,60,61,62]
7	VCEAYU1EC476M	AC	N	С	Capacitor (25WV 47μF)	[C3,15,26,28,41,54]
8	VCEAYU1VC476M	AC	N	С	Capacitor (25WV 47μF)	[C18]
	VCKYCZ1CF104Z	AB		С	Capacitor (35WV 0.10µF)	[C100,1,2,7,12,13,17,27]
	VCKYCZ1CF104Z	AB		С	Capacitor (35WV 0.10μF)	[C29,30,35,36,37,42,43]
9	VCKYCZ1CF104Z	AB		С	Capacitor (35WV 0.10μF)	[C45,46,50,55,58,63,64]
	VCKYCZ1CF104Z	AB		С	Capacitor (35WV 0.10μF)	[C65,66]
10	VCKYCZ1HB102K	AA		С	Capacitor (50WV 1000pF)	[C16,20,21,57,59]
11	VCKYCZ1HF103Z	AA		С	Capacitor (0.01µF/50V)	[C6,14,19,38,39,44,56]
12	VHi74VHC04M-1	ΑE	N	В	IC (74VHC04M)	[IC4]
13	VHi74VHCT240X	AF		В	IC (74VHCT240X)	[IC100]
14	VHi7SZ125M5-1	ΑE	N	В	IC (7SZ125M5)	[IC2]
15	VHi90LV27AW-1	AQ	N	В	IC (90LV27AW)	[IC5]
16	V H i D 8 2 8 2 5 G M - 1	BK	N	В	IC (D82825GM)	[IC1]


40 CIS Control PWB[AR-EF1]

	•				
NO.	PARTS CODE	PRICE RANK	NEW MARK	PART RANK	DESCRIPTION
17	VH i F S 7 8 1 B Z B - 1	AP		В	IC (FS781BZB) [IC6]
18	V H i M 3 0 6 4 A T C - 1	AX	N	В	IC (M3064ATC) [IC7]
19	VH i VHC 2 4 4 S J - 1	AG	N	В	IC (VHC244SJ) [IC3]
	VRS-CZ1JD000J	AA		С	Resistor (1/16W $0\Omega \pm 5\%$) [R5,15,18,19,20,21,34]
20	VRS-CZ1JD000J	AA		С	Resistor (1/16W 0 Ω ±5%) [R35,43,44,45,46,48,49]
	VRS-CZ1JD000J	AA		С	Resistor (1/16W 0 Ω ±5%) [R50,51,52,53,54,55,59]
	VRS-CZ1JD101J	AA		С	Resistor (1/16W 100 Ω ±5%) [R1,2,3,4,9,10,14,22]
21	VRS-CZ1JD101J	AA		С	Resistor (1/16W 100 Ω ±5%) [R23,24,25,37,38,39,40]
	VRS-CZ1JD101J	AA		С	Resistor (1/16W 100 Ω ±5%) [R41,47,56,57]
22	VRS-CZ1JD102J	AA		С	Resistor (1/16W 1.0K Ω ±5%) [R100,17,26,27,28,29,30]
	VRS-CZ1JD102J	AA		С	Resistor (1/16W 1.0K Ω ±5%) [R31,32,33,36,42]
23	VRS-CZ1JD222J	AA		С	Resistor (1/16W 2.2K Ω ±5%) [R6,7,8,11,12,13]
24	VRS-CZ1JD332F	AA		С	Resistor (1/16W 3.3K Ω ±1%) [R58]
	(Unit)				
901	CPWBN1458FCE1	BF	N	Е	CIS control PWB

41 MFP Controler PWB[AR-M11]

NO.	PARTS CODE	PRICE RANK	NEW MARK	PART RANK	DESCRIPTION
4	VHi28F322L01F	BE	N	В	MFP flash ROM A J (28F322L01F) [Japan]
1	VHi28F322L03F	BF	N	В	MFP flash ROM A EX (28F322L03F) [except Japan]
2	VHi28F322L02F	BF	N	В	MFP flash ROM B J (28F322L02F) [Japan]
	VHi28F322L04F	BL	N	В	MFP flash ROM B EX (28F322L04F) [except Japan]
	L X - B Z 0 8 2 8 F C Z Z	AD		С	Handle fixing screw
	L X - B Z 0 9 2 1 F C Z 1	ΑE	N	С	Scanner Screw
	PCOVP1557FCZZ	AC		С	LAN/option cover
	PCOVP1560FCZZ	AC	N	С	FAX I/F cover
7	XBBSD30P06000	AA		С	Screw (3×6)
	XBPSD26P06000	AA		С	Screw (2.6×6)
9	XBPSD30P06000	AA		С	Screw (3×6)
11	XHBSE30P06000	AA		С	Screw (3×6)
12	LPLTM5765FCZ1	ΑH	N	С	Control joint plate


41 MFP Controler PWB[AR-M11]



42 Packing material & Accessories[ARM11]

NO.	PARTS CODE	PRICE RANK	NEW MARK	PART RANK	DESCRIPTION
2	SPAKP2792RCZZ	ΑE		D	Vinyl bag (460×500mm)
4	SPAKA6144FCZZ	AH	N	D	Packing add B
5	SPAKA6143FCZZ	AN	N	D	Packing add A
	SPAKC6142FCZZ	AP	N	D	Packing case [Japan]
6	SPAKC6142FC11	AP	N	D	Packing case [USA]
0	SPAKC6142FC12	AP	N	D	Packing case [Europe]
	SPAKC6142FC13	AP	N	D	Packing case [Other countries]

42 Packing material & Accessories[ARM11]




FCP05058

43 Packing Material & Accessories[AR-RK1]

NO.	PARTS CODE	PRICE RANK	NEW MARK	PART RANK		DESCRIPTION
1	SPAKA6136FCZZ	ΑE	N	D	Protect add	
	SPAKC6134DSZZ	ΑT	N	D	Packing case	(Japan)
_	SPAKC6134DS11	ΑT	N	D	Packing case	(U.S.A Other countries)
2	SPAKC6134DS12	ΑT	N	D	Packing case	(Europe, U. Kngdom, Australia, New Zealand)
	SPAKC6134DS13	ΑT	N	D	Packing case	(China)
7	SPAKA6135FCZZ	AK	N	D	Sleeve	
8	SPAKA6137FCZZ	AK	N	D	Spacer	

43 Packing Material & Accessories[AR-RK1]



■ Index

■ Index					
PARTS CODE	NO.	PRICE	NEW	PART	
	140.	RANK	MARK	RANK	
[C] CARMP0147DS51	29 501	ВА	N	Е	
CBTN-0250FC01	28-501 29- 18	AH	N	E	
CBTN-0251FC01	29- 15	AF	N	E	
CBTN-0252FC01	29- 13	AP	N	Е	
CBTN-0253FC01	29- 12	AN	N	E	
CCOVP1541FC02	31- 5	AT	N	D	
CDA i U0 6 1 9 DS 5 1	31- 1 32-901	BF BF	N N	E E	
CF i LW0282FC01	29- 16	AF	N	D	
CFiLW0283FC01	29- 17	AF	N	D	
CFiLW0284FC01	29- 14	AF	N	D	
CGLSP0003RS51	27- 10	ВС	N	В	
CGLSP0003RS52	27- 10	BF	N	В	
CGLSP0102DS51 CHLDZ1446FC31	27- 13 31-501	BF BC	N N	B E	
CiNSR2085FC51	17- 20	AS	N	D	
CiNSR2127FC51	17- 20	AR	N	D	
CiNSZ2086FC51	17- 20	AS	N	D	
CiNSZ2128FC51	17- 20	AR	N	D	
CPLTM0031RS51	31- 41	BS	N	E	
CPLTM5719FC01 CPLTM5746FC01	31- 31	AG AE	N	С	
CPL TM5 7 4 6 F C 0 1 CPL TM5 8 8 2 F C 0 2	35- 7 34- 47	AL	N N	C	
CPNLC0244DS51	27- 26	CV	N	D	
CPNLC0244DS52	27- 26	CT	N	D	
CPNLC0245FC01	29- 20	AY	N	D	
CPNLC0245FC02	29- 20	AY	N	D	
CPNLH0020QS12	1- 26	AK	N	D	
CPNLH0020QS13	1- 26	AK	N	D	
CPNLH0020QS22 CPNLH0020QS23	1- 26 1- 26	AK AK	N N	D D	
CPWBF1449FC31	32- 9	BH	N	E	
CPWBF1453FCE1	28- 9	BN	N	E	
CPWBF1454FCE1	31- 45	BN	N	E	
CPWBF1459DS51	33- 26	BN	N	E	
CPWBF1469FCE1	29- 11	BN	N	E	
" CPWBF1470DS51	38-901	BN BN	N	E	
CPWBF1470D351	29- 4 33- 16	BN	N N	E E	
CPWBN1450FCE1	30- 13	BF	N	E	
"	39-901	BF	N	E	
CPWBN1451DS51	30- 18	BF	N	Е	
CPWBN1458FCE1	36- 1	BF	N	E	
CPWBN1471FCE1	40-901	BF	N	E	
CSFTZ2586FC31	29- 1 31-502	BF AZ	N N	E E	
[D]	31-302	7,2	IN		
DHAi-3150FCZZ	31- 40	AD	N	С	
DHAi-3152FCZZ	30- 19	AF	N	С	
DHAi-3153FCZZ	30- 38	AC	N	С	
DHAI-3161FCZZ	33- 29	AK	N	С	
DHA i - 3 1 6 2 F C Z Z DHA i - 3 1 6 6 F C Z Z	35- 13 33- 27	AK AY	N N	C	
DHA i - 3166FCZZ	29- 6	AF	N	C	
DHA i -3191FCZZ	29- 5	AD	N	С	
DHAi-3193FCZZ	29- 22	AC	N	С	
DHAi-3281FCZZ	34- 62	AH	N	С	
DHA: 3303FCZZ	30- 28	BC	N	С	
DHAi-3336FCZZ DUNT-7079FCZZ	34- 79	AB CC	N	С	
DUNT-7079FCZZ DUNT-7132DSZZ	36- 4 27- 8	CY	N N	E E	
DUNT-7132D32Z	27- 8	CZ	N	E	
[G]					
GCAB-0940FCZ2	1- 5	ВА	N	D	
GCAB-0942FCZZ	27- 5	AP	N	D	
// CCAB-0043EC77	28- 12	AP	N	D	
GCAB-0943FCZZ GCAB-0945FCZZ	27- 1 27- 7	AK AR	N N	D D	
(H)	21- 1	ΛN	IN	U	
HPNLC0243FCZ1	1- 11	AP	N	D	
HPNLC0244FCZZ	29- 19	AZ	N	D	
HPNLH0246FCZZ	29- 10	BF	N	D	-
[J]	04 -			_	
JKNBZ0141FCZZ	34- 56	AH	N	С	
[L] LBNDJ0043FCZZ	30- 37	AA		С	
LBSHC0161FCZZ	31- 4	AB		C	
LBSHZ1102CCZZ	28- 3	AC		C	
-		*			

LDA 1UD6 19FCZZ 30-30	PARTS CODE	NO.	PRICE	NEW	PART	
LDAIU0619FCZZ 32-5				MARK		
LDAIJUG627FCZZ				NI		
LFIX-0284FCZZ						
LFIX-0537FCZZ				11		
LF X - 05 4 3 F C Z Z						
LFIX-0544FCZZ				N		
LFIX-0568FCZZ	LFiX-0544FCZZ	27- 9	AG		D	
LFIX-0569FCZZ	LFiX-0545FCZZ	32- 12	AC	N	С	
LFRM-1022FCZZ	LFiX-0568FCZZ	33- 12	AC	N	С	
LHLDW0429FCZZ 34-52 AB C LHLDW1007FCZZ 30-35 AC C C LHLDW1007FCZZ 30-35 AC C C LHLDW1007FCZZ 30-35 AC C C LHLDW1007FCZZ 30-34 AD C C		30- 46	AD	N	С	
LHLDW0595FCZZ				N		
LHLDW1007LCZZ						
LHLDW1009ACZZ						
## C						
LHLDW11115FCZZ						
## 1901 March Marc						
LHLDW1201CCZZ 30-45 AA C LHLDW1264FCZZ 30-36 AD C C LHLDW12010SCZZ 34-59 AB C C LHLDW12010SCZZ 34-59 AB C C LHLDZ1085FCZ2 28-8 AD N C LHLDZ1381FCZZ 29-9 AF N C LHLDZ1458FCZZ 29-9 AF N C LHLDZ1458FCZZ 29-9 AF N C LHLDZ1458FCZZ 29-7 AE N C LHLDZ1484FCZZ 34-13 AF C LHLDZ1484FCZZ 34-13 AF C LHLDZ1484FCZZ 34-13 AF C LHLDZ1484FCZZ 34-13 AF C LHLDZ1485FCZZ 34-32 AC N C LHLDZ1486FCZZ 34-32 AC N C LHLDZ1486FCZZ 34-32 AC N C LHLDZ1486FCZZ 34-32 AC N C LHLDZ1505FCZZ 31-2 AC N C LHLDZ1505FCZZ 31-2 AC N C LHLDZ1505FCZZ 31-3 AC N C LPINS1031HCZZ 34-48 AA C LPINS1031HCZZ 34-48 AA C LPLTM2573FCZZ 30-20 AK N C LPLTM5720FCZZ 30-20 AK N C LPLTM5720FCZZ 30-20 AK N C LPLTM5765FCZZ 34-453 AC N C LPLTM5765FCZZ 34-453 AC N C LPLTM5765FCZZ 30-24 AE N C LPLTM5884FCZZ 34-53 AC N C LPLTM5887FCZZ 30-24 AE N C LPLTM5887FCZZ 33-10 AL N C LPLTM5929FCZZ 33-10 AL N C LPLTM5929FCZZ 34-57 AC N C LPLTM5929FCZZ 34-57 AC N C LPLTM5929FCZZ 34-57 AC N C LPLTM5929FCZZ 34-67 AC N C LPLTM5929FCZZ 35-24 AC N C LPLTM5929FCZZ 35-32 AD N C C LPLTM5938FCZZ 34-67 AC N C LPLTM5929FCZZ 35-32 AD N C C LPLTM5938FCZZ 35-32 AD N C						
LHLDW1264FCZZ LHLDW2101SCZZ LHLDZ1085FCZ2 28-8 AD N C LHLDZ1381FCZZ LHLDZ1381FCZZ LHLDZ1458FCZZ 29-9 AF N C LHLDZ1458FCZZ 29-9 AF N C LHLDZ1458FCZZ 29-7 AE N C LHLDZ1483FCZZ 29-7 AE N C LHLDZ1483FCZZ 29-7 AC N C LHLDZ1485FCZZ 34-13 AF C LHLDZ1485FCZZ 34-43 AF C LHLDZ1485FCZZ 34-45 AC N C LHLDZ1486FCZZ 34-45 AC N C LHLDZ1486FCZZ 34-45 AC N C LHLDZ1480FCZZ 34-45 AC N C LHLDZ1505FCZZ 31-2 AC N C LPINS0014QSGZ 29-21 AC N C LPINS0131HCZZ AG N C LPITM5720FCZZ 30-20 AK N C LPLTM5723FCZZ 30-10 AG N C LPLTM5723FCZZ 30-10 AG N C LPLTM5723FCZZ 30-10 AG N C LPLTM5785FCZZ 34-53 AC N C LPLTM5785FCZZ 34-51 AW N C LPLTM5887FCZZ 34-53 AC N C LPLTM5887FCZZ 34-51 AW N C LPLTM5887FCZZ 34-51 AW N C LPLTM5887FCZZ 34-51 AW N C LPLTM5887FCZZ 34-57 AC N C LPLTM5887FCZZ 34-57 AC N C LPLTM5889FCZZ 34-57 AC N C LPLTM5889FCZZ 34-57 AC N C LPLTM5889FCZZ 34-57 AC N C LPLTM5891FCZZ 34-57 AC N C LPLTM5891FCZZ 34-57 AC N C LPLTM5891FCZZ 35-1 AE N C LPLTM592FCZZ 34-61 AR N C LPLTM5928FCZZ 34-57 AC N C LPLTM5928FCZZ 34-57 AC N C LPLTM5928FCZZ 34-57 AC N C LPLTM5928FCZZ 34-61 AR N C LPLTM5939FCZZ 34-61 AR N C LPLTM5939FCZZ 35-2 AC N C LPLTM5938FCZZ 35-3 AC N C LPLTM5939FCZZ 35-2 AC N C LPLTM5939FCZZ 35-2 AC N C LPLTM5939FCZZ 35-3 AC N C LPLTM5939FCZZ 35-3 AC N C LPLTM5939FCZZ 35-4 AC N C C LPLTM5939FCZZ 3						
LHLDZ1018CZZ 28-8 AD N C LHLDZ1381FCZZ 28-8 AD N C C LHLDZ1381FCZZ 29-9 AF N C LHLDZ1459FCZZ 29-9 AF N C LHLDZ1459FCZZ 29-7 AE N C LHLDZ1483FCZZ 34-13 AF C C LHLDZ1483FCZZ 34-13 AF C C LHLDZ1483FCZZ 34-13 AF C C LHLDZ1485FCZZ 34-13 AF C C LHLDZ1485FCZZ 34-23 AC N C LHLDZ1486FCZZ 34-24 AC N C LHLDZ1486FCZZ 34-34-67 AC N C LHLDZ1486FCZZ 34-34-48 AA C N C LHLDZ15014QSGZ 29-21 AC N C LHLDZ15014QSGZ 29-21 AC N C LPINS1031HCZZ 34-48 AA C C LPLTM2573FCZI 33-43 AD C LPLTM2573FCZI 33-43 AD C LPLTM5728FCZZ 30-20 AK N C LPLTM5728FCZZ 30-20 AK N C LPLTM5766FCZI 12-35 AH N C LPLTM5786FCZI 12-35 AH N C LPLTM5786FCZI 34-53 AC N C LPLTM5787FCZZ 30-24 AE N C LPLTM5887FCZZ 34-451 AW N C LPLTM5887FCZZ 34-51 AW N C LPLTM5889FCZZ 34-51 AW N C LPLTM5891FCZZ 34-51 AW N C LPLTM5891FCZZ 34-51 AC N C LPLTM5927FCZZ 30-22 AF N C LPLTM5927FCZZ 30-22 AF N C LPLTM5927FCZZ 30-22 AF N C LPLTM5927FCZZ 35-5 AD N C LPLTM5930FCZZ 35-5 AD N						
LHLDZ1085FCZ2 28-8 AD N C LHLDZ1381FCZZ 31-44 AL C LHLDZ1458FCZZ 29-9 AF N C LHLDZ1483FCZZ 29-7 AE N C LHLDZ1483FCZZ 34-13 AF C LHLDZ1483FCZZ 34-13 AF C LHLDZ1485FCZZ 34-67 AC N C LHLDZ1485FCZZ 34-67 AC N C LHLDZ1486FCZZ 34-45 AC N C LHLDZ1486FCZZ 34-45 AC N C LHLDZ1505FCZZ 31-2 AC N C LHLDZ1505FCZZ 31-2 AC N C LPINS0014QSGZ 29-21 AC N C LPINS0014QSGZ 29-21 AC N C LPINS0714VSZZ 34-48 AA C LPINS0714VSZ 34-48 AA C LPLTM5725FCZZ 30-20 AK N C LPLTM5725FCZZ 30-20 AK N C LPLTM5725FCZZ 30-20 AK N C LPLTM5765FCZI 12-35 AH N C LPLTM5765FCZI 12-35 AH N C LPLTM5785FCZZ 34-53 AC N C LPLTM5887FCZZ 34-51 AW N C LPLTM5887FCZZ 34-51 AW N C LPLTM5889FCZZ 34-57 AC N C LPLTM5927FCZZ 30-22 AF N C LPLTM5927FCZZ 34-61 AR N C LPLTM5927FCZZ 34-61 AR N C LPLTM5927FCZZ 34-57 AC N C LPLTM5927FCZZ 34-61 AR N C LPLTM5927FCZZ 34-61 AR N C LPLTM5927FCZZ 35-5 AD N C LPLTM59374FCZZ 35-5 AD N C LPLTM59374FCZZ 35-5 AD N C LPLTM5938FCZZ 34-52 AC N C LPLTM5938FCZZ 34-53 AG N C LPLTM5938FCZZ 34-53 AG N C LPLTM5938FCZZ 33-37 AG N D LPLTP5748FCZZ 35-32 AD N C LPLTP5748FCZZ 35-32 AD N C LPLTP5777FCZZ 35-8 AC N C LPLTP5938FCZZ 33-37 AG N D LPLTP5777FCZZ 35-8 AC N C LPLTP5938FCZZ 33-37 AG N D LPLTP5777FCZZ 35-8 AC N C LPLTP5938FCZZ 33-37 AG N C LPLTP5938FCZZ						
LHLD21381FCZZ 31-44 AL C LHLD21458FCZZ 29-9 AF N C LHLD21483FCZZ 29-7 AE N C LHLD21483FCZZ 34-67 AC N C LHLD21483FCZZ 34-67 AC N C LHLD21486FCZZ 34-52 AC N C LHLD21505FCZZ 31-2 AC N C LPINS0014QSGZ 29-21 AC N C LPINS1031HCZZ 34-88 AA C LPLTM5726FCZZ 33-43 AD C LPLTM5726FCZZ 30-20 AK N C LPLTM5729FCZZ 30-20 AK N C LPLTM5723FCZZ 30-10 AG N C LPLTM5765FCZZ 34-53 AC N C LPLTM5765FCZZ 34-53 AC N C LPLTM5787FCZZ 30-24 AE N C LPLTM5884FCZZ 34-53 AC N C LPLTM5884FCZZ 34-51 AW N C LPLTM5889FCZZ 34-53 AC N C LPLTM5891FCZZ 33-10 AL N C LPLTM5891FCZZ 33-10 AL N C LPLTM5928FCZZ 34-61 AR N C LPLTM5932FCZZ 34-61 AR N C LPLTM5932FCZZ 34-61 AR N C LPLTM5932FCZZ 33-17 AF C LPLTTP5747FCZZ 33-31 AG N C LPLTTM5932FCZZ 33-17 AF C LPLTTP5936FCZZ 33-37 AG N C LPLTTP5747FCZZ 33-38 AG N C LPLTTP5936FCZZ 33-37 AG N C LPLTTP5936FCZZ 33-37 AG N C LPLTTP5946FCZZ 33-37 AG N C LPLTTP5976CZZ 33-37 AG N C LPLTTP5966FCZZ 33-37 AG N C LPLTTP5966FCZZ 33-37 AG N C LPLTTP5966FCZZ 33-37 AG N C LPLTTP5936FCZZ 33-38 AG N C LPLTTP5936FCZZ 33-37 AG N C LPLTTP5936FCZZ 33-44 AC C LPLTTP5936FCZZ 33-44				N		
LHLD21458FCZZ 29-9 AF N C LHLD21483FCZZ 34-13 AF C LHLD21484FCZZ 34-13 AF C LHLD21484FCZZ 34-67 AC N C LHLD21486FCZZ 34-67 AC N C LHLD21505FCZZ 31-2 AC N C LHLD21505FCZZ 31-2 AC N C LHLD21505FCZZ 31-2 AC N C LPINS0014QSGZ 29-21 AC N C LPINS0014QSGZ 29-21 AC N C LPINS0714CZ 34-48 AA C LPLTM5725FCZI 33-43 AD C LPLTM5725FCZI 33-43 AD C LPLTM5720FCZZ 30-20 AK N C LPLTM5725FCZI 33-43 AD C LPLTM5725FCZI 33-43 AD C LPLTM5765FCZI 12-35 AH N C LPLTM5765FCZI 12-35 AH N C LPLTM587FCZZ 34-53 AC N C LPLTM5887FCZZ 34-53 AC N C LPLTM5887FCZZ 34-51 AW N C LPLTM5891FCZZ 35-1 AE N C LPLTM5927FCZZ 30-22 AF N C LPLTM5928FCZZ 34-23 AG N C LPLTM5929FCZZ 34-61 AR N C LPLTM5929FCZZ 34-61 AR N C LPLTM5930FCZZ 35-5 AD N C LPLTM5932FCZZ 35-24 AC C LPLTM5932FCZZ 35-34 AC N C LPLTM5932FCZZ 35-32 AD N C LPLTP5744FCZZ 35-32 AD N C LPLTP5747FCZZ 35-38 AC N C LPLTP5777FCZZ 35-32 AD N C LPLTP5777FCZZ 35-34 AC N C LPLTP5777FCZZ 35-34 AC N C LPLTP5777FCZZ 35-35 AD N C LPLTP5777FCZZ 35-36 AC N C LPLTP5777FCZZ 35-37 AR D LC C LPLTP5777FCZZ 35-38 AC N C LPLTP5777FCZZ 35-34 AC N C LPLTP5777FCZZ 35-35 AC N C C LPLTP5777FCZZ 35-34 AC N C C LP						
LHLD21483FCZZ 34-13 AF C LHLD21484FCZZ 34-67 AC N C LHLD21486FCZZ 34-67 AC N C LHLD21486FCZZ 34-45 AC N C LHLD21505FCZZ 31-2 AC N C LHLD21505FCZZ 31-2 AC N C LPINS0014QSGZ 29-21 AC N C LPINS1031HCZZ 34-48 AA C LPINS0737FCZI 33-43 AD C LPINS725FCZZ 34-53 AD N C LPLTM5720FCZZ 30-10 AG N C LPLTM5720FCZZ 30-10 AG N C LPLTM5723FCZI 33-43 AD C LPLTM5723FCZI 33-43 AD C LPLTM5723FCZI 30-30 AK N C LPLTM5785FCZZ 30-10 AG N C LPLTM5785FCZZ 30-10 AG N C LPLTM5785FCZZ 34-53 AC N C LPLTM5785FCZZ 34-53 AC N C LPLTM5887FCZZ 34-53 AC N C LPLTM5884FCZZ 34-51 AW N C LPLTM5889FCZZ 34-51 AW N C LPLTM5927FCZZ 30-22 AF N C LPLTM5927FCZZ 30-22 AF N C LPLTM5927FCZZ 30-22 AF N C LPLTM5927FCZZ 33-10 AL N C LPLTM5927FCZZ 35-1 AE N C LPLTM5927FCZZ 35-1 AE N C LPLTM5928FCZZ 34-51 AR N C LPLTM5927FCZZ 35-1 AC N C LPLTM5937FCZZ 35-1 AC N C LPLTTS777FCZZ 35-2 AN D N C LPLTTS777FCZZ 35-3 AN N C LPLTTS777FCZZ 35-3 AN N C LPLTTS777FCZZ 35-3 AN N C LPLTTS9778FCZZ 35-1 AC N C LPLTP59778FCZZ 35-3 AN N C LPLTTS9778FCZZ 35-3 AN N C C L				N		
LHLD21483FCZZ 34-13 AF C C LHLD21486FCZZ 34-32 AC N C LHLD21486FCZZ 34-32 AC N C LHLD21486FCZZ 34-32 AC N C LHLD21505FCZZ 31-2 AC N C LHD21505FCZZ 31-2 AC N C LPINS0014QSGZ 29-21 AC N C LPINS1031HCZZ 34-48 AA C C LPLTM2573FCZ1 33-34 AD C LPLTM5720FCZZ 30-20 AK N C LPLTM5720FCZZ 30-20 AK N C LPLTM5720FCZZ 30-10 AG N C LPLTM5723FCZZ 30-10 AG N C LPLTM5765FCZI 12-35 AH N C LPLTM5785FCZZ 34-53 AC N C LPLTM5887FCZZ 34-53 AC N C LPLTM5887FCZZ 34-53 AC N C LPLTM5887FCZZ 34-51 AW N C LPLTM5887FCZZ 34-57 AC N C LPLTM5927FCZZ 35-1 AE N C LPLTM5927FCZZ 35-1 AE N C LPLTM5927FCZZ 34-61 AR N C LPLTM5927FCZZ 34-61 AR N C LPLTM5927FCZZ 34-61 AR N C LPLTM5928FCZZ 34-61 AR N C LPLTM5937FCZZ 35-5 AD N C LPLTM5937FCZZ 35-5 AD N C LPLTM5937FCZZ 35-5 AD N C LPLTM5937FCZZ 35-6 AC N C LPLTM5937FCZZ 35-1 AC N C LPLTM5937FCZZ 35-1 AC N C LPLTM5937FCZZ 35-2 AC N C LPLTM5937FCZZ 35-3 AC N C LPLTTP5743FCZZ 35-3 AC N C LPLTTP5748FCZZ 35-32 AD N C LPLTP5777FCZZ 33-38 AG N C LPLTP5938FCZZ 35-34 AC N C LPLTP5938FCZZ 35-32 AD N C LPLTP5938FCZZ 35-34 AC N C LPLTP5938FCZZ 35-35 AC N C LPLTP5938FCZZ 35-35 AC N C LPLTP5938FCZZ 35-34 AC N C LPLTP5938FCZZ 35-35 AC N C C LPLTP5938FCZZ 35-34 AC N C						
LHLDZ1485FCZZ 34-32 AC N C LHLDZ1486FCZZ 34-45 AC N C LHLDZ1505FCZZ 31-2 AC N C LPINS0014QSGZ 29-21 AC N C LPINS1031HCZZ 34-48 AA AC C LPINS1031HCZZ 34-48 AA AC C LPLTM573FCZZ 30-20 AK N C LPLTM5725FCZZ 30-20 AK N C LPLTM5723FCZZ 30-10 AG N C LPLTM5765FCZZ 30-10 AG N C LPLTM5765FCZZ 30-10 AG N C LPLTM5765FCZZ 34-53 AC N C LPLTM5765FCZZ 34-53 AC N C LPLTM5877FCZZ 30-24 AE N C LPLTM5877FCZZ 30-24 AE N C LPLTM5884FCZZ 34-51 AW N C LPLTM5884FCZZ 34-51 AW N C LPLTM5884FCZZ 34-57 AC N C LPLTM5889FCZZ 34-57 AC N C LPLTM5891FCZZ 35-1 AE N C LPLTM5929FCZZ 34-61 AR N C LPLTM5930FCZZ 35-5 AD N C LPLTM5932FCZZ 33-10 AC N C LPLTM5932FCZZ 33-10 AC N C LPLTM5932FCZZ 33-10 AC N C LPLTM5932FCZZ 34-61 AR N C LPLTM5932FCZZ 33-10 AC N C LPLTM5932FCZZ 33-10 AC N C LPLTM5932FCZZ 34-61 AR N C LPLTM5933FCZZ 33-10 AC N C LPLTM5933FCZZ 33-10 AC N C LPLTM5933FCZZ 33-10 AC N C LPLTP5743FCZZ 33-10 AC N C LPLTP5743FCZZ 33-10 AC N C LPLTP5745FCZZ 33-10 AC N C LPLTP5745FCZZ 33-10 AC N C LPLTP5745FCZZ 33-10 AC N C LPLTP5747FCZZ 33-10 AC N C LPLTP5747FCZZ 33-10 AC N C LPLTP5746FCZZ 33-10 AC N C LPLTP5746FCZZ 33-10 AC N C LPLTP5777FCZZ 33-10 AC N C LPLTP5938FCZZ 33-17 AF C LPLTP5748FCZZ 33-17 AF C LPLTP5748FCZZ 33-17 AF C LPLTP5748FCZZ 33-18 AC N C LPLTP5746FCZZ 33-18 AC N C LPLTP5777FCZZ 33-8 AC N C LPLTP5938FCZZ 33-14 AC N C LPLTP59057FCZZ 33-24 AC N C LPLTP59057FCZZ 33-24 AC N C LPLTP59057FCZZ 33-24 AC N C LPLTP59057FCZZ 33-37 AG N D LTSP00314FCZZ 33-37 AG N D LTSP00314FCZZ 33-41 AG N C LSOU-0179FCZZ 33-24 AC N C LSOU-0179FCZZ 33-24 AC N C LSTP00359FCZZ 34-65 AB N C LSTP00359FCZZ 34-65 AB N C LSTP00359FCZZ 34-65 AB N C LSTP00359FCZZ 34-61 AR N C LSTP00359FCZZ 34-61 AR N C LSTP00359FCZZ 34-61 AR N C LSTP00359FCZZ 34-61 AC N C	LHLDZ1483FCZZ		AF		С	
LHLDZ1486FCZZ 34-45 AC N C LHLDZ1505FCZZ 31-2 AC N C LPINS0014QSGZ 29-21 AC N C LPINS1031HCZZ 34-48 AA C LPLTM573FCZ1 33-43 AD C LPLTM5720FCZZ 30-20 AK N C LPLTM5723FCZZ 30-10 AG N C LPLTM5723FCZZ 30-10 AG N C LPLTM5765FCZI 12-35 AH N C LPLTM5765FCZI 12-35 AH N C LPLTM5765FCZZ 30-24 AE N C LPLTM5785FCZZ 34-53 AC N C LPLTM5877FCZZ 30-24 AE N C LPLTM5887FCZZ 34-51 AW N C LPLTM5887FCZZ 33-10 AL N C LPLTM5889FCZZ 34-51 AW N C LPLTM5889FCZZ 34-57 AC N C LPLTM5891FCZZ 35-1 AE N C LPLTM592FCZZ 34-57 AC N C LPLTM5928FCZZ 34-23 AG N C LPLTM5928FCZZ 34-23 AG N C LPLTM5928FCZZ 35-24 AC C LPLTM5930FCZZ 35-3 AD N C LPLTM5937FCZZ 35-4 AC N C LPLTM5937FCZZ 35-3 AD N C LPLTM5937FCZZ 35-4 AC N C LPLTM5938FCZZ 33-17 AF C LPLTM5938FCZZ 33-17 AF C LPLTM5938FCZZ 33-17 AF C LPLTF5748FCZZ 33-37 AG N C LPLTF5748FCZZ 33-37 AG N C LPLTF5748FCZZ 33-37 AF C LPLTF5748FCZZ 33-37 AF C LPLTF5748FCZZ 33-37 AF C LPLTF5748FCZZ 33-37 AF C LPLTP5748FCZZ 33-37 AF C LPLTP5748FCZZ 33-37 AF C LPLTP5748FCZZ 33-37 AF C LPLTP5778FCZZ 33-38 AG N C LPLTP5778FCZZ 33-34 AC N C LPLTP5748FCZZ 33-37 AF C LPLTP5748FCZZ 33-37 AF C LPLTP5748FCZZ 33-37 AF C LPLTP5748FCZZ 33-44 AC N C LPLTP5748FCZZ 33-44 AC N C LPLTP5748FCZZ 33-44 AC N C LPLTP578FCZZ	LHLDZ1484FCZZ	34- 67	AC	N	С	
LHLDZ1505FCZZ 31- 2 AC N C LPINS0014QSGZ 29-21 AC N C LPINS1031HCZZ 34-48 AA C LPLTM2573FCZ1 33-48 AA C LPLTM5729FCZZ 30-20 AK N C LPLTM5729FCZZ 30-10 AG N C LPLTM5729FCZZ 30-10 AG N C LPLTM5765FCZ1 12-35 AH N C LPLTM5765FCZ1 12-35 AH N C LPLTM5765FCZZ 34-53 AC N C LPLTM58765FCZZ 34-53 AC N C LPLTM5877FCZZ 30-24 AE N C LPLTM5884FCZZ 34-51 AW N C LPLTM5884FCZZ 34-51 AW N C LPLTM5889FCZZ 34-57 AC N C LPLTM5889FCZZ 34-57 AC N C LPLTM5891FCZZ 35-1 AE N C LPLTM5929FCZZ 34-61 AR N C LPLTM5932FCZZ 35-5 AD N C LPLTM5932FCZZ 35-5 AD N C LPLTP5743FCZZ 35-32 AD N C LPLTP5747FCZZ 35-35 AD N C LPLTP5748FCZZ 33-37 AG N C LPLTP5777FCZZ 33-38 AC N C LPLTP5777FCZZ 35-35 AD N C LPLTP5777FCZZ 35-36 AC N C LPLTP5777FCZZ 35-37 AG N D LPLTP5778FCZZ 35-32 AD N C LPLTP5777FCZZ 33-38 AC N C LPLTP5777FCZZ 33-37 AG N D LPLTP5778FCZZ 33-37 AG N D LPLTP5778FCZZ 33-44 AC N C LSTYP0359FCZZ 34-65 AE N C LSTYP0359FCZZ 34-66 AD C LX-BZ094PCZZ 31-19 AB C LX-BZ094PCZZ 31-19 AB C LX-BZ094PCZZ 31-19 AB C LX-BZ094PCZZ 31-19 AB C LX-BZ09776FCZZ 32-14 AA C LX-BZ09776FCZZ 32-14 AA C LX-BZ098FCZZ 31-19 AB C LX-BZ098FCZZ 31-19 AB C LX-BZ0931FCZZ 32-14 AA C LX-BZ0931FCZZ 32-14 AA C LX-BZ0931FCZZ 32-14 AA C LX-BZ0931FCZZ 32-16 AG C LX-BZ0931FCZZ 34-76 AC N C LX-BZ0931FCZZ 28-10 AK N C		34- 32		N		
LP NS0014QSGZ		-			С	
LP INS1 0 3 HCZZ						
LPLTM2573FCZ1				N		
LPLTM5729FCZZ 30- 20 AK N C LPLTM5723FCZZ 30- 10 AG N C LPLTM5765FCZ1 12- 35 AH N C LPLTM5785FCZZ 34- 53 AC N C LPLTM5887FCZZ 34- 53 AC N C LPLTM5884FCZZ 34- 51 AW N C LPLTM5887FCZZ 33- 10 AL N C LPLTM5891FCZZ 35- 1 AE N C LPLTM5991FCZZ 35- 1 AE N C LPLTM5929FCZZ 34- 61 AR N C LPLTM5929FCZZ 34- 61 AR N C LPLTM5930FCZZ 35- 5 AD N C LPLTM5932FCZZ 35- 5 AD N C LPLTM5932FCZZ 35- 8 AC N C LPLTM5932FCZZ 35- 8 AC N C LPLTM5936FCZZ 35- 8						
LPLTM5723FCZZ 30- 10 AG N C LPLTM5765FCZ1 12- 35 AH N C " 41- 12 AH N C LPLTM5785FCZZ 34- 53 AC N C LPLTM5887FCZZ 30- 24 AE N C LPLTM5887FCZZ 34- 51 AW N C LPLTM5889FCZZ 34- 57 AC N C LPLTM5889FCZZ 34- 57 AC N C LPLTM5929FCZZ 34- 23 AG N C LPLTM5928FCZZ 34- 23 AG N C LPLTM5928FCZZ 34- 23 AG N C LPLTM5928FCZZ 34- 61 AR N C LPLTM5928FCZZ 34- 61 AR N C LPLTM5932FCZZ 35- 5 AD N C LPLTM5932FCZZ 35- 8 AC N C LPLTP574FCZZ 35- 32 AD						
LPLTM5765FCZ1						
## 41- 12 ## AH						
LPLTM5785FCZZ 34-53 AC N C LPLTM5877FCZZ 30-24 AE N C LPLTM5884FCZZ 34-51 AW N C LPLTM5887FCZZ 33-10 AL N C LPLTM5889FCZZ 34-57 AC N C LPLTM5889FCZZ 34-57 AC N C LPLTM5891FCZZ 35-1 AE N C LPLTM5927FCZZ 35-1 AE N C LPLTM5927FCZZ 30-22 AF N C LPLTM5928FCZZ 34-23 AG N C LPLTM5929FCZZ 34-61 AR N C LPLTM5930FCZZ 35-5 AD N C LPLTM5932FCZZ 35-32 AC N C LPLTP5743FCZZ 35-32 AD N C LPLTP5743FCZZ 35-32 AD N C LPLTP5777FCZZ 33-38 AG N D LPLTP5778FCZZ 33-37 AG N D LPLTP57938FCZZ 30-44 AC N C LPLTP5960FCZZ 30-44 AC N C LRALM0183FCZZ 30-31 AG N C LRALM0184FCZZ 30-31 AG N C LRALM0184FCZZ 30-31 AG N C LSOU-0177FCGZ 37-2 AP D LSOU-0177FCGZ 37-2 AP D LSTPP0314FCZZ 35-32 AD N C LSTPP0359FCZZ 34-65 AE N C LSTPP0359FCZZ 34-65 AE N C LSTPP0359FCZZ 34-31 AK N C LSTPP0359FCZZ 34-35 AB N C LSTPP0359FCZZ 34-31 AK N C LSTPP0359FCZZ 34-35 AB N C LSTPP0359FCZZ 34-65 AE N C LSTPP0359FCZZ 34-31 AK N C LX-BZ004QSZZ 30-42 AB C LX-BZ004QSZZ 30-42 AB C LX-BZ004QSZZ 30-42 AB C LX-BZ004GFCZZ 37-24 AA C LX-BZ004GFCZZ 37-24 AA C LX-BZ004GFCZZ 37-24 AA C LX-BZ004GFCZZ 37-5 AH C LX-BZ0076FCZZ 37-5 AH C LX-BZ0076FCZZ 37-5 AH C LX-BZ0776FCZZ 37-5 AH C LX-BZ0787FCZZ 37-5 AH C LX-BZ0787FCZZ 37-5 AH C LX-BZ0787FCZZ 37-5 AH C LX-BZ0787FCZZ 37-5 AH C LX-BZ0776FCZZ 37-5 AH C LX-BZ0787FCZZ 37-5 AH C LX-BZ0921FCZ1 12-56 AD C LX-BZ0921FCZ1 12-56 AD C LX-BZ0921FCZ1 12-56 AD C LX-BZ0931FCZZ 34-76 AC N C LX-BZ0931FCZZ 38-10 AK N C						
LPLTM5877FCZZ						
LPLTM5884FCZZ						
LPLTM5887FCZZ						
LPLTM5891FCZZ 34- 57 AC N C LPLTM5891FCZZ 35- 1 AE N C LPLTM5927FCZZ 30- 22 AF N C LPLTM5928FCZZ 34- 23 AG N C LPLTM5930FCZZ 35- 5 AD N C LPLTM5932FCZZ 35- 5 AD N C LPLTM5932FCZZ 35- 5 AD N C LPLTP5743FCZZ 33- 17 AF C C LPLTP5743FCZZ 35- 8 AC N C LPLTP5748FCZZ 35- 32 AD N C LPLTP5748FCZZ 35- 32 AD N C LPLTP5778FCZZ 33- 37 AG N D LPLTP5778FCZZ 33- 37 AG N D LPLTP5938FCZZ 33- 44 AC N C LRALM0184FCZZ 30- 41 AG N C LRALM0184FCZZ 30- 41 AG N C LSÖU-0179FCZZ 37- 2 AR <td< td=""><td></td><td></td><td></td><td></td><td></td><td></td></td<>						
LPLTM5891FCZZ 35- 1 AE N C LPLTM5927FCZZ 30- 22 AF N C LPLTM5928FCZZ 34- 23 AG N C LPLTM5929FCZZ 34- 61 AR N C LPLTM5930FCZZ 35- 5 AD N C LPLTM5932FCZZ 35- 5 AD N C LPLTM5743FCZZ 35- 8 AC N C LPLTP5743FCZZ 35- 8 AC N C LPLTP574FCZZ 35- 32 AD N C LPLTP5778FCZZ 33- 38 AG N D LPLTP5938FCZZ 30- 44 AE N C LRALM0183FCZZ 30- 44 AE N C LRALM0184FCZZ 30- 41	LPLTM5889FCZZ		AC	N	С	
LPLTM5928FCZZ 34-23 AG N C LPLTM5929FCZZ 34-61 AR N C LPLTM5930FCZZ 35-5 AD N C LPLTM5932FCZZ 35-24 AC C C LPLTP5743FCZZ 33-17 AF C C LPLTP5747FCZZ 35-8 AC N C LPLTP5748FCZZ 35-32 AD N C LPLTP5778FCZZ 33-37 AG N D LPLTP5778FCZZ 33-37 AG N D LPLTP5938FCZZ 33-34 AC N C LPLTP59860FCZZ 30-44 AE N C LRALM0183FCZZ 30-41 AG N C LRALM0184FCZZ 30-41 AG N C LSŌU-0177FCGZ 37-2 AP D D LSTP0314FCZZ 35-3 AE N C LSTPP0315FCZZ 35-3 AE	LPLTM5891FCZZ	35- 1	ΑE	N	С	
LPLTM5929FCZZ 34-61 AR N C LPLTM5930FCZZ 35-5 AD N C LPLTM5932FCZZ 35-5 AD N C LPLTP5743FCZZ 35-8 AC N C LPLTP5747FCZZ 35-8 AC N C LPLTP5748FCZZ 35-32 AD N C LPLTP5778FCZZ 33-38 AG N D LPLTP5778FCZZ 33-37 AG N D LPLTP5938FCZZ 33-44 AC N C LPLTP5938FCZZ 33-44 AC N C LRALM0183FCZZ 30-31 AG N C LRALM0184FCZZ 30-41 AG N C LRALM0184FCZZ 37-2 AP D D LSŌU-0177FCGZ 37-2 AR D D LSTPP0314FCZZ 35-3 AE N C LSTPP0359FCZZ 34-65 AE		30- 22		N	С	
LPLTM5930FCZZ 35- 5 AD N C LPLTM5932FCZZ 35- 24 AC C LPLTP5743FCZZ 35- 8 AC N C LPLTP5747FCZZ 35- 8 AC N C LPLTP5748FCZZ 35- 8 AC N C LPLTP5777FCZZ 35- 8 AC N D LPLTP5777FCZZ 33- 38 AG N D LPLTP5777FCZZ 33- 38 AG N D LPLTP5778FCZZ 33- 37 AG N D LPLTP5938FCZZ 33- 37 AG N D LPLTP5960FCZZ 30- 44 AE N C LRALM0183FCZZ 30- 31 AG N C LRALM0183FCZZ 30- 31 AG N C LRALM0184FCZZ 30- 41 AG N C LSŌU-0177FCGZ 37- 2 AP D LSŌU-0177FCGZ 37- 2 AR D LSTPP0314FCZZ 35- 3 AE N C LSTPP0359FCZZ 34- 65 AE N C LSTYM0261FCZZ 32- 11 AB N C LSTYM0261FCZZ 31- 34- 31 AK N C LX-BZ0004QSZZ 30- 42 AB C LX-BZ0004QSZZ 30- 42 AB C LX-BZ0049FCZZ 31- 19 AB C LX-BZ0046FCZZ 31- 22 AA C LX-BZ0046FCZZ 37- 5 AB C LX-BZ0776FCZZ 37- 5 AB C LX-BZ0776FCZZ 37- 5 AB C LX-BZ0828FCZZ 12- 56 AD C LX-BZ0828FCZZ 27- 4 AG C LX-BZ0828FCZZ 12- 56 AD C LX-BZ0821FCZ1 12- 25 AE N C LX-BZ0931FCZZ 31- 35 AA C				N	С	
LPLTM5932FCZZ 35- 24 AC C LPLTP5743FCZZ 33- 17 AF C LPLTP5747FCZZ 35- 8 AC N C LPLTP5748FCZZ 35- 32 AD N C LPLTP5777FCZZ 33- 38 AG N D LPLTP5778FCZZ 33- 37 AG N D LPLTP5938FCZZ 33- 44 AC N C LPLTP5960FCZZ 30- 44 AE N C LRALM0183FCZZ 30- 31 AG N C LRALM0184FCZZ 30- 41 AG N C LSŌU-0177FCGZ 37- 2 AP D D LSTPP0314FCZZ 35- 21 AA C C LSTPP0359FCZZ 34- 65 AE N C LSTYM0261FCZZ 32- 11 AB N C LSTYM0288FCZZ 34- 31 AK N C LX-BZ0049FCZZ 31- 19 AB C LX-BZ00465FCZZ 31- 22 AA C LX-BZ0787						
LPLTP5743FCZZ 33-17 AF C LPLTP5747FCZZ 35-8 AC N C LPLTP5748FCZZ 35-32 AD N C LPLTP577FCZZ 33-38 AG N D LPLTP5778FCZZ 33-37 AG N D LPLTP5988FCZZ 33-44 AC N C LPLTP5960FCZZ 30-44 AE N C LRALM0183FCZZ 30-31 AG N C LRALM0184FCZZ 30-41 AG N C LSOU-0177FCGZ 37-2 AP D D LSTPP0314FCZZ 35-21 AA C C LSTPP0359FCZZ 35-31 AE N C LSTPP0359FCZZ 35-31 AB N C LSTYM0261FCZZ 35-31 AE N C LSTYM0261FCZZ 34-65 AE N C LX-BZ0049FCZZ 34-31 AK N <td></td> <td></td> <td></td> <td>N</td> <td></td> <td></td>				N		
LPLTP5747FCZZ 35- 8 AC N C LPLTP5748FCZZ 35- 32 AD N C LPLTP5777FCZZ 33- 38 AG N D LPLTP5778FCZZ 33- 37 AG N D LPLTP5938FCZZ 33- 44 AC N C LPLTP5960FCZZ 30- 44 AE N C LPLTP5960FCZZ 30- 44 AE N C LRALM0183FCZZ 30- 31 AG N C LRALM0184FCZZ 30- 41 AG N C LSŌU-0177FCGZ 37- 2 AP D LSŌU-0179FCZZ 37- 2 AR D LSTPP0314FCZZ 35- 21 AA C LSTPP0359FCZZ 35- 3 AE N C LSTPP0359FCZZ 34- 65 AE N C LSTYM0261FCZZ 32- 11 AB N C LSTYM0288FCZZ 34- 31 AK N C LX-BZ0049FCZZ 31- 19 AB C LX-BZ0049FCZZ 31- 19 AB C LX-BZ0049FCZZ 31- 19 AB C LX-BZ0324FCZZ 37- 24 AA C LX-BZ0787FCZZ 37- 5 AB C LX-BZ0787FCZZ 37- 5 AB C LX-BZ0787FCZZ 37- 5 AB C LX-BZ0828FCZZ 12- 56 AD C LX-BZ0828FCZZ 12- 56 AD C LX-BZ0921FC						
LPLTP5748FCZZ 35- 32 AD N C LPLTP5777FCZZ 33- 38 AG N D LPLTP5777FCZZ 33- 38 AG N D LPLTP5938FCZZ 33- 34- 4A AC N C LPLTP5960FCZZ 30- 44- AE N C LRALM0183FCZZ 30- 31- AG N C LRALM0184FCZZ 30- 41- AG N C LSŌU-0177FCGZ 37- 2- AP D D LSŌU-0179FCZZ 37- 2- AR D D LSTPP0314FCZZ 35- 3- AE N C LSTPP0359FCZZ 34- 65- AE N C LSTYM0261FCZZ 32- 11- AB N C LSTYM0261FCZZ 32- 11- AB N C LSTYM0288FCZZ 34- 31- AK N C LX-BZ00049FCZZ 31- 19- AB C LX-BZ00324FCZZ 31- 19- AB C LX-BZ0680FCZZ 27- 24- AA C LX-BZ0787FCZZ 37- 5- AB C LX-BZ0828FCZZ 12- 56- AB C				N.		
LPLTP5777FCZZ 33- 38 AG N D LPLTP5778FCZZ 33- 37 AG N D LPLTP5938FCZZ 33- 44 AC N C LPLTP5960FCZZ 30- 44 AE N C LRALM0183FCZZ 30- 31 AG N C LRALM0184FCZZ 30- 41 AG N C LSŌU-0177FCGZ 37- 2 AP D LSŌU-0179FCZZ 37- 2 AR D LSTPP0314FCZZ 35- 21 AA C LSTPP0359FCZZ 34- 35- 3 AE N C LSTPP0359FCZZ 34- 65 AE N C LSTYM0261FCZZ 32- 11 AB N C LSTYM0288FCZZ 34- 31 AK N C LX-BZ0049FCZZ 31- 19 AB C LX-BZ0049FCZZ 31- 22 AA C LX-BZ0465FCZZ 27- 24 AA C LX-BZ0680FCZZ 37- 5 AB C LX-BZ0787FCZZ 37- 5 AH	_, _, , , , , , , , , , , , , , , , , ,				•	
LPLTP5778FCZZ 33- 37 AG N D LPLTP5938FCZZ 33- 44 AC N C LPLTP5960FCZZ 30- 44 AE N C LRALM0183FCZZ 30- 31 AG N C LRALM0184FCZZ 30- 41 AG N C LSŌU-0177FCGZ 37- 2 AP D D LSŌU-0179FCZZ 37- 2 AR D D LSTPP0314FCZZ 35- 21 AA C C LSTPP0359FCZZ 35- 3 AE N C LSTPP0359FCZZ 34- 65 AE N C LSTYM0261FCZZ 32- 11 AB N C LSTYM0288FCZZ 34- 31 AK N C LX-BZ0049FCZZ 31- 19 AB C LX-BZ0049FCZZ 31- 19 AB C LX-BZ0324FCZZ 31- 22 AA C LX-BZ0680FCZZ 36- 5 AB C LX-BZ0680FCZZ 37- 5 AH C LX-BZ0828FCZZ 1						
LPLTP5938FCZZ 33- 44 AC N C LPLTP5960FCZZ 30- 44 AE N C LRALM0183FCZZ 30- 31 AG N C LRALM0184FCZZ 30- 41 AG N C LSŌU-0177FCGZ 37- 2 AP D D LSŌU-0179FCZZ 37- 2 AR D D LSTPP0314FCZZ 35- 21 AA C C LSTPP0359FCZZ 35- 3 AE N C LSTPP0359FCZZ 34- 65 AE N C LSTYM0261FCZZ 32- 11 AB N C LSTYM0288FCZZ 34- 31 AK N C LX-BZ0049FCZZ 31- 19 AB C LX-BZ0049FCZZ 31- 19 AB C LX-BZ0049FCZZ 31- 19 AB C LX-BZ0680FCZZ 36- 5 AB C LX-BZ0787FCZZ 37- 5 AH C LX-BZ0828FCZZ 12- 56 AD C LX-BZ0824FCZZ 27- 4 <						
LPLTP5960FCZZ 30- 44 AE N C LRALM0183FCZZ 30- 31 AG N C LRALM0184FCZZ 30- 41 AG N C LSŌU-0177FCGZ 37- 2 AP D LSŌU-0179FCZZ 37- 2 AR D LSTPP0314FCZZ 35- 21 AA C LSTPP0353FCZZ 35- 3 AE N C LSTPP0359FCZZ 34- 65 AE N C LSTYM0261FCZZ 32- 11 AB N C LSTYM0288FCZZ 34- 31 AK N C LX-BZ0049FCZZ 31- 19 AB C LX-BZ0049FCZZ 31- 19 AB C LX-BZ0324FCZZ 31- 22 AA C LX-BZ0324FCZZ 31- 22 AA C LX-BZ0680FCZZ 36- 5 AB C LX-BZ0787FCZZ 37- 5 AH C LX-BZ0828FCZZ 12- 56 AD C LX-BZ0824FCZZ 27- 4 AG C LX-BZ0931FC						
LRALM0183FCZZ 30- 31 AG N C LRALM0184FCZZ 30- 41 AG N C LSŌU-0177FCGZ 37- 2 AP D LSŌU-0179FCZZ 37- 2 AR D LSTPP0314FCZZ 35- 21 AA C LSTPP0353FCZZ 35- 3 AE N C LSTPP0359FCZZ 34- 65 AE N C LSTYM0261FCZZ 32- 11 AB N C LSTYM0288FCZZ 34- 31 AK N C LX-BZ0049FCZZ 31- 19 AB C LX-BZ0049FCZZ 31- 19 AB C LX-BZ0324FCZZ 31- 22 AA C LX-BZ0324FCZZ 31- 22 AA C LX-BZ0680FCZZ 36- 5 AB C LX-BZ0787FCZZ 37- 5 AH C LX-BZ0828FCZZ 12- 56 AD C LX-BZ0824FCZZ 27- 4 AG C LX-BZ0921FCZ1 12- 25 AE N C LX-BZ0931FC						
LRALM0184FCZZ 30- 41 AG N C LSŌU-0177FCGZ 37- 2 AP D LSŌU-0179FCZZ 37- 2 AR D LSTPP0314FCZZ 35- 21 AA C LSTPP0353FCZZ 35- 3 AE N C LSTPP0359FCZZ 34- 65 AE N C LSTYM0261FCZZ 32- 11 AB N C LSTYM0288FCZZ 34- 31 AK N C LX-BZ0004QSZZ 30- 42 AB C LX-BZ00049FCZZ 31- 19 AB C LX-BZ0324FCZZ 31- 22 AA C LX-BZ0324FCZZ 31- 22 AA C LX-BZ0680FCZZ 36- 5 AB C LX-BZ0787FCZZ 37- 5 AH C LX-BZ0828FCZZ 12- 56 AD C LX-BZ0842FCZZ 27- 4 AG C LX-BZ0921FCZ1 12- 25 AE N C LX-BZ0931FCZZ 34- 76 AC N C LX-BZ0931F						
LSŌU-0179FCZZ 37- 2 AR D LSTPP0314FCZZ 35- 21 AA C LSTPP0353FCZZ 35- 3 AE N C LSTPP0359FCZZ 34- 65 AE N C LSTYM0261FCZZ 32- 11 AB N C LSTYM0288FCZZ 34- 31 AK N C LX-BZ0004QSZZ 30- 42 AB C LX-BZ0049FCZZ 31- 19 AB C LX-BZ0324FCZZ 31- 22 AA C LX-BZ0324FCZZ 31- 22 AA C LX-BZ0680FCZZ 36- 5 AB C LX-BZ0680FCZZ 36- 5 AB C LX-BZ0787FCZZ 37- 5 AH C LX-BZ0828FCZZ 12- 56 AD C LX-BZ0828FCZZ 27- 4 AG C LX-BZ0921FCZ1 12- 25 AE N C LX-BZ0931FCZZ 34- 76 AC N C						
LSTPP0314FCZZ 35- 21 AA C LSTPP0353FCZZ 35- 3 AE N C LSTPP0359FCZZ 34- 65 AE N C LSTYM0261FCZZ 32- 11 AB N C LSTYM0288FCZZ 34- 31 AK N C LSTYM0288FCZZ 34- 31 AK N C LX-BZ0004QSZZ 30- 42 AB C LX-BZ00049FCZZ 31- 19 AB C LX-BZ0049FCZZ 31- 19 AB C LX-BZ0324FCZZ 31- 22 AA C LX-BZ0680FCZZ 36- 5 AB C LX-BZ0680FCZZ 36- 5 AB C LX-BZ0787FCZZ 27- 6 AG C LX-BZ0787FCZZ 37- 5 AH C LX-BZ0787FCZZ 37- 5 AH C LX-BZ0828FCZZ 12- 56 AD C LX-BZ0821FCZ1 12- 25 AE N C LX-BZ0921FCZ1 12- 25 AE N C LX-BZ0931FCZZ 31- 35 AA C [M] MARMP0147FCZZ 28- 10 AK N C	LSŌU-0177FCGZ	37- 2	AP			
LSTPP0353FCZZ 35- 3 AE N C LSTPP0359FCZZ 34- 65 AE N C LSTYM0261FCZZ 32- 11 AB N C LSTYM0288FCZZ 34- 31 AK N C LX-BZ0004QSZZ 30- 42 AB C LX-BZ0049FCZZ 31- 19 AB C LX-BZ0049FCZZ 31- 19 AB C LX-BZ0049FCZZ 31- 22 AA C LX-BZ0324FCZZ 31- 22 AA C LX-BZ0680FCZZ 27- 24 AA C LX-BZ0680FCZZ 36- 5 AB C LX-BZ0776FCZZ 27- 6 AG C LX-BZ0787FCZZ 37- 5 AH C LX-BZ0787FCZZ 37- 5 AH C LX-BZ0828FCZZ 12- 56 AD C LX-BZ0821FCZ1 12- 25 AE N C LX-BZ0921FCZ1 12- 25 AE N C LX-BZ0931FCZZ 34- 76 AC N C LX-WZ0119FCZZ 31- 35 AA C [M] MARMP0147FCZ2 28- 10 AK N C		37- 2			D	
LSTPP0359FCZZ 34- 65 AE N C LSTYM0261FCZZ 32- 11 AB N C LSTYM0288FCZZ 34- 31 AK N C LX-BZ0004QSZZ 30- 42 AB C LX-BZ0049FCZZ 31- 19 AB C LX-BZ0324FCZZ 31- 19 AB C LX-BZ0324FCZZ 31- 22 AA C LX-BZ0324FCZZ 37- 24 AA C LX-BZ0680FCZZ 27- 24 AA C LX-BZ0776FCZZ 27- 6 AG C LX-BZ0776FCZZ 27- 6 AG C LX-BZ0787FCZZ 37- 5 AH C LX-BZ0828FCZZ 12- 56 AD C LX-BZ0828FCZZ 12- 56 AD C LX-BZ0828FCZZ 12- 56 AD C LX-BZ0824FCZZ 27- 4 AG C LX-BZ0821FCZ1 12- 25 AE N C LX-BZ0921FCZ1 12- 25 AE N C LX-BZ0931FCZZ 34- 76 AC N C LX-WZ0119FCZZ 31- 35 AA C [M] MARMP0147FCZ2 28- 10 AK N C						
LSTYM0261FCZZ 32- 11 AB N C LSTYM0288FCZZ 34- 31 AK N C LX-BZ0004QSZZ 30- 42 AB C LX-BZ0049FCZZ 31- 19 AB C LX-BZ0324FCZZ 31- 22 AA C LX-BZ0324FCZZ 37- 24 AA C LX-BZ0680FCZZ 27- 24 AA C LX-BZ0776FCZZ 27- 6 AG C LX-BZ0787FCZZ 37- 5 AH C LX-BZ0828FCZZ 12- 56 AD C LX-BZ0821FCZ1 12- 25 AE N C LX-BZ0831FCZZ 37- 4 AG C LX-BZ0931FCZZ 34- 76 AC N C LX-BZ0931FCZZ 31- 35 AA C [M] MARMP0147FCZZ 28- 10 AK N C						
LSTYM0288FCZZ 34- 31 AK N C LX-BZ0004QSZZ 30- 42 AB C LX-BZ0049FCZZ 31- 19 AB C LX-BZ0324FCZZ 31- 22 AA C LX-BZ0324FCZZ 31- 22 AA C LX-BZ0465FCZZ 27- 24 AA C LX-BZ0680FCZZ 36- 5 AB C LX-BZ0776FCZZ 27- 6 AG C LX-BZ0776FCZZ 37- 5 AH C LX-BZ0787FCZZ 37- 5 AH C LX-BZ0828FCZZ 12- 56 AD C LX-BZ0828FCZZ 12- 56 AD C LX-BZ0842FCZZ 27- 4 AG C LX-BZ0921FCZ1 12- 25 AE N C LX-BZ0931FCZZ 34- 76 AC N C LX-BZ0931FCZZ 34- 76 AC N C LX-WZ0119FCZZ 31- 35 AA C [M] MARMP0147FCZ2 28- 10 AK N C						
LX-BZ0004QSZZ 30- 42 AB C LX-BZ0049FCZZ 31- 19 AB C LX-BZ0324FCZZ 31- 22 AA C LX-BZ0465FCZZ 27- 24 AA C LX-BZ0680FCZZ 36- 5 AB C LX-BZ0776FCZZ 27- 6 AG C LX-BZ0787FCZZ 37- 5 AH C LX-BZ0828FCZZ 12- 56 AD C LX-BZ0824FCZZ 27- 4 AG C LX-BZ0842FCZZ 27- 4 AG C LX-BZ0921FCZ1 12- 25 AE N C LX-BZ0931FCZZ 34- 76 AC N C LX-BZ0931FCZZ 31- 35 AA C LX-WZ0119FCZZ 31- 35 AA C MARMP0147FCZ2 28- 10 AK N C						
LX-BZ0049FCZZ 31- 19 AB C LX-BZ0324FCZZ 31- 22 AA C LX-BZ0465FCZZ 27- 24 AA C LX-BZ0680FCZZ 36- 5 AB C LX-BZ0776FCZZ 27- 6 AG C LX-BZ0787FCZZ 37- 5 AH C LX-BZ0828FCZZ 12- 56 AD C LX-BZ0828FCZZ 27- 4 AG C LX-BZ0842FCZZ 27- 4 AG C LX-BZ0921FCZ1 12- 25 AE N C LX-BZ0931FCZZ 34- 76 AC N C LX-WZ0119FCZZ 31- 35 AA C [M] MARMP0147FCZ2 28- 10 AK N C				N		
LX-BZ0324FCZZ 31- 22 AA C LX-BZ0465FCZZ 27- 24 AA C LX-BZ0680FCZZ 36- 5 AB C LX-BZ0776FCZZ 27- 6 AG C LX-BZ0787FCZZ 37- 5 AH C LX-BZ0828FCZZ 12- 56 AD C " 41- 3 AD C LX-BZ0842FCZZ 27- 4 AG C LX-BZ0921FCZ1 12- 25 AE N C LX-BZ0931FCZZ 34- 76 AC N C LX-WZ0119FCZZ 31- 35 AA C [M] MARMP0147FCZ2 28- 10 AK N C						
LX-BZ0465FCZZ 27- 24 AA C LX-BZ0680FCZZ 36- 5 AB C LX-BZ0776FCZZ 27- 6 AG C LX-BZ0787FCZZ 37- 5 AH C LX-BZ0828FCZZ 12- 56 AD C						
LX-BZ0680FCZZ 36- 5 AB C LX-BZ0776FCZZ 27- 6 AG C LX-BZ0787FCZZ 37- 5 AH C LX-BZ0828FCZZ 12- 56 AD C " 41- 3 AD C LX-BZ0842FCZZ 27- 4 AG C LX-BZ0921FCZ1 12- 25 AE N C LX-BZ0931FCZZ 34- 76 AC N C LX-BZ0931FCZZ 34- 76 AC N C LX-WZ0119FCZZ 31- 35 AA C [M] MARMP0147FCZ2 28- 10 AK N C						
LX-BZ0776FCZZ 27- 6 AG C LX-BZ0787FCZZ 37- 5 AH C LX-BZ0828FCZZ 12- 56 AD C " 41- 3 AD C LX-BZ0842FCZZ 27- 4 AG C LX-BZ0921FCZ1 12- 25 AE N C LX-BZ0931FCZZ 34- 76 AC N C LX-BZ0931FCZZ 34- 76 AC N C LX-WZ0119FCZZ 31- 35 AA C [M] MARMP0147FCZ2 28- 10 AK N C						
LX-BZ0787FCZZ 37- 5 AH C LX-BZ0828FCZZ 12- 56 AD C " 41- 3 AD C LX-BZ0842FCZZ 27- 4 AG C LX-BZ0921FCZ1 12- 25 AE N C " 41- 4 AE N C LX-BZ0931FCZZ 34- 76 AC N C LX-BZ0931FCZZ 31- 35 AA C [M] MARMP0147FCZ2 28- 10 AK N C						
LX-BZ0828FCZZ 12- 56 AD C " 41- 3 AD C LX-BZ0842FCZZ 27- 4 AG C LX-BZ0921FCZ1 12- 25 AE N C " 41- 4 AE N C LX-BZ0931FCZZ 34- 76 AC N C LX-WZ0119FCZZ 31- 35 AA C [M] MARMP0147FCZ2 28- 10 AK N C						
" 41- 3 AD C LX-BZ0842FCZZ 27- 4 AG C LX-BZ0921FCZ1 12- 25 AE N C " 41- 4 AE N C LX-BZ0931FCZZ 34- 76 AC N C LX-WZ0119FCZZ 31- 35 AA C [M] MARMP0147FCZ2 28- 10 AK N C						
LX-BZ0842FCZZ 27- 4 AG C LX-BZ0921FCZ1 12- 25 AE N C " 41- 4 AE N C LX-BZ0931FCZZ 34- 76 AC N C LX-WZ0119FCZZ 31- 35 AA C [M] MARMP0147FCZ2 28- 10 AK N C						
LX-BZ0921FCZ1 12- 25 AE N C " 41- 4 AE N C LX-BZ0931FCZZ 34- 76 AC N C LX-WZ0119FCZZ 31- 35 AA C [M] MARMP0147FCZ2 28- 10 AK N C						
" 41- 4 AE N C LX-BZ0931FCZZ 34- 76 AC N C LX-WZ0119FCZZ 31- 35 AA C [M] MARMP0147FCZ2 28- 10 AK N C				N		
LX-WZ0119FCZZ 31- 35 AA C [M] MARMP0147FCZ2 28- 10 AK N C						
[M] MARMP0147FCZ2 28-10 AK N C	LX-BZ0931FCZZ		AC	N	С	
MARMP0147FCZ2 28- 10 AK N C		31- 35			С	
MARMPU148FGZ2 28- 1 AK N C					_	
	IMANIME U I 48FUZZ	∠0- 1	ΑŇ	IN	U	

	T		1	T.	1
PARTS CODE	NO.	PRICE	NEW	PART	
		RANK	MARK	RANK	
MARMP0243FCZZ	33- 41	AD		С	
MARMP0248FCZZ	35- 15	ΑE		С	
MARMP0284FCZZ	34- 26	AC	N	С	
MHNG-0208FCZZ	33- 7	BA	N	С	
MHNG-0209FCZZ	34- 34	ВС	N	С	
MLEVP0794FCZZ	33- 34	AC	N	С	
MLEVP0796FCZZ	35- 14	AC	N	Č	
MLEVP0797FCZZ	35- 26	AC	N	C	
MLEVP0804FCZZ		AC	N		
	35- 16			С	
MLEVP0837FCZZ	34- 70	AC	N	С	
MSLi-0138FCZZ	31- 15	AC		С	
<i>"</i>	32- 8	AC		С	
MSPRC2865FCZ1	27- 21	AB	N	С	
MSPRC3001FCZZ	34- 69	AB	N	С	
MSPRD2870FCZ1	35- 22	AC	N	С	
MSPRD2879FCZZ	35- 27	AB	N	C	
MSPRD3002FCZZ	34- 33	AC	N	C	
MSPRD3020FCZ1	31- 49	AG	N		
				С	
MSPRP2825FCZZ	32- 14	AC	N	С	
MSPRP2830FCZZ	33- 19	AA		С	
MSPRP2832FCZZ	35- 17	AC	N	С	
MSPRP2878FCZZ	34- 8	AC	N	С	
MSPRP3009FCZZ	29- 2	AD	N	С	
MSPRP3011FCZZ	34- 39	AC	N	C	
MSPRT1563FCZZ	28- 7	AC		C	
MSPRT2846FCZZ	31- 30	AC	N	C	
MSPRT2863FCZZ	35- 31	AB	N	C	
MSPRT2864FCZZ	35- 9	AC	N	С	
[N]					
NBLTH0329FCZZ	31- 18	AG	N	В	
NBLTH0363FCZZ	34- 18	AG	N	В	
NBLTH0364FCZZ	34- 44	AG	N	В	
NBRGC0133FCZ1	31- 42	AC		С	
NBRGC0136FCZZ	34- 12	AC		С	
NBRGM0096FCZ1	34- 17	AB		Č	
NGERH0027QSZZ	31- 33	AH		C	
NGERH1476FCZZ		AD	N.I		
	34- 42		N	С	
NGERH1477FCZZ	34- 37	AC	N	С	
NGERH1478FCZZ	34- 43	ΑE	N	С	
NGERP1385FCZZ	33- 22	AF		С	
NGERR1386FCZZ	33- 21	ΑE		С	
NPLYZ0005QSZZ	31- 24	AG		С	
NPLYZ0006QSZZ	31- 26	AD		С	
NPLYZ0013QSZZ	31- 23	ΑL		С	
NPLYZ0338FCZZ	31- 20	AN		C	
NPLYZ0375FCZZ	34- 46	AC		С	
NPLYZ0397FCZZ	34- 20	AK		С	
NPLYZ0398FCZZ	34- 16	AC		С	
NPLYZ0399FCZZ	31- 9	AG	N	С	
NROLP0011QSZZ	27- 18	AD		С	
NRŌLP1364FCZZ	34- 28	AC		С	
NRŌLR1312FCZZ	34- 19	AN		С	
NRŌLR1317FCZZ	34- 21	AP		С	
NRŌLR1318FCZZ	34- 30	AR	N	C	
NRŌLR1320FCZZ	34- 50	AQ	N	C	
NSFTZ1805FCZZ	28- 5	AE	1.4	C	
NSFTZ2586FCZZ	31- 25	AS	NI.		
			N	С	
NSFTZ2599FCZ1	34- 10	AW	N	С	
NSFTZ2600FCZZ	34- 7	AM	N	С	
NSFTZ2601FCZZ	27- 20	AH	N	С	
NSFTZ2659FCZZ	35- 23	AR	N	С	
NSFTZ2678FCZZ	34- 15	AL	N	С	
[P]					
PBRSS0209FCZZ	34- 77	AG	N	В	
PCAPH0010GCZZ	26- 1	AD		D	
PCLC-0302FCZZ	34- 22	ΑТ	N	В	
PCLC-0303FCZZ	34- 14	AT	N	В	
PCLR-0426FCZZ	34- 49	AD	1.4	С	
PCLR-0471FCZZ			N		
	34- 6	AG	IN	С	
PCOVP1468FCZZ	26- 2	AD		D	
PCOVP1518FCZZ	33- 9	AE		D	
PCOVP1549FCZZ	33- 39	AU	N	D	
PCOVP1557FCZZ	12- 38	AC		С	
//	41- 5	AC		С	
	1 40 0=	AC	N	С	
PCŌVP1560FCZZ	12- 37			С	
	12- 37 41- 6	AC	N		
PCŌVP1560FCZZ		AC AS	N	D	
PCŌVP1560FCZZ // PCŌVP1566FCZZ	41- 6 27- 3	AS	N	D	
PCOVP1560FCZZ " PCOVP1566FCZZ PCOVP1593FCZZ	41- 6 27- 3 36- 3	AS AF	N N	D D	
PCÖVP1560FCZZ " PCÖVP1566FCZZ PCÖVP1593FCZZ PCÖVP1594FCZZ	41- 6 27- 3 36- 3 34- 1	AS AF AG	N N N	D D D	
PCOVP1560FCZZ " PCOVP1566FCZZ PCOVP1593FCZZ	41- 6 27- 3 36- 3	AS AF	N N	D D	

TANIS OF CALL TANIS TANI	PARTS CODE	NO.	PRICE	NEW	PART	
PCOVP1601FCZZ			RANK			
PCOVP1615FCZZ					_	
PCOVP1624FCZZ						
PCOVP1644FCZZ						
PCOVP1645FCZZ 33-24						
PCUSS0373FCZZ 34-72 AB N C PCUSS0373FCZZ 31-7 AE PCUSS0373FCZZ 31-7 AE "" 32-6 AE PGIDN1897FCZZ 34-74 AT N C PGIDN1890FCZZ 31-8 AC N C PGIDM1890FCZZ 31-8 AC N C PGIDM1900FCZZ 27-16 AR N C PGIDM1901FCZZ 27-17 AQ N C PGIDM1901FCZZ 27-17 AQ N C PGIDM1901FCZZ 27-17 AQ N C PGIDM1961FCZZ 27-17 AQ N C PGIDM1963FCZZ 31-50 AC N C PGIDM1963FCZZ 31-50 AC N C PGIDM1963FCZZ 31-50 AC N C PGUMS0002CSZ 31-32 AL C PGUMS0002CSZ 31-32 AL C PGUMS0298FCZZ 33-15 AC N C PMAGT0072FCZZ 35-11 AF C PMAGT0072FCZZ 35-11 AF C PMIR-0164FCZZ 32-13 AP N B PMIR-0165FCZZ 31-13 AP N B PMIR-0165FCZZ 34-56 AB N C PMLT-1257FCZZ 34-56 AB N C PMLT-1270FCZZ 34-56 AB N C PMLT-1271FCZZ 34-36 AB N C PMLT-1284FCZZ 30-47 AE N C PMLT-1271FCZZ 33-38 AB N C PMLT-1284FCZZ 30-47 AE N C PMLT-1284FCZZ 30-47 AE N C PMLT-1284FCZZ 30-47 AE N C PMLT-1284FCZZ 33-45 AB N C PMLT-1284FCZZ 33-45 AB N C PMLT-1284FCZZ 33-45 AB N C PMLT-1284FCZZ 36-8 AE N C PMLT-1284FCZZ 36-8 AE N C PMLT-1284FCZZ 36-8 AE N C PSHEP4915FCCZ 33-45 AB N C PMLT-1284FCZZ 36-8 AE N C PSHEP4915FCCZ 33-50 AB N C PMLT-1284FCZZ 36-8 AE N C PSHEP4915FCCZ 34-58 AD N C PSHEP4915FCCZ 31-58 AB N C PMLT-1284FCZZ 36-8 AE N C PSHEP4917FCCZ 34-58 AD N C PSHEP4917FCCZ 34-58 AD N C PSHEP4917FCCZ 34-58 AD N C PSHEP4927FCC1 17-13 AR N D PSHEP4927FCC1 17-13 AR N D PSHEP4927FCC1 17-13 AR N D PSHEP4927FCC2 37-30 AB N C PSHEP4927FCC2 38-3 AP N C PSHEP4937FCCZ 38-4 AB N C PSHEP4937FCCZ 38-5 AB N C PSHEP4937FCCZ						
PCUSS0373FCZZ 34-72 AB N C PCUSS03FCZZ 31-7 AE C "" 32-6 AE C "" 32-6 AE C "" 9G1DH1897FCZZ 34-74 AT N C PG1DM1899FCZZ 31-8 AC N C PG1DM1899FCZZ 35-30 AY N C PG1DM1991FCZZ 27-16 AR N C PG1DM1991FCZZ 27-17 AQ N C PG1DM1953FCZZ 34-4 AS N C PG1DM1963FCZZ 34-4 AS N C PG1DM1963FCZZ 34-5 AC N C PG1DM1963FCZZ 34-5 AV N C PG1DM1963FCZZ 34-5 AV N C PG1DM1963FCZZ 34-5 AV N C PG1DM1964FCZZ 31-50 AC N C PG1DM296FCZZ 33-150 AC N C PGUMS002GSZZ 34-75 AV N C PGUMS0283FCZI 33-20 AD N C PGUMS0298FCZZ 33-10 AD N C PGUMS0298FCZZ 33-13 AP N B PMRF10164FCZZ 32-13 AP N B PMRF10165FCZZ 32-13 AP N B PMRF1015FCZZ 32-13 AP N B PMRT-1256FCZZ 37-30 AB N C PMLT-1270FCZZ 35-28 AB N C PMLT-1284FCZZ 33-2 AB N C PMLT-1284FCZZ 33-2 AB N C PMLT-1284FCZZ 33-3 AR N C PREFL0172FCZZ 33-3 AR N C PMLT-1284FCZZ 33-3 AR N C PSHEP49484FCZZ 33-3 AR N C PSHEP4947FCZZ 33-3 AR N C PMLT-1270FCZZ 34-3 AB N C PMLT-1284FCZZ 30-47 AE N C PSHEP4947FCZZ 33-2 AB N C PSHEP4927FCZZ 34-5 AE N C PSHEP4927FCZZ 34-6 AE N C PSHEP4927FCZZ 34-6 AE N C PSHEZ48949FCZZ 34-6 AE N C PSHEZ48949FCZZ 34-7 AB N	PCUSF0334FCZZ	32- 10	AP		С	
PCUSU0203FCZZ		34- 64	AD	N	С	
				N		
PGIDH1897FCZZ						
PGIDM1890FCZZ 35-30 AY N C PGIDM1990FCZZ 27-16 AR N C PGIDM1900FCZZ 27-17 AQ N C PGIDM1901FCZZ 27-17 AQ N C PGIDM1953FCZZ 34-4 AS N C PGIDM1953FCZZ 34-5 AS N C PGIDM1964FCZZ 34-50 AC N C PGIDM1964FCZZ 34-50 AC N C PGISM103FCZZ 34-75 AV N C PGLSP0103FCZZ 34-75 AV N C PGLSP0103FCZZ 34-75 AV N C PGUMS0283FCZI 30-29 AA N C PGUMS0298FCZZ 33-20 AD N C PGUMS0298FCZZ 33-20 AD N C PGUMS0298FCZZ 33-15 AC N C PGUMS0298FCZZ 33-15 AC N C PMAGT0072FCZZ 35-11 AF C PMIR-0164FCZZ 32-13 AP N B PMIR-0165FCZZ 31-13 AP N B PMIR-0165FCZZ 31-13 AP N B PMIR-1256FCZZ 27-29 AC N C PMLT-1270FCZZ 35-28 AB N C PMLT-1270FCZZ 35-28 AB N C PMLT-1271FCZZ 36-28 AB N C PMLT-1278FCZZ 30-47 AE N C PMLT-1284FCZZ 30-47 AE N C PMLT-1284FCZZ 30-47 AE N C PMLT-1286FCZZ 33-2 AD N C PSHEP4916FCZI 33-3 AP N C PSHEP4916FCZI 33-3 AC N C PSHEP4916FCZI 33-3 AC N C PSHEP4917FCZZ 34-58 AD N C PSHEP4927FCZZ 34-58 AD N C PSHEP4927FCZZ 34-58 AD N C PSHEP4927FCZZ 34-58 AD N C PSHEP4917FCZZ 34-58 AD N C PSHEP4917FCZZ 34-58 AD N C PSHEP4917FCZZ 34-58 AD N C PSHEP4927FCZZ 34-78 AD N C PSHEP4927FCZZ 34-78 AD N C PSHEP4927FCZZ 34-78 AD N C PSHEP4927FCZZ 34-				N.		
PGIDM1899FCZZ 27-16 AR N C PGIDM1901FCZZ 27-16 AR N C PGIDM1901FCZZ 27-17 AQ N C PGIDM1901FCZZ 27-17 AQ N C PGIDM1901FCZZ 27-17 AQ N C PGIDM1953FCZZ 34-4 AS N C PGIDM1953FCZZ 34-5 AC N C PGIDM1964FCZZ 31-50 AC N C PGIDM1964FCZZ 31-50 AC N C PGIDM1002QSZZ 31-32 AL C C PGUMS002QSZZ 31-32 AL N C PGUMS0283FCZI 30-29 AA N C PGUMS0298FCZZ 33-20 AD N C PGUMS0298FCZZ 33-15 AC N C PGUMS0298FCZZ 33-15 AC N C PGUMS0299FCZZ 33-15 AC N C PGUMS0299FCZZ 33-15 AC N C PMAGT0072FCZZ 35-11 AF C C PMAGT0072FCZZ 35-11 AF C C PMAGT0072FCZZ 35-11 AF C C PMIR-0165FCZZ 31-13 AP N B PMIR-0165FCZZ 31-13 AP N B PMIR-1155FCZZ 27-29 AC N C C PMLT-1270FCZZ 34-55 AB N C PMLT-1284FCZZ 30-47 AE N C PMLT-1284FCZZ 36-8 AC N C PSHEP4848FCZZ 33-2 AD N C PSHEP4848FCZZ 34-55 AC N C PSHEP4848FCZZ 35-20 AB N C PSHEP4915FCZZ 34-55 AC N C PSHEP4917FCZZ 37-29 AC N C PSHEP4917FCZZ 37-29 AB N C PSHEP4917FCZZ 37-29 AB N C PSHEP4927FCZZ 37-30 AB N C PSH						
PG DM1 9 0 1 F CZZ						
PGIDM1901FCZZ						
PGIDM1953FCZZ 34- 4 AS N C PGIDM1964FCZZ 31-50 AC N C C PGLSP0103FCZZ 31-75 AV N C PGUMS0002QSZZ 31-32 AL C PGUMS002285FCZI 30-29 AA N C PGUMS02285FCZI 30-29 AA N C PGUMS02296FCZZ 33-20 AD N C PGUMS0298FCZZ 33-15 AC N C PGUMS0299FCZZ 33-15 AC N C PGUMS0299FCZZ 33-15 AC N C PMAGT0072FCZZ 35-11 AF C PMIR-0164FCZZ 32-13 AP N B PMIR-0165FCZZ 31-13 AP N B PMIR-0165FCZZ 27-30 AB N C PMIR-0125FCZZ 27-30 AB N C PMIR-1279FCZZ 27-30 AB N C PMIR-1279FCZZ 34-55 AB N C PMIR-1279FCZZ 34-55 AB N C PMIR-1279FCZZ 34-55 AB N C PMIR-1279FCZZ 34-56 AB N C PMIR-1279FCZZ 34-56 AB N C PMIR-1282FCZZ 30-47 AE N C PMIR-1284FCZZ 36-28 AB N C PMIR-1286FCZZ 33-2 AD N C PMIR-1286FCZZ 34-56 AB N C PMIR-1286FCZZ 33-2 AD N C PMIR-1286FCZZ 33-2 AD N C PMIR-1286FCZZ 34-56 AB N C PMIR-1286FCZZ 34-56 AB N C PMIR-1286FCZZ 33-2 AD N C PMIR-1286FCZZ 34-56 AB N C PMIR-1286FCZZ 34-56 AB N C PSHEP44916FCZI 34-58 AD N C PSHEP44916FCZI 34-58 AD N C PSHEP4915FCZZ 34-58 AD N C PSHEP4927FCI 17-13 AR N D PSHEP4927FCI 17-13 AR N D PSHEP4927FCZI 17-13 AR N D						
PGLSP0103FCZZ	PGiDM1953FCZZ			N		
PGUMS01020SZZ	PGiDM1964FCZZ	31- 50	AC	N	С	
PGUMS0285FCZ1 30-29 AA N C C PGUMS0298FCZZ 33-20 AD N C C PGUMS0298FCZZ 33-20 AD N C C PGUMS0298FCZZ 33-25 AH N C PGUMS0299FCZZ 33-25 AH N C PMAGT0072FCZZ 35-11 AF C C PMAGT0072FCZZ 35-11 AF N B PMIR-0164FCZ 31-13 AP N B PMIR-0165FCZ 31-13 AP N B PMIR-0165FCZ 27-29 AC N C PMLT-1256FCZZ 27-20 AB N C PMLT-1256FCZZ 27-30 AB N C PMLT-1270FCZ 34-55 AB N C PMLT-1270FCZ 34-55 AB N C PMLT-1271FCZZ 35-28 AB N C PMLT-1272FCZZ 35-28 AB N C PMLT-1284FCZZ 36-8 AB N C PMLT-1286FCZZ 30-47 AE N C PMLT-1286FCZZ 33-20 AD N C PSHEP4846FCZZ 33-20 AB N C PSHEP4846FCZZ 34-58 AD N C PSHEP4846FCZZ 34-58 AD N C PSHEP4915FCZZ 34-58 AD N C PSHEP4915FCZZ 34-58 AD N C PSHEP4915FCZZ 34-58 AD N C PSHEP4927FC10 17-13 AR N D PSHEP4927FC10 17-13 AR N D PSHEP4927FCZ1 17-13 AR N D PSHEP4927FCZ2 17-13 AR N D PSHEP4927FCZ2 17-13 AR N D PSHEP4927FCZ2 17-13 AR N D PSHEP4927FCZ3 17-13 AR N D PSHEP4927FCZ3 17-13 AR N D PSHEP4927FCZ4 17-13 AR N D PSHEP4927FCZ5 17-13 AR N	PGLSP0103FCZZ	34- 75	ΑV	N	С	
PGUMS0 29 8 F C ZZ 33 - 20 AD N C PGUMS0 29 8 F C ZZ 33 - 25 AH N C PGUMS0 29 9 F C ZZ 33 - 25 AH N C PMAGT0 07 2 F C ZZ 35 - 11 AF C PMAGT0 07 2 F C ZZ 32 - 13 AP N B PMIR - 01 6 5 F C ZZ 31 - 13 AP N B PMIR - 01 6 5 F C ZZ 31 - 13 AP N B PMIR - 01 6 5 F C ZZ 31 - 13 AP N B PMIR - 01 6 5 F C ZZ 31 - 13 AP N B PMIR - 01 6 5 F C ZZ 31 - 13 AP N B PMIR - 01 6 5 F C ZZ 31 - 13 AP N B PMIR - 01 6 5 F C ZZ 32 - 30 AB N C C PMIR - 1 2 5 7 F C ZZ 27 - 29 AC N C C PMIR - 1 2 5 7 F C ZZ 27 - 30 AB N C C PMIR - 1 2 7 7 F C ZZ 34 - 55 AB N C C PMIR - 1 2 7 7 F C ZZ 34 - 55 AB N C C PMIR - 1 2 8 2 F C ZZ 34 - 55 AB N C C PMIR - 1 2 8 2 F C ZZ 34 - 3 AB N C C PMIR - 1 2 8 2 F C ZZ 34 - 3 AB N C C PMIR - 1 2 8 4 F C ZZ 34 - 3 AB N C C PMIR - 1 2 8 4 F C ZZ 34 - 3 AB N C C PMIR - 1 2 8 4 F C ZZ 34 - 3 AB N C C PMIR - 1 2 8 4 F C ZZ 34 - 3 AB N C C PMIR - 1 2 8 4 F C ZZ 34 - 3 AB N C C PMIR - 1 2 8 4 F C ZZ 34 - 3 AB N C C PMIR - 1 2 8 4 F C ZZ 34 - 3 AB N C C PMIR - 1 2 8 4 F C ZZ 34 - 3 AB N C C PMIR - 1 2 8 4 F C ZZ 34 - 3 AB N C C PMIR - 1 2 8 4 F C ZZ 34 - 3 AB N C C PMIR - 1 2 8 4 F C ZZ 34 - 5 AB N C C PMIR - 1 2 8 4 F C ZZ 34 - 5 AB N C C PMIR - 1 2 8 4 F C ZZ 34 - 5 AB N C C PMIR - 1 2 8 4 F C ZZ 34 - 5 AB N C C PMIR - 1 3 AB N D D D		31- 32			С	
PGUMS0 29 8 F C ZZ 33-15						
PGUMS0 29 9 F C Z						
PMAGT0072FCZZ 35-11 AF C C PMIR-0164FCZZ 32-13 AP N B PMIR-0165FCZZ 31-13 AP N B PMIR-0165FCZZ 31-13 AP N B PMIR-0165FCZZ 27-29 AC N C PMLT-1256FCZZ 27-29 AC N C PMLT-1257FCZZ 27-30 AB N C PMLT-1271FCZZ 34-55 AB N C PMLT-1271FCZZ 34-55 AB N C PMLT-1271FCZZ 34-35 AB N C PMLT-1271FCZZ 34-35 AB N C PMLT-1272FCZZ 34-35 AB N C PMLT-1284FCZZ 34-3 AB N C PMLT-1284FCZZ 36-8 AE N C PMLT-1284FCZZ 33-2 AD N C PREFL0172FCZZ 33-3 AK B PRNGP0090FCZZ 33-42 AA C C PSHEP4846FCZZ 34-58 AD N C PSHEP4846FCZZ 34-58 AD N C PSHEP4846FCZZ 34-58 AD N C PSHEP4915FCZZ 34-5 AE N C PSHEP4916FCZI 34-5 AE N C PSHEP4916FCZI 34-73 AF N C PSHEP4927FCZI 17-13 AR N D PSHEP4927FCZI 17-13 AR N D D PSHEP4927FCZZ 17-14 AR N D D D D D D D D D D D D D D D D D D						
PMIR-0164FCZZ 32-13				IN		
PMIR-0165FCZZ 31-13 AP N B PMLT-1256FCZZ 27-29 AC N C PMLT-1257FCZZ 27-30 AB N C PMLT-1271FCZZ 34-55 AB N C PMLT-1271FCZZ 34-55 AB N C PMLT-1271FCZZ 34-55 AB N C PMLT-1271FCZZ 34-35 AB N C PMLT-1272FCZZ 34-3 AB N C PMLT-1272FCZZ 34-3 AB N C PMLT-1282FCZZ 30-47 AE N C PMLT-1284FCZZ 36-8 AE N C PREFL0172FCZZ 32-3 AK B PRNOP0090FCZZ 33-42 AA C PSHEP44846FCZZ 34-58 AD N C PSHEP4846FCZZ 34-58 AD N C PSHEP4915FCZZ 34-5 AB N C PSHEP4916FCZI 34-73 AF N C PSHEP4916FCZI 34-73 AF N C PSHEP4927FCZI 17-13 AR N D PSHEP4927FCZI 17-13 AR N D PSHEP4927FCZI 17-13 AR N D PSHEP4927FCZZ 30-7 AD N C PSHEP4927FCZZ 30-7 AD N C PSHEP4927FCZZ 30-7 AD N C PSHEP4927FCZZ 30-27 AD N C PSHEZ4841FCZI 30-40 AD N C PSHEZ4841FCZI 30-40 AD N C PSHEZ4843FCZZ 30-27 AD N C PSHEZ4845FCZZ 33-1 AV N C PSHEZ4878FCZZ 33-1 AV N C PSHEZ495FCZZ 34-38 AE N C PSHEZ495FCZZ 34-38 AE N C PSHEZ495FCZZ 34-38 AE N C PSHEZ495FCZZ 33-1 AV N C PSHEZ495FCZZ 34-18 AC N C PSHEZ495FCZZ 33-1 AC N C QCNCM0829FCZZ 33-1 AC N C QCNCM0829FCZZ 33-1 AC N C QCNCM1166FCZZ 36-5 AP N C QCNCM1166FCZZ 36				N	_	
PMLT-1256FCZZ 27-30 AB N C PMLT-1270FCZZ 34-55 AB N C PMLT-1270FCZZ 34-55 AB N C PMLT-1271FCZZ 35-28 AB N C PMLT-1271FCZZ 35-28 AB N C PMLT-1272FCZZ 34-3 AB N C PMLT-1272FCZZ 34-3 AB N C PMLT-1282FCZZ 30-47 AE N C PMLT-1284FCZZ 30-47 AE N C PMLT-1284FCZZ 30-47 AE N C PMLT-1284FCZZ 36-8 AE N C PMLT-1286FCZZ 33-2 AD N C PREFL0172FCZZ 32-3 AK BPRNGP0090FCZZ 33-42 AA C PSHEP4846FCZZ 34-58 AD N C PSHEP4846FCZZ 34-58 AD N C PSHEP4915FCZZ 34-58 AD N C PSHEP4915FCZZ 34-58 AD N C PSHEP4916FCZI 34-73 AF N C PSHEP4927FC10 17-13 AR N D PSHEP4927FC11 17-13 AR N D PSHEP4927FC21 17-13 AR N D PSHEP4927FC21 17-13 AR N D PSHEP4927FC22 17-13 AR N D PSHEP4927FC23 17-13 AR N D PSHEP4927FC24 17-13 AR N D PSHEP4927FCZ6 17-13 AR N D PSHEP4927FCZ7 17-13 AR N D PSHEP4927FCZ6 17-13 AR N D PSHEP4927FCZ7 17-13 AR N D PSHEP4927FCZ6 17-13 AR N D PSHEP4927FCZ6 17-13 AR N D PSHEP4927FCZ6 17-13 AR N D PSHEP4927FCZ7 17-13 AR N D PSHEP4927FCZ7 17-13 AR N D PSHEP4927FCZ6 17-13 AR N D PSHEP4927FCZ7 17-13 AR N D PSHE						
PMLT-1257FCZZ						
PMLT-1271FCZZ 35-28 AB N C PMLT-1272FCZZ 34-3 AB N C " 35-2 AB N C " 35-2 AB N C PMLT-1282FCZZ 30-47 AE N C PMLT-1284FCZZ 36-8 AE N C PMLT-1286FCZZ 36-8 AE N C PREFL0172FCZZ 32-3 AK B N C PREFL0172FCZZ 32-3 AK B N C PREFL0172FCZZ 33-42 AA C PSHEP4846FCZZ 34-58 AD N C PSHEP4915FCZZ 34-5 AE N C PSHEP4915FCZZ 34-5 AE N C PSHEP4916FCZI 34-73 AF N C PSHEP4927FCI 17-13 AR N D PSHEP4927FCZI 17-13 AR N D PSHEP4927FCZZ 30-27 AD N C PSHEP4937FCZZ 35-29 AB N C PSHEP4937FCZZ 36-29 AB N C PSHEZ4841FCZI 30-40 AD N C PSHEZ48436FCZZ 30-27 AD N C PSHEZ4843FCZZ 30-27 AD N C PSHEZ4843FCZZ 30-27 AD N C PSHEZ4843FCZZ 30-27 AD N C PSHEZ4845FCZZ 33-13 AC N C PSHEZ4847FCZZ 35-19 AL N C PSHEZ4847FCZZ 36-19 AL N C PSHEZ4906FCZZ 33-13 AC N C PSHEZ4906FCZZ 33-13 AC N C PSHEZ4907FCZZ 31-16 AQ N B PWIR-0192FCZZ 31-16 AQ N B PWIR-0192FCZZ 31-17 AG N C QCNCM0829FCZZ 33-13 AC N C QCNCM0829FCZZ 33-14 AE C QCNCM0829FCZZ 33-24 AE C QCNCM1466FCZZ 33-3 AK N C						
PMLT-1271FCZZ						
// 35- 2 AB N C PMLT-1284FCZZ 30- 47 AE N C PMLT-1286FCZZ 30- 47 AE N C PMLT-1286FCZZ 33- 2 AD N C PRNGP0090FCZZ 33- 22 AD N C PSHEP4846FCZZ 32- 3 AK B PSHEP4846FCZZ 33- 42 AA C PSHEP4848FCZZ 35- 20 AB N C PSHEP4915FCZZ 34- 5 AE N C PSHEP4916FCZ1 34- 73 AF N C PSHEP4927FC10 17- 13 AR N D PSHEP4927FCZ1 17- 13 AR N D PSHEP4927FCZ1 17- 13 AR N D PSHEP4927FCZ3 17- 13 AR N D PSHEP4927FCZ4 17- 13 AR N D PSHEP4927FCZ5 17- 13 AR N D<	PMLT-1271FCZZ		AB	N	С	
PMLT-1282FCZZ 30-47 AE N C PMLT-1284FCZZ 36-8 AE N C PMLT-1286FCZZ 33-2 AD N C PREFL0172FCZZ 32-3 AK B PRNGP0090FCZZ 32-3 AK B PRNGP0090FCZZ 33-42 AA C PSHEP4846FCZZ 34-58 AD N C PSHEP4846FCZZ 34-58 AD N C PSHEP4846FCZZ 34-58 AD N C PSHEP4915FCZZ 34-5 AE N C PSHEP4915FCZZ 34-5 AE N C PSHEP4917FC10 17-13 AR N D PSHEP4927FC11 17-13 AR N D PSHEP4927FCZ1 17-13 AR N D PSHEP4927FCZ2 17-13 AR N D PSHEP4927FCZ2 17-13 AR N D PSHEP4927FCZ2 17-13 AR N D PSHEP4927FCZ4 17-13 AR N D PSHEP4927FCZ5 17-13 AR N D PSHEP4927FCZ6 17-13 AR N D PSHEP4927FCZ7 17-13 AR N D PSHEP4927FCZ6 17-13 AR N D PSHEP4927FCZ6 17-13 AR N D PSHEP4927FCZ7 30-7 AD N C PSHEP4937FCZZ 30-7 AD N C PSHEZ4845FCZZ 30-43 AB N C PSHEZ4845FCZZ 30-27 AD N C PSHEZ4844FCZZ 30-32 AC N C PSHEZ4845FCZZ 33-1 AV N C PSHEZ4847FCZZ 35-19 AL N C PSHEZ4847FCZZ 35-19 AL N C PSHEZ4847FCZZ 35-19 AB N C PSHEZ4847FCZZ 36-3 AP C QCNCM0829FCZZ 34-38 AE N C PSHEZ4906FCZZ 34-38 AE N C PSHEZ495FFCZZ 34-38 AE N C QCNCM0829FCZZ 39-2 AG C QCNCM0829FCZZ 39-3 AK N C QCNCM0829FCZZ 39-3 AK N C QCNCM0829FCZZ 39-3 AK N C QCNCM01466FCZZ 26-5 AP N C QCNCM01466FCZZ 26-6 AP N C QCNCM11466FCZZ 39-3 AK N C		34- 3	AB	N	С	
PMLT-1284FCZZ 36-8						
PMLT-1286FCZZ 33- 2 AD N C PREFL0172FCZZ 32- 3 AK B PRNGP0090FCZZ 33- 42 AA C PSHEP4846FCZZ 33- 45 AD N C PSHEP4846FCZZ 34- 58 AD N C PSHEP4815FCZZ 34- 5 AE N C PSHEP4916FCZI 34- 73 AF N C PSHEP4916FCZI 34- 73 AF N C PSHEP4927FC10 17- 13 AR N D PSHEP4927FC11 17- 13 AR N D PSHEP4927FCZI 17- 13 AR N D PSHEP4927FCZI 17- 13 AR N D PSHEP4927FCZZ 30- 27 AD N C PSHEZ4836FCZZ 30- 32 AB N C PSHEZ4841FCZI 30- 40 AD N C PSHEZ4843FCZZ 30- 32 AC N C PSHEZ4843FCZZ 33- 1 AV N C PSHEZ487FCZZ 35- 19 AL N C PSHEZ487FCZZ 35- 18 AC N C PSHEZ487FCZZ 35- 19 AL N C PSHEZ487FCZZ 35- 19 AL N C PSHEZ487FCZZ 35- 19 AL N C PSHEZ487FCZZ 35- 18 AC N C PSHEZ487FCZZ 35- 19 AL N C PSHEZ487FCZZ 35- 19 AL N C PSHEZ487FCZZ 35- 19 AL N C PSHEZ487FCZZ 35- 19 AB C N C PSHEZ487FCZZ 35- 19 AL N C PSHEZ487FCZZ 35- 19 AB C N C PSHEZ487FCZZ 35- 19 AL N C PSHEZ487FCZZ 35- 19 AB C N C PSHEZ487FCZZ						
PREFLO172FCZZ 32- 3 AK B PRNGP0090FCZZ 33- 42 AA C PSHEP4846FCZZ 34- 58 AD N C PSHEP4846FCZZ 34- 58 AD N C PSHEP4846FCZZ 34- 58 AD N C PSHEP4915FCZZ 34- 5 AE N C PSHEP4916FCZI 34- 73 AF N C PSHEP492FC10 17- 13 AR N D PSHEP4927FC11 17- 13 AR N D PSHEP4927FCZ1 17- 13 AR N D PSHEP4927FCZ2 17- 13 AR N D PSHEP4927FCZ3 17- 13 AR N D PSHEP4927FCZ3 17- 13 AR N D PSHEP4927FCZ3 17- 13 AR N D PSHEP4927FCZ4 17- 13 AR N D PSHEP4927FCZ5 17- 13 AR N D PSHEP4927FCZ5 17- 13 AR N D PSHEP4927FCZ6 17- 13 AR N D PSHEP4927FCZ7 17- 13 AR N D PSHEP4927FCZ8 17- 13 AR N D PSHEP4927FCZ7 30- 30- 30- 30- 30- 30- 30- 30- 30- 30-						
PRNGP0090FCZZ 33-42 AA C PSHEP4846FCZZ 34-58 AD N C PSHEP4848FCZZ 35-20 AB N C PSHEP4915FCZZ 34-5 AE N C PSHEP4916FCZ1 34-73 AF N C PSHEP4916FCZ1 34-73 AF N D PSHEP4927FC10 17-13 AR N D PSHEP4927FCZ1 17-13 AR N D PSHEP4927FCZ2 17-13 AR N D PSHEP4927FCZ2 17-13 AR N D PSHEP4927FCZ3 17-13 AR N D PSHEP4927FCZ4 17-13 AR N D PSHEP4927FCZ5 17-13 AR N D PSHEP4927FCZ6 17-13 AR N D PSHEP4927FCZ6 17-13 AR N D PSHEP4927FCZ7 17-13 AR N D PSHEP4927FCZ6 17-13 AR N D PSHEP4927FCZ6 17-13 AR N D PSHEP4927FCZ7 17-13 AR N D PSHEP4927FCZ7 17-13 AR N D PSHEP4927FCZ8 17-13 AR N D PSHEP4927FCZ7 17-13 AR N D PSHEP4927FCZ8 17-13 AR N D PSHEP4927FCZ7 17-13 AR N D PSHEP4927FCZZ 30- 7 AD N C PSHEZ4846FCZZ 30- 43 AB N C PSHEZ4846FCZZ 30- 43 AB N C PSHEZ4847FCZZ 35- 19 AD N C PSHEZ4844FCZZ 30- 32 AC N C PSHEZ4844FCZZ 30- 32 AC N C PSHEZ4844FCZZ 30- 32 AC N C PSHEZ4847FCZZ 35- 19 AL N C PSHEZ4847FCZZ 35- 19 AL N C PSHEZ4847FCZZ 35- 18 AC N C PSHEZ4847FCZZ 35- 18 AC N C PSHEZ4949FCZZ 34- 78 AC N C PSHEZ4949FCZZ 33- 18 AC N C PSHEZ4949FCZZ 34- 78 AC N C PSHEZ4949FCZZ 34- 78 AC N C PSHEZ495FCZZ 31- 17 AQ N B PWIR-0191FCZZ 31- 17 AQ N B PWIR-0191FCZZ 31- 17 AQ N B PWIR-0192FCZZ 31- 16 AQ N B PWIR-0192FCZZ 31- 16 AC N C QCNCM0829FCZZ 39- 2 AG C QCNCM0829FCZZ 39- 2 AG C QCNCM0880FCZZ 39- 2 AG C QCNCM0880FCZZ 39- 2 AG C QCNCM01166FCZZ 39- 3 AK N C				N		
PSHEP4846FCZZ 34-58 AD N C PSHEP4915FCZZ 35-20 AB N C PSHEP4915FCZZ 34-5 AE N C PSHEP4916FCZ1 34-73 AF N C PSHEP4916FCZ1 34-73 AF N C PSHEP4927FC10 17-13 AR N D PSHEP4927FCZ1 17-13 AR N D PSHEP4927FCZ2 17-13 AR N D PSHEP4927FCZ2 17-13 AR N D PSHEP4927FCZ3 17-13 AR N D PSHEP4927FCZ4 17-13 AR N D PSHEP4927FCZ5 17-13 AR N D PSHEP4927FCZ5 17-13 AR N D PSHEP4927FCZ6 17-13 AR N D PSHEP4927FCZ6 17-13 AR N D PSHEP4927FCZ6 17-13 AR N D PSHEP4927FCZ7 17-13 AR N D PSHEP4927FCZ6 17-13 AR N D PSHEP4927FCZ7 17-13 AR N D PSHEP4927FCZ8 17-13 AR N D PSHEP4927FCZ9 17-13 AR N D PSHEP4927FCZ 17-13 AR N D PSHEP4927FCZ 17-13 AR N D PSHEP4927FCZ 30-7 AD N C PSHEP4937FCZZ 35-29 AB N C PSHEZ4836FCZZ 30-43 AB N C PSHEZ4844FCZI 30-40 AD N C PSHEZ48445FCZZ 30-27 AD N C PSHEZ48445FCZZ 30-32 AC N C PSHEZ4845FCZZ 33-1 AV N C PSHEZ4847FCZZ 35-18 AC N C PSHEZ4847FCZZ 35-18 AC N C PSHEZ4847FCZZ 34-38 AE N C PSHEZ4906FCZZ 29-24 AC N C PSHEZ4949FCZZ 34-38 AE N C PSHEZ4957FCZZ 34-78 AC N C PSHEZ4957FCZZ 33-17 AQ N B PSHEZ4957FCZZ 31-16 AQ N B PWIR-0191FCZZ 31-17 AQ N B PWIR-0191FCZZ 31-17 AQ N B PWIR-0191FCZZ 31-16 AQ N B PWIR-0191FCZZ 31-16 AQ N B PWIR-0192FCZZ 39-2 AG C QCNCM0828FCZZ 39-1 AE C QCNCM0829FCZZ 39-2 AG C QCNCM0820FCZZ 39-2 AG C QCNCM01146FCZZ 26-4 AE N C QCNCM1146FCZZ 26-5 AP N C QCNCM1146FCZZ 26-5 AP N C QCNCM1146FCZZ 36-5 AP N C QCNCM1146FCZZ 39-3 AK N C						
PSHEP4915FCZZ 34- 5 AE N C PSHEP4916FCZ1 34- 5 AE N C PSHEP4916FCZ1 34- 73 AF N C PSHEP4927FC10 17- 13 AR N D PSHEP4927FC11 17- 13 AR N D PSHEP4927FCZ1 17- 13 AR N D PSHEP4927FCZ2 17- 13 AR N D PSHEP4927FCZ3 17- 13 AR N D PSHEP4927FCZ3 17- 13 AR N D PSHEP4927FCZ4 17- 13 AR N D PSHEP4927FCZ5 17- 13 AR N D PSHEP4927FCZ5 17- 13 AR N D PSHEP4927FCZ6 17- 13 AR N D PSHEP4927FCZ6 17- 13 AR N D PSHEP4927FCZ7 17- 13 AR N D PSHEP4927FCZ7 17- 13 AR N D PSHEP4927FCZ8 17- 13 AR N D PSHEP4927FCZ8 17- 13 AR N D PSHEP4927FCZ8 17- 13 AR N D PSHEP4927FCZ7 17- 13 AR N D PSHEP4937FCZZ 30- 7 AD N C PSHEP4937FCZZ 30- 7 AD N C PSHEZ4836FCZZ 30- 43 AB N C PSHEZ4834FCZZ 30- 43 AB N C PSHEZ4834FCZZ 30- 27 AD N C PSHEZ4834FCZZ 30- 32 AC N C PSHEZ4845FCZZ 33- 1 AV N C PSHEZ4847FCZZ 35- 19 AL N C PSHEZ4847FCZZ 35- 18 AC N C PSHEZ4957FCZZ 34- 38 AE N C PSHEZ49				N		
PSHEP4915FCZZ 34- 5 AE N C PSHEP4916FCZ1 34- 73 AF N C PSHEP4927FC10 17- 13 AR N D PSHEP4927FC11 17- 13 AR N D PSHEP4927FCZ1 17- 13 AR N D PSHEP4927FCZ2 17- 13 AR N D PSHEP4927FCZ2 17- 13 AR N D PSHEP4927FCZ3 17- 13 AR N D PSHEP4927FCZ4 17- 13 AR N D PSHEP4927FCZ5 17- 13 AR N D PSHEP4927FCZ6 17- 13 AR N D PSHEP4927FCZ6 17- 13 AR N D PSHEP4927FCZ7 17- 13 AR N D PSHEP4927FCZ6 17- 13 AR N D PSHEP4927FCZ7 17- 13 AR N D PSHEP4927FCZ8 17- 13 AR N D PSHEP4927FCZ9 17- 13 AR N D PSHEP4927FCZ2 17- 13 AR N D PSHEP4937FCZ2 30- 7 AD N C PSHEP4937FCZ2 30- 7 AD N C PSHEP4937FCZ2 30- 43 AB N C PSHEZ4846FCZZ 30- 43 AB N C PSHEZ4846FCZZ 30- 32 AC N C PSHEZ4843FCZZ 30- 32 AC N C PSHEZ4844FCZZ 30- 32 AC N C PSHEZ4845FCZZ 35- 19 AL N C PSHEZ4845FCZZ 35- 19 AL N C PSHEZ4846FCZZ 34- 38 AE N C PSHEZ4896FCZZ 34- 38 AE N C PSHEZ4949FCZZ 34- 38 AE N C PSHEZ4957FCZZ 31- 17 AQ N B PWIR-0192FCZZ 31- 16 AQ N B QCNCM0829FCZZ 39- 2 AG C QCNCM0820FCZZ 39- 2 AG C QCNCM01146FCZZ 26- 3 AP C QCNCM1146FCZZ 26- 4 AE N C QCNCM1146FCZZ 26- 5 AP N C QCNCM1146FCZZ 26- 5 AP N C QCNCM1146FCZZ 39- 3 AK N C						
PSHEP4927FC10 17- 13 AR N D PSHEP4927FC11 17- 13 AR N D PSHEP4927FCZ1 17- 13 AR N D PSHEP4927FCZ2 17- 13 AR N D PSHEP4927FCZ3 17- 13 AR N D PSHEP4927FCZ3 17- 13 AR N D PSHEP4927FCZ4 17- 13 AR N D PSHEP4927FCZ5 17- 13 AR N D PSHEP4927FCZ5 17- 13 AR N D PSHEP4927FCZ6 17- 13 AR N D PSHEP4927FCZ7 17- 13 AR N D PSHEP4927FCZ7 17- 13 AR N D PSHEP4927FCZ8 17- 13 AR N D PSHEP4927FCZ9 17- 13 AR N D PSHEP4927FCZ 30- 7 AD N C PSHEP4937FCZZ 35- 29 AB N C PSHEZ4836FCZZ 30- 43 AB N C PSHEZ4841FCZ1 30- 40 AD N C PSHEZ4841FCZ1 30- 40 AD N C PSHEZ4843FCZZ 30- 32 AC N C PSHEZ4845FCZZ 35- 19 AL N C PSHEZ4847FCZZ 35- 19 AL N C PSHEZ487FCZZ 35- 19 AL N C PSHEZ487FCZZ 35- 19 AL N C PSHEZ48796FCZZ 35- 19 AL N C PSHEZ4879FCZZ 35- 19 AL N C PSHEZ4957FCZZ 35- 10 AL N C PSHEZ4957FCZZ 35- 10 AL N C PSHEZ526FCZZ 35- 10 AL N C PSHEZ526FCZZ 35- 10 AL N C PSHEZ52						
PSHEP4927FC11 17- 13 AR N D PSHEP4927FCZ1 17- 13 AR N D PSHEP4927FCZ2 17- 13 AR N D PSHEP4927FCZ3 17- 13 AR N D PSHEP4927FCZ4 17- 13 AR N D PSHEP4927FCZ5 17- 13 AR N D PSHEP4927FCZ6 17- 13 AR N D PSHEP4927FCZ7 17- 13 AR N D PSHEP4927FCZ7 17- 13 AR N D PSHEP4927FCZ7 17- 13 AR N D PSHEP4927FCZ8 17- 13 AR N D PSHEP4927FCZ8 17- 13 AR N D PSHEP4927FCZ9 17- 13 AR N D PSHEP4927FCZ9 17- 13 AR N D PSHEP4927FCZ2 17- 13 AR N D PSHEP4927FCZ2 30- 7 AD N C PSHEP4932FCZZ 30- 7 AD N C PSHEP4932FCZZ 30- 43 AB N C PSHEZ4836FCZZ 30- 43 AB N C PSHEZ4845FCZZ 30- 32 AC N C PSHEZ4845FCZZ 30- 32 AC N C PSHEZ4847FCZZ 35- 19 AL N C PSHEZ4847FCZZ 35- 19 AL N C PSHEZ4847FCZZ 35- 18 AC N C PSHEZ4906FCZZ 29- 24 AC N C PSHEZ4949FCZZ 34- 38 AE N C PSHEZ4949FCZZ 34- 38 AE N C PSHEZ4949FCZZ 34- 38 AE N C PSHEZ4957FCZZ 34- 78 AC N C PSHEZ4957FCZZ 35- 19 AL N C PSHEZ4957FCZZ 34- 78 AC N C PSHEZ4957FCZZ 34- 78 AC N C PSHEZ4957FCZZ 34- 78 AC N C PSHEZ4957FCZZ 33- 13 AC N C PSHEZ495FCZZ 33- 13 AC N C PSHEZ495FCZZ 33- 13 AC N C PSHEZ495FCZZ 33- 14 AV N B PWIR-0191FCZZ 31- 17 AQ N B PWIR-0191FCZZ 31- 17 AQ N B PWIR-0192FCZZ 31- 16 AQ N B C QCNCM0829FCZZ 39- 1 AE C QCNCM0829FCZZ 39- 2 AG C QCNCM0829FCZZ 39- 3 AF C QCNCM1146FCZZ 26- 4 AE N C QCNCM1146FCZZ 26- 4 AE N C QCNCM1146FCZZ 26- 5 AP N C QCNCM1146FCZZ 26- 5 AP N C QCNCM1166FCZZ 39- 3 AK N C	PSHEP4916FCZ1	34- 73	AF	N	C	
PSHEP4927FCZ1 17- 13 AR N D PSHEP4927FCZ2 17- 13 AM N D PSHEP4927FCZ3 17- 13 AR N D PSHEP4927FCZ4 17- 13 AR N D PSHEP4927FCZ4 17- 13 AR N D PSHEP4927FCZ5 17- 13 AR N D PSHEP4927FCZ6 17- 13 AR N D PSHEP4927FCZ6 17- 13 AR N D PSHEP4927FCZ8 17- 13 AR N D PSHEP4927FCZ8 17- 13 AR N D PSHEP4927FCZ8 17- 13 AR N D PSHEP4927FCZ9 17- 13 AR N D PSHEP4927FCZ9 17- 13 AR N D PSHEP4927FCZZ 17- 13 AR N D PSHEP4927FCZZ 30- 7 AD N C PSHEP4932FCZZ 30- 7 AD N C PSHEP4937FCZZ 35- 29 AB N C PSHEZ4836FCZZ 30- 43 AB N C PSHEZ4841FCZ1 30- 40 AD N C PSHEZ4841FCZ1 30- 40 AD N C PSHEZ4843FCZZ 30- 32 AC N C PSHEZ4845FCZZ 33- 1 AV N C PSHEZ4847FCZZ 35- 18 AC N C PSHEZ487FCZZ 35- 18 AC N C PSHEZ487FCZZ 34- 38 AE N C PSHEZ4906FCZZ 29- 24 AC N C PSHEZ497FCZZ 34- 38 AE N C PSHEZ497FCZZ 34- 38 AC N C PSHEZ497FCZZ 34- 48 AD C N C PSH		17- 13		N	D	
PSHEP4927FCZ2 17- 13 AM N D PSHEP4927FCZ3 17- 13 AR N D PSHEP4927FCZ4 17- 13 AR N D PSHEP4927FCZ5 17- 13 AR N D PSHEP4927FCZ6 17- 13 AR N D PSHEP4927FCZ6 17- 13 AR N D PSHEP4927FCZ6 17- 13 AR N D PSHEP4927FCZ7 17- 13 AR N D PSHEP4927FCZ8 17- 13 AR N D PSHEP4927FCZ8 17- 13 AR N D PSHEP4927FCZ9 17- 13 AR N D PSHEP4927FCZ2 17- 13 AM N D PSHEP4927FCZ2 30- 7 AD N C PSHEP4937FCZZ 35- 29 AB N C PSHEP4937FCZZ 30- 40 AD N C PSHEZ4836FCZZ 30- 40 AD N C PSHEZ4841FCZ1 30- 40 AD N C PSHEZ48447FCZZ 30- 27 AD N C PSHEZ4847FCZZ 30- 32 AC N C PSHEZ4847FCZZ 33- 1 AV N C PSHEZ4847FCZZ 35- 19 AL N C PSHEZ4847FCZZ 35- 19 AL N C PSHEZ4878FCZZ 34- 38 AE N C PSHEZ4906FCZZ 29- 24 AC N C PSHEZ4957FCZZ 34- 38 AE N C PSHEZ4957FCZZ 34- 38 AE N C PSHEZ4957FCZZ 34- 38 AE N C PSHEZ4957FCZZ 34- 38 AC N C PSHEZ4957FCZZ 34- 40- 1 AF C QCNCM0829FCZZ 39- 2 AG C QCNCM0829FCZZ 39- 2 AG C QCNCM1148FCZZ 26- 5 AP N C QCNCM1166FCZZ 39- 3 AK N C						
PSHEP4927FCZ3 17- 13 AR N D PSHEP4927FCZ4 17- 13 AR N D PSHEP4927FCZ5 17- 13 AR N D PSHEP4927FCZ6 17- 13 AR N D PSHEP4927FCZ7 17- 13 AR N D PSHEP4927FCZ9 17- 13 AR N D PSHEP4927FCZ2 17- 13 AR N D PSHEP4927FCZZ 30- 27 AD N C PSHEP4932FCZZ 30- 27 AD N C PSHEP4937FCZZ 35- 29 AB N C PSHEZ4836FCZZ 30- 43 AB N C PSHEZ4841FCZ1 30- 40 AD N C PSHEZ4841FCZ1 30- 40 AD N C PSHEZ48445FCZZ 30- 32 AC N C PSHEZ4847FCZZ 35- 14 AV N C PSHEZ4847FCZZ 35- 18 AC N C PSHEZ4847FCZZ 35- 19 AL N C PSHEZ4847FCZZ 35- 18 AC N C PSHEZ4847FCZZ 35- 18 AC N C PSHEZ4906FCZZ 29- 24 AC N C PSHEZ4997FCZZ 34- 38 AE N C PSHEZ4957FCZZ 34- 78 AC N C PSHEZ4957FCZZ 34- 78 AC N C PSHEZ4957FCZZ 33- 13 AC N C PSHEZ4957FCZZ 33- 13 AC N C PSHEZ4957FCZZ 31- 17 AQ N B PTPE-0265FCZZ 33- 13 AC N C PSPEDH0178FCZZ 31- 17 AQ N B PWIR-0191FCZZ 31- 17 AQ N B PWIR-0192FCZZ 31- 16 AQ N B PWIR-0192FCZZ 39- 2 AG C QCNCM0829FCZZ 39- 2 AG C QCNCM0823FCZZ 39- 2 AG C QCNCM1146FCZZ 26- 4 AE N C QCNCM1148FCZZ 26- 5 AP N C QCNCM1166FCZZ 39- 3 AK N C						
PSHEP4927FCZ4 17- 13 AR N D PSHEP4927FCZ5 17- 13 AR N D PSHEP4927FCZ6 17- 13 AR N D PSHEP4927FCZ7 17- 13 AR N D PSHEP4927FCZ8 17- 13 AR N D PSHEP4927FCZ8 17- 13 AR N D PSHEP4927FCZ8 17- 13 AR N D PSHEP4927FCZZ 17- 13 AR N D PSHEP4927FCZZ 17- 13 AR N D PSHEP4927FCZZ 30- 7 AD N C PSHEP4937FCZZ 30- 7 AD N C PSHEP4937FCZZ 30- 7 AD N C PSHEZ4836FCZZ 30- 43 AB N C PSHEZ4841FCZ1 30- 40 AD N C PSHEZ4841FCZ1 30- 20- AD N C PSHEZ4843FCZZ 30- 32 AC N C PSHEZ4845FCZZ 30- 32 AC N C PSHEZ4847FCZZ 35- 19 AL N C PSHEZ4847FCZZ 35- 19 AL N C PSHEZ4806FCZZ 35- 19 AL N C PSHEZ4906FCZZ 39- 24 AC N C PSHEZ4906FCZZ 39- 24 AC N C PSHEZ4957FCZZ 34- 38 AE N C PSHEZ4957FCZZ 33- 1 AV N C PSHEZ4957FCZZ 34- 38 AE N C PSHEZ4957FCZZ 34- 38 AE N C PSHEZ4957FCZZ 31- 16 AQ N B PWIR-0191FCZZ 31- 16 AQ N B PWIR-0192FCZZ 39- 1 AE C QCNCM0828FCZZ 39- 2 AG C QCNCM0828FCZZ 39- 1 AE C QCNCM0828FCZZ 39- 2 AG C QCNCM0828FCZZ 39- 2 AG C QCNCM0828FCZZ 39- 3 AP C QCNCM1146FCZZ 26- 4 AE N C QCNCM1146FCZZ 26- 5 AP N C QCNCM1148FCZZ 26- 5 AP N C QCNCM1148FCZZ 26- 5 AP N C QCNCM1148FCZZ 26- 5 AP N C						
PSHEP4927FCZ5 17- 13 AR N D PSHEP4927FCZ6 17- 13 AR N D PSHEP4927FCZ7 17- 13 AR N D PSHEP4927FCZ8 17- 13 AR N D PSHEP4927FCZ8 17- 13 AR N D PSHEP4927FCZ9 17- 13 AR N D PSHEP4927FCZ2 17- 13 AR N D PSHEP4927FCZZ 17- 13 AR N D PSHEP4932FCZZ 30- 7 AD N C PSHEP4937FCZZ 35- 29 AB N C PSHEZ4836FCZZ 30- 43 AB N C PSHEZ4841FCZ1 30- 40 AD N C PSHEZ4843FCZZ 30- 27 AD N C PSHEZ4843FCZZ 30- 27 AD N C PSHEZ4845FCZZ 30- 32 AC N C PSHEZ4847FCZZ 35- 19 AL N C PSHEZ4847FCZZ 35- 19 AL N C PSHEZ4847FCZZ 35- 19 AL N C PSHEZ4949FCZZ 34- 38 AE N C PSHEZ4949FCZZ 34- 38 AE N C PSHEZ4949FCZZ 34- 38 AE N C PSHEZ4949FCZZ 33- 13 AC N C PSHEZ4949FCZZ 34- 38 AC N C PSHEZ4957FCZZ 33- 13 AC N C PSHEZ4957FCZZ 33- 13 AC N C PSPD-0001QSZZ 27- 19 AB C PTPE-0265FCZZ 33- 13 AC N C PSPD-0001QSZZ 27- 19 AB C PTPE-0265FCZZ 31- 16 AQ N B [Q] QCNCM0041QSZZ 26- 3 AP C QCNCM0829FCZZ 39- 2 AG C QCNCM0829FCZZ 39- 2 AG C QCNCM0820FCZZ 39- 2 AG C QCNCM0820FCZZ 39- 2 AG C QCNCM0820FCZZ 39- 2 AG C QCNCM0923FC1Z 40- 2 AE C QCNCM1146FCZZ 26- 4 AE N C QCNCM1146FCZZ 26- 5 AP N C QCNCM1148FCZZ 26- 5 AP N C QCNCM1148FCZZ 26- 5 AP N C QCNCM1148FCZZ 26- 5 AP N C						
PSHEP4927FCZ6 17- 13 AR N D PSHEP4927FCZ7 17- 13 AR N D PSHEP4927FCZ8 17- 13 AR N D PSHEP4927FCZ9 17- 13 AR N D PSHEP4927FCZ2 17- 13 AR N D PSHEP4927FCZ2 17- 13 AM N D PSHEP4932FCZZ 30- 7 AD N C PSHEP4937FCZZ 35- 29 AB N C PSHEZ4836FCZZ 30- 43 AB N C PSHEZ4841FCZ1 30- 40 AD N C PSHEZ4842FCZZ 30- 27 AD N C PSHEZ4843FCZZ 30- 32 AC N C PSHEZ4845FCZZ 30- 32 AC N C PSHEZ4847FCZZ 35- 19 AL N C PSHEZ4847FCZZ 35- 19 AL N C PSHEZ4847FCZZ 35- 19 AL N C PSHEZ4847FCZZ 35- 18 AC N C PSHEZ4906FCZZ 29- 24 AC N C PSHEZ4949FCZZ 34- 38 AE N C PSHEZ4949FCZZ 34- 38 AE N C PSHEZ4957FCZZ 33- 13 AC N C PSHEZ4957FCZZ 31- 16 AQ N B PTPE-0265FCZZ 31- 16 AQ N B PWIR-0191FCZZ 31- 16 AQ N B PWIR-0192FCZZ 39- 2 AG C QCNCM0829FCZZ 39- 2 AG C QCNCM0829FCZZ 39- 2 AG C QCNCM0823FCZZ 39- 2 AG C QCNCM1146FCZZ 26- 4 AE N C QCNCM1146FCZZ 26- 4 AE N C QCNCM1146FCZZ 26- 5 AP N C QCNCM1148FCZZ 26- 5 AP N C						
PSHEP4927FCZ7 17- 13 AR N D PSHEP4927FCZ8 17- 13 AR N D PSHEP4927FCZ9 17- 13 AR N D PSHEP4927FCZZ 17- 13 AM N D PSHEP4937FCZZ 30- 7 AD N C PSHEP4937FCZZ 35- 29 AB N C PSHEP4937FCZZ 30- 43 AB N C PSHEZ4836FCZZ 30- 43 AB N C PSHEZ4841FCZ1 30- 40 AD N C PSHEZ4841FCZ1 30- 40 AD N C PSHEZ4845FCZZ 30- 32 AC N C PSHEZ4847FCZZ 30- 32 AC N C PSHEZ4847FCZZ 35- 19 AL N C PSHEZ4847FCZZ 35- 19 AL N C PSHEZ4847FCZZ 35- 18 AC N C PSHEZ4906FCZZ 32- 24 AC N C PSHEZ4957FCZZ 34- 38 AE N C PSHEZ4957FCZZ 34- 38 AE N C PSHEZ4957FCZZ 33- 13 AC N C PSHEZ4957FCZZ 33- 13 AC N C PSHEZ4957FCZZ 33- 13 AC N C PSPO-0001QSZZ 27- 19 AB C PSPO-0001QSZZ 27- 19 AB C PTPE-0265FCZZ 33- 15 AQ N B PWIR-0191FCZZ 31- 16 AQ N B PWIR-0192FCZZ 31- 16 AQ N B PWIR-0192FCZZ 39- 2 AG C QCNCM0829FCZZ 39- 2 AG C QCNCM0829FCZZ 39- 2 AG C QCNCM0823FCZZ 39- 2 AG C QCNCM0823FCZZ 39- 2 AG C QCNCM0823FCZZ 36- 3 AP C QCNCM0823FCZZ 36- 4 AE C QCNCM1146FCZZ 26- 4 AE N C QCNCM1146FCZZ 26- 5 AP N C QCNCM1148FCZZ 26- 5 AP N C QCNCM1148FCZZ 26- 5 AP N C						
PSHEP4927FCZ8 17- 13 AR N D PSHEP4927FCZ9 17- 13 AR N D PSHEP4927FCZZ 17- 13 AM N D PSHEP4932FCZZ 30- 7 AD N C PSHEP4937FCZZ 35- 29 AB N C PSHEZ4836FCZZ 30- 40 AD N C PSHEZ4841FCZI 30- 40 AD N C PSHEZ4843FCZZ 30- 32 AC N C PSHEZ4847FCZZ 30- 32 AC N C PSHEZ4847FCZZ 35- 19 AL N C PSHEZ4877FCZZ 35- 18 AC N C PSHEZ4906FCZZ 35- 18 AC N C PSHEZ4997FCZZ 34- 38 AE N C PSHEZ4957FCZZ 34- 78 AC N C PSPŌ-0001QSZZ 27- 19 AB C PTPE-0265FCZZ 33- 13 AC	PSHEP4927FCZ7			- ' '		
PSHEP4927FCZZ 17- 13 AM N D PSHEP4932FCZZ 30- 7 AD N C PSHEP4937FCZZ 35- 29 AB N C PSHEZ4836FCZZ 30- 43 AB N C PSHEZ4841FCZ1 30- 40 AD N C PSHEZ4842FCZZ 30- 27 AD N C PSHEZ4842FCZZ 30- 27 AD N C PSHEZ4843FCZZ 30- 32 AC N C PSHEZ4845FCZZ 33- 1 AV N C PSHEZ4847FCZZ 35- 19 AL N C PSHEZ4847FCZZ 35- 19 AL N C PSHEZ4806FCZZ 39- 24 AC N C PSHEZ4906FCZZ 29- 24 AC N C PSHEZ4949FCZZ 34- 38 AE N C PSHEZ4957FCZZ 34- 38 AC N C PSHEZ4906FCZZ 29- 24 AC N C PSHEZ4906FCZZ 39- 34- 38 AE N C PSHEZ4906FCZZ 31- 16 AQ N B PWIR-0192FCZZ 31- 16 AQ N B IQI QCNCM0041QSZZ 26- 3 AP C QCNCM0828FCZZ 39- 1 AE C QCNCM0828FCZZ 39- 2 AG C QCNCM0828FCZZ 39- 1 AE C QCNCM0828FCZZ 39- 1 AE C QCNCM1146FCZZ 26- 4 AE N C QCNCM1146FCZZ 26- 4 AE N C QCNCM1146FCZZ 26- 5 AP N C QCNCM1148FCZZ 26- 5 AP N C						
PSHEP4932FCZZ 30- 7 AD N C PSHEP4937FCZZ 35- 29 AB N C PSHEZ4836FCZZ 30- 43 AB N C PSHEZ4841FCZ1 30- 40 AD N C PSHEZ4842FCZZ 30- 27 AD N C PSHEZ4843FCZZ 30- 27 AD N C PSHEZ4845FCZZ 30- 32 AC N C PSHEZ4845FCZZ 35- 19 AL N C PSHEZ4847FCZZ 35- 19 AL N C PSHEZ4847FCZZ 35- 19 AL N C PSHEZ4906FCZZ 29- 24 AC N C PSHEZ4949FCZZ 34- 38 AE N C PSHEZ4949FCZZ 34- 38 AE N C PSHEZ4949FCZZ 34- 38 AE N C PSHEZ4957FCZZ 33- 13 AC N C PSPD-0001QSZZ 27- 19 AB C PSPD-0001QSZZ 27- 19 AB C PTPE-0265FCZZ 33- 13 AC N C PWIR-0191FCZZ 31- 16 AQ N B [Q] QCNCM0041QSZZ 26- 3 AP C QCNCM0828FCZZ 39- 1 AE C QCNCM0828FCZZ 39- 1 AE C QCNCM0823FCZZ 39- 1 AE C QCNCM0823FCZZ 39- 1 AE C QCNCM0823FCZZ 39- 2 AG C QCNCM0823FCZZ 39- 1 AE C QCNCM0823FCZZ 39- 1 AE C QCNCM0823FCZZ 39- 2 AG C QCNCM0823FCZZ 39- 2 AG C QCNCM0823FCZZ 39- 2 AG C QCNCM1146FCZZ 26- 4 AE N C QCNCM1146FCZZ 26- 5 AP N C QCNCM1148FCZZ 26- 5 AP N C QCNCM1148FCZZ 26- 5 AP N C	PSHEP4927FCZ9		AR			
PSHEP4937FCZZ 35- 29 AB N C PSHEZ4836FCZZ 30- 43 AB N C PSHEZ4841FCZ1 30- 40 AD N C PSHEZ4842FCZZ 30- 27 AD N C PSHEZ4843FCZZ 30- 32 AC N C PSHEZ4845FCZZ 33- 1 AV N C PSHEZ4847FCZZ 35- 19 AL N C PSHEZ4906FCZZ 35- 18 AC N C PSHEZ4949FCZZ 34- 38 AE N C PSHEZ4957FCZZ 34- 38 AE N C PSHEZ4957FCZZ 34- 78 AC N C PSHEZ4957FCZZ 34- 78 AC N C PSHEZ4957FCZZ 33- 13 AC N C PSPŌ-0001QSZZ 27- 19 AB C PTPE-0265FCZZ 33- 13 AC N C PWiR-0191FCZZ 31- 17 AQ						
PSHEZ4836FCZZ 30-43 AB N C PSHEZ4841FCZ1 30-40 AD N C PSHEZ4841FCZ1 30-40 AD N C PSHEZ4843FCZZ 30-27 AD N C PSHEZ4843FCZZ 30-32 AC N C PSHEZ4847FCZZ 33-1 AV N C PSHEZ4847FCZZ 35-19 AL N C PSHEZ4878FCZZ 35-19 AL N C PSHEZ4906FCZZ 29-24 AC N C PSHEZ4949FCZZ 34-38 AE N C PSHEZ4957FCZZ 34-78 AC N C PSHEZ4957FCZZ 34-78 AC N C PSHEZ4957FCZZ 33-13 AC N C PSHEZ4957FCZZ 34-78 AC N C PSPŌ-0001QSZZ 27-19 AB C PSPŌ-0001QSZZ 27-19 AB C PSPŌ-0001QSZZ 31-17 AQ N B PWIR-0191FCZZ 31-17 AQ N B PWIR-0192FCZZ 31-16 AQ N B QCNCM0828FCZZ 39-1 AE C QCNCM0829FCZZ 39-2 AG C QCNCM0829FCZZ 39-2 AG C QCNCM0823FCZZ 40-1 AF C QCNCM1146FCZZ 26-4 AE N C QCNCM1146FCZZ 26-5 AP N C QCNCM1148FCZZ 26-5 AP N C QCNCM1148FCZZ 26-5 AP N C						
PSHEZ4841FCZ1 30-40 AD N C PSHEZ4842FCZZ 30-27 AD N C PSHEZ4843FCZZ 30-32 AC N C PSHEZ4845FCZZ 33-1 AV N C PSHEZ4847FCZZ 35-19 AL N C PSHEZ4878FCZZ 35-18 AC N C PSHEZ4906FCZZ 29-24 AC N C PSHEZ4949FCZZ 34-38 AE N C PSHEZ4957FCZZ 34-78 AC N C PSPDO-0001QSZZ 27-19 AB C PTPE-0265FCZZ 33-13 AC N C PWIR-0191FCZZ 31-17 AQ N B PWIR-0192FCZZ 31-16 AQ N B [Q] QCNCM0041QSZZ 26-3 AP C QCNCM0828FCZZ 39-1 AE C QCNCM0828FCZZ 39-1 AE C QCNCM0823FCZZ 40-1 AF C QCNCM0923FC12 40-2 AE C QCNCM1146FCZZ 26-5 AP N C QCNCM1148FCZZ 26-5 AP N C						
PSHEZ4842FCZZ 30- 27 AD N C PSHEZ4843FCZZ 30- 32 AC N C PSHEZ4845FCZZ 33- 1 AV N C PSHEZ4847FCZZ 35- 19 AL N C PSHEZ4878FCZZ 35- 18 AC N C PSHEZ4906FCZZ 29- 24 AC N C PSHEZ4949FCZZ 34- 38 AE N C PSHEZ4957FCZZ 34- 78 AC N C PSHEZ4957FCZZ 34- 78 AC N C PSLDH0178FCZZ 28- 4 AD C PSPÖ-0001QSZZ 27- 19 AB C PTPE-0265FCZZ 33- 13 AC N C PWIR-0191FCZZ 31- 17 AQ N B PWIR-0192FCZZ 31- 16 AQ N B [Q] QCNCM0041QSZZ 26- 3 AP C QCNCM0828FCZZ 39- 1 AE C QCNCM0829FCZZ 39- 1 AE C QCNCM0823FCZZ 40- 1 AF C QCNCM0923FC1Z 40- 2 AE C QCNCM1146FCZZ 26- 5 AP N C QCNCM1148FCZZ 26- 5 AP N C						
PSHEZ4843FCZZ 30-32 AC N C PSHEZ4845FCZZ 33-1 AV N C PSHEZ4847FCZZ 35-19 AL N C PSHEZ4878FCZZ 35-18 AC N C PSHEZ4906FCZZ 29-24 AC N C PSHEZ4949FCZZ 34-38 AE N C PSHEZ4957FCZZ 34-38 AE N C PSHEZ4957FCZZ 34-78 AC N C PSHEZ4957FCZZ 34-78 AC N C PSLDH0178FCZZ 28-4 AD C PSPŌ-0001QSZZ 27-19 AB C PTPE-0265FCZZ 33-13 AC N C PWiR-0191FCZZ 31-17 AQ N B PWiR-0192FCZZ 31-16 AQ N B [Q] QCNCM0041QSZZ 26-3 AP C QCNCM0828FCZZ 39-1 AE C QCNCM0829FCZZ 39-1 AE C QCNCM0823FCZZ 40-1 AF C QCNCM0923FC1Z 40-2 AE C QCNCM1146FCZZ 26-5 AP N C QCNCM1148FCZZ 26-5 AP N C						
PSHEZ4845FCZZ 33- 1 AV N C PSHEZ4847FCZZ 35- 19 AL N C PSHEZ4878FCZZ 35- 18 AC N C PSHEZ4906FCZZ 29- 24 AC N C PSHEZ4949FCZZ 34- 38 AE N C PSHEZ4957FCZZ 34- 78 AC N C PSLDH0178FCZZ 28- 4 AD C PSPŌ-0001QSZZ 27- 19 AB C PTPE-0265FCZZ 33- 13 AC N C PWiR-0191FCZZ 31- 17 AQ N B IQI QCNCM0041QSZZ 26- 3 AP C QCNCM0828FCZZ 39- 1 AE C QCNCM0829FCZZ 39- 2 AG C QCNCM0923FC12 40- 1 AF C QCNCM1146FCZZ 26- 4 AE N C QCNCM1148FCZZ 26- 5 AP N C QCNCM1166FCZ						
PSHEZ4847FCZZ 35- 19 AL N C PSHEZ4878FCZZ 35- 18 AC N C PSHEZ4906FCZZ 29- 24 AC N C PSHEZ4949FCZZ 34- 38 AE N C PSHEZ4957FCZZ 34- 78 AC N C PSHEZ4957FCZZ 34- 78 AC N C PSHEZ4957FCZZ 28- 4 AD C PSPŌ-0001QSZZ 27- 19 AB C PTPE-0265FCZZ 33- 13 AC N C PWIR-0191FCZZ 31- 17 AQ N B PWIR-0192FCZZ 31- 16 AQ N B QCNCM0041QSZZ 26- 3 AP C QCNCM0828FCZZ 39- 1 AE C QCNCM0829FCZZ 39- 2 AG C QCNCM0820FCZZ 40- 1 AF C QCNCM0923FC1Z 40- 2 AE C QCNCM1146FCZZ 26- 4 AE N C QCNCM1146FCZZ 26- 5 AP N C QCNCM1148FCZZ 26- 5 AP N C						
PSHEZ4878FCZZ 35- 18 AC N C PSHEZ4906FCZZ 29- 24 AC N C PSHEZ4949FCZZ 34- 38 AE N C PSHEZ4957FCZZ 34- 78 AC N C PSLDH0178FCZZ 28- 4 AD C PSPŌ-0001QSZZ 27- 19 AB C PTPE-0265FCZZ 33- 13 AC N C PWiR-0191FCZZ 31- 17 AQ N B PWiR-0192FCZZ 31- 16 AQ N B QCNCM0041QSZZ 26- 3 AP C QCNCM0828FCZZ 39- 1 AE C QCNCM0829FCZZ 39- 2 AG C QCNCM0923FC12 40- 1 AF C QCNCM1146FCZZ 26- 4 AE N C QCNCM1148FCZZ 26- 5 AP N C QCNCM1166FCZZ 39- 3 AK N C						
PSHEZ4906FCZZ 29- 24 AC N C PSHEZ4949FCZZ 34- 38 AE N C PSHEZ4957FCZZ 34- 78 AC N C PSLDH0178FCZZ 28- 4 AD C PSPŌ-0001QSZZ 27- 19 AB C PTPE-0265FCZZ 33- 13 AC N C PWiR-0191FCZZ 31- 17 AQ N B PWiR-0192FCZZ 31- 16 AQ N B IQI QCNCM0828FCZZ 39- 1 AE C QCNCM0829FCZZ 39- 2 AG C QCNCM0880FCZZ 40- 1 AF C QCNCM0923FC12 40- 2 AE C QCNCM1146FCZZ 26- 4 AE N C QCNCM1146FCZZ 26- 5 AP N C QCNCM1166FCZZ 39- 3 AK N C						
PSHEZ4957FCZZ 34-78 AC N C PSLDH0178FCZZ 28-4 AD C PSPŌ-0001QSZZ 27-19 AB C PTPE-0265FCZZ 33-13 AC N C PWiR-0191FCZZ 31-17 AQ N B PWiR-0192FCZZ 31-16 AQ N B [Q] QCNCM0041QSZZ 26-3 AP C QCNCM0828FCZZ 39-1 AE C QCNCM0829FCZZ 39-2 AG C QCNCM0829FCZZ 40-1 AF C QCNCM0923FC1Z 40-2 AE C QCNCM1146FCZZ 26-4 AE N C QCNCM1148FCZZ 26-5 AP N C QCNCM1166FCZZ 39-3 AK N C						
PSLDH0178FCZZ 28- 4 AD C PSPŌ-0001QSZZ 27- 19 AB C PTPE-0265FCZZ 33- 13 AC N C PWiR-0191FCZZ 31- 17 AQ N B PWiR-0192FCZZ 31- 16 AQ N B [Q] QCNCM0041QSZZ 26- 3 AP C QCNCM0828FCZZ 39- 1 AE C QCNCM0829FCZZ 39- 1 AE C QCNCM0880FCZZ 40- 1 AF C QCNCM0923FC1Z 40- 2 AE C QCNCM1146FCZZ 26- 4 AE N C QCNCM1148FCZZ 26- 5 AP N C QCNCM1166FCZZ 39- 3 AK N C						
PSPŌ-0001QSZZ 27- 19 AB C PTPE-0265FCZZ 33- 13 AC N C PWiR-0191FCZZ 31- 17 AQ N B PWiR-0192FCZZ 31- 16 AQ N B [Q] QCNCM0041QSZZ 26- 3 AP C QCNCM0828FCZZ 39- 1 AE C QCNCM0829FCZZ 39- 2 AG C QCNCM0880FCZZ 40- 1 AF C QCNCM0923FC1Z 40- 2 AE C QCNCM1146FCZZ 26- 4 AE N C QCNCM1148FCZZ 26- 5 AP N C QCNCM1166FCZZ 39- 3 AK N C				N		
PTPE-0265FCZZ 33-13 AC N C PWiR-0191FCZZ 31-17 AQ N B PWiR-0192FCZZ 31-16 AQ N B [Q] QCNCM0041QSZZ 26-3 AP C QCNCM0828FCZZ 39-1 AE C QCNCM0829FCZZ 39-2 AG C QCNCM0880FCZZ 40-1 AF C QCNCM0923FC12 40-2 AE C QCNCM01146FCZZ 26-4 AE N C QCNCM1148FCZZ 26-5 AP N C QCNCM1166FCZZ 39-3 AK N C						
PWiR-0191FCZZ 31- 17 AQ N B PWiR-0192FCZZ 31- 16 AQ N B [Q] QCNCM0041QSZZ 26- 3 AP C QCNCM0828FCZZ 39- 1 AE C QCNCM0829FCZZ 39- 2 AG C QCNCM0880FCZZ 40- 1 AF C QCNCM0923FC12 40- 2 AE C QCNCM0923FC12 40- 2 AE C QCNCM1146FCZZ 26- 4 AE N C QCNCM1148FCZZ 26- 5 AP N C QCNCM1166FCZZ 39- 3 AK N C				h :		
PWiR-0192FCZZ 31- 16 AQ N B [Q] QCNCM0041QSZZ 26- 3 AP C QCNCM0828FCZZ 39- 1 AE C QCNCM0829FCZZ 39- 2 AG C QCNCM0880FCZZ 40- 1 AF C QCNCM0923FC12 40- 2 AE C QCNCM01146FCZZ 26- 4 AE N C QCNCM1148FCZZ 26- 5 AP N C QCNCM1166FCZZ 39- 3 AK N C					_	
[Q] QCNCM0041QSZZ 26- 3 AP C QCNCM0828FCZZ 39- 1 AE C QCNCM0829FCZZ 39- 2 AG C QCNCM0880FCZZ 40- 1 AF C QCNCM0923FC12 40- 2 AE C QCNCM1146FCZZ 26- 4 AE N C QCNCM1148FCZZ 26- 5 AP N C QCNCM1166FCZZ 39- 3 AK N C						
QCNCM0041QSZZ 26-3 AP C QCNCM0828FCZZ 39-1 AE C QCNCM0829FCZZ 39-2 AG C QCNCM0880FCZZ 40-1 AF C QCNCM0923FC12 40-2 AE C QCNCM1146FCZZ 26-4 AE N C QCNCM1148FCZZ 26-5 AP N C QCNCM1166FCZZ 39-3 AK N C		31- 10	7.0	IN	ט	
QCNCM0828FCZZ 39- 1 AE C QCNCM0829FCZZ 39- 2 AG C QCNCM0880FCZZ 40- 1 AF C QCNCM0923FC12 40- 2 AE C QCNCM1146FCZZ 26- 4 AE N C QCNCM1148FCZZ 26- 5 AP N C QCNCM1166FCZZ 39- 3 AK N C		26- 3	AP		С	
QCNCM0829FCZZ 39- 2 AG C QCNCM0880FCZZ 40- 1 AF C QCNCM0923FC12 40- 2 AE C QCNCM1146FCZZ 26- 4 AE N C QCNCM1148FCZZ 26- 5 AP N C QCNCM1166FCZZ 39- 3 AK N C						
QCNCM0880FCZZ 40- 1 AF C QCNCM0923FC12 40- 2 AE C QCNCM1146FCZZ 26- 4 AE N C QCNCM1148FCZZ 26- 5 AP N C QCNCM1166FCZZ 39- 3 AK N C						
QCNCM1146FCZZ 26- 4 AE N C QCNCM1148FCZZ 26- 5 AP N C QCNCM1166FCZZ 39- 3 AK N C	QCNCM0880FCZZ		AF			
QCNCM1148FCZZ 26- 5 AP N C QCNCM1166FCZZ 39- 3 AK N C						
QCNCM1166FCZZ 39- 3 AK N C						
QUINUMITTO/FUZZ 39- 4 AP N C						
	QUINCIVIT 10/FUZZ	აყ- 4	AP	IN	U	

PARTS CODE NO. PRICE RANK MARK RANK MARK RANK PRATT RANK QCNCM1171FCZZ 38- 1 AE N C QCNCM7014SC1C 39- 5 AC C C QCNCM7022SC0C 39- 6 AB C C QCNCM7022SC0E 39- 7 AB C QCNCM7022SC0F 39- 8 AB C QCNCW09846FCZZ 39- 9 AG C QCNCW0946FCZZ 26- 6 AH C QCNCW1134FCZZ 38- 2 AH C QCNCW1147FCZZ 26- 7 AL N C QCNCW1149FCZZ 26- 8 AN N C	
QCNCM1171FCZZ 38- 1 AE N C QCNCM7014SC1C 39- 5 AC C C QCNCM7022SC0C 39- 6 AB C QCNCM7022SC0E 39- 7 AB C QCNCM7022SC0F 39- 8 AB C QCNCW0885FCZZ 39- 9 AG C QCNCW0946FCZZ 26- 6 AH C QCNCW1134FCZZ 38- 2 AH C QCNCW1147FCZZ 26- 7 AL N C	
QCNCM7014SC1C 39-5 AC C QCNCM7022SC0C 39-6 AB C QCNCM7022SC0E 39-7 AB C QCNCM7022SC0F 39-8 AB C QCNCW0885FCZZ 39-9 AG C QCNCW0946FCZZ 26-6 AH C QCNCW1134FCZZ 38-2 AH C QCNCW1147FCZZ 26-7 AL N C	
QCNCM7022SC0C 39-6 AB C QCNCM7022SC0E 39-7 AB C QCNCM7022SC0F 39-8 AB C QCNCW0885FCZZ 39-9 AG C QCNCW0946FCZZ 26-6 AH C QCNCW1134FCZZ 38-2 AH C QCNCW1147FCZZ 26-7 AL N	
QCNCM7022SC0E 39-7 AB C QCNCM7022SC0F 39-8 AB C QCNCW0885FCZZ 39-9 AG C QCNCW0946FCZZ 26-6 AH C QCNCW1134FCZZ 38-2 AH C QCNCW1147FCZZ 26-7 AL N C	
QCNCM7022SC0F 39-8 AB C QCNCW0885FCZZ 39-9 AG C QCNCW0946FCZZ 26-6 AH C QCNCW1134FCZZ 38-2 AH C QCNCW1147FCZZ 26-7 AL N C	
QCNCW0885FCZZ 39-9 AG C QCNCW0946FCZZ 26-6 AH C QCNCW1134FCZZ 38-2 AH C QCNCW1147FCZZ 26-7 AL N C	
QCNCW0885FCZZ 39-9 AG C QCNCW0946FCZZ 26-6 AH C QCNCW1134FCZZ 38-2 AH C QCNCW1147FCZZ 26-7 AL N C	
QCNCW0946FCZZ 26-6 AH C QCNCW1134FCZZ 38-2 AH C QCNCW1147FCZZ 26-7 AL N C	
QCNCW1134FCZZ 38-2 AH C QCNCW1147FCZZ 26-7 AL N C	
QCNCW1147FCZZ 26-7 AL N C	
QCNCW1149FCZZ 26-8 AN N C	
QCNCW1160FCZZ 40- 3 AD N C	
QCNCW7040XC8J 39-10 AP C	
QCNW-0165FCZZ 30-15 AH N C	
QCNW-0166FCZZ 29-25 AE N C	
QCNW-0167FCZZ 30- 5 AM N C	
QCNW-0168FCZZ 30- 4 AE N C	
" 32- 7 AE N C	
QCNW-0170FCZZ 36- 6 AH N C	
QCNW-0181FCZZ 30-16 AH N C	
QFS-D132CQCZZ 26- 9 AG A	
QFSHB0028FCZZ 26- 10 AC C	
QP i N - 0 0 0 3 GC Z Z 26- 11 AC C	
QSOCZ0001QSZZ 26-12 AL C	
QSOCZ0002QSZZ 39- 11 AD C	
QSŌCZ0071FCZZ 39- 12 AP C	
QSŌCZ0073FCZZ 26- 13 AL C	
QSŌCZ6428ACZZ 26- 15 AE C	
" 39- 13 AE C	
QSW-P0005QSZZ 38- 3 AC B	
QSW-Z0531FCZZ 34-63 AL B	
[R]	
RALMB1002LCZZ 38- 4 AE B	
RC-KZ0008QCZZ 38- 5 AB N C	
RCORF0041FCZZ 27-31 AH N C	
RCRMZ6007RCZZ 39- 14 AD B	
RCRSP6676RCZZ 26- 16 AG B	
RCRSZ0001QSZZ 39- 15 AG B	
RCRUA0005FCZZ 26- 17 AP B	
RCRUA0007FCZZ 26- 18 AP B	
RCRUA0008FCZZ 26- 19 AP B	
RCRUA0009FCZZ 26- 20 AP B	
RCRUA0012FCZZ 26- 21 AP B	
RF i LN0 0 4 8 F C Z Z 26- 22 AC C	
30 10 11 0	
RFiLN0051FCZZ 26- 23 AC N C	
RFiLN6012RCZZ 39- 17 AB C	
" 40- 4 AB C	
RF i L Z 1 0 0 5 L C Z Z 39- 18 AB C	
" 40- 5 AB C	
RH-DZ0016FCZZ 38- 7 AB B	
RH-iX2196SCZZ 39-19 AG B	
RLMPD0658FCZZ 32- 1 BA N B	
RMŌTS0857FCZZ 31- 27 AZ N B	
RMŌTS0876FCZZ 34- 35 BD N B	
11 1 2 2	
" 39- 20 AB B	
RMPTR4330ACZZ 26- 26 AB B	
RMPTR4472ACZZ 26-27 AB B	
RPLU-0336FCZZ 34- 25 AS N B	
RPLU-0347FCZZ 35- 12 AQ N B	
[8]	
SPAKA0307QSZZ 37- 3 AD D	
SPAKA6075DSZZ 37- 1 AA N D	
SPAKA6132FCZZ 37- 6 AT N D	
SPAKA6135FCZZ 43- 7 AK N D	
SPAKA6136FCZZ 43- 1 AE N D	
SPAKA6137FCZZ 43-8 AK N D	
SPAKA6143FCZZ 42-5 AN N D	
SPAKA6144FCZZ 42-4 AH N D	
SPAKA6265FCZZ 37-10 AC N D	
SPAKC6118DS12 17- 5 AU N D	
SPAKC6118DS13 17- 5 AU N D	
SPAKC6122DS17 17- 5 AU N D	
SPAKC6122DS18 17- 5 AU N D	
ISPAKU6122DS10 17 E AII N D	
SPAKC6122DS19 17- 5 AU N D	
SPAKC6122DS19 17-5 AU N D SPAKC6122DS20 17-5 AU N D SPAKC6122DS21 17-5 AU N D	

PARTS CODE	NO.	PRICE	NEW	PART	
SPAKC6122DS22		RANK AU	MARK	RANK	
SPAKC6122D522 SPAKC6131DS11	17- 5 37- 9	AF	N N	D D	
SPAKC6131DSZZ	37- 9	AF	N	D	
SPAKC6134DS11	43- 2	AT	N	D	
SPAKC6134DS12	43- 2	ΑТ	N	D	
SPAKC6134DS13	43- 2	ΑT	N	D	
SPAKC6134DSZZ	43- 2	ΑT	N	D	
SPAKC6142FC11	42- 6	AP	N	D	
SPAKC6142FC12	42- 6	AP	N	D	
SPAKC6142FC13 SPAKC6142FCZZ	42- 6	AP	N	D	
SPAKC6142FCZZ SPAKP2792RCZZ	42- 6 42- 2	AP AE	N	D D	
SSAKZ0003QSZZ	37- 7	AF		D	
[T]	01 1	, ()			
TCADZ1178FCZZ	37- 4	AB		D	
TiNSD2092GHZZ	17- 20	AS	N	D	
TiNSD2134GHZZ	17- 20	AS	N	D	
TiNSE2077FCZZ	17- 20	AQ	N	D	
TiNSE2078FCZZ	17- 20	AW	N	D	
TiNSE2081GHZZ	17- 20	AS	N	D	
TiNSE2087FCZZ	17- 20	AX	N	D	
TiNSE2119FCZZ	17- 20	AN	N	D	
TiNSE2120FCZZ TiNSE2123GHZZ	17- 20 17- 20	AV	N N	D D	
TiNSE2123GHZZ	17- 20	AV	N	D	
TiNSE2181FCZZ	17- 20	AT	N	D	
TiNSF2079FCZZ	17- 20	AW	N	D	
TiNSF2121FCZZ	17- 20	AV	N	D	
TiNSG2080GHZZ	17- 20	AS	N	D	
TiNSG2122GHZZ	17- 20	AS	N	D	
TiNSH2084GHZZ	17- 20	AS	N	D	
TiNSH2126GHZZ	17- 20	AS	N	D	
TiNSi2083GHZZ	17- 20	AS	N	D	
TiNSi2125GHZZ TiNSJ2076FCZZ	17- 20	AS AQ	N	D	
TiNSJ2118FCZZ	17- 20 17- 20	AN	N N	D D	
TiNSS2082FCZZ	17- 20	AW	N	D	
TiNSS2124FCZZ	17- 20	AV	N	D	
TiNSW2089GHZZ	17- 20	AS	N	D	
TiNSW2131GHZZ	17- 20	AS	N	D	
TiNSZ2090GHZZ	17- 20	AS	N	D	
TiNSZ2091GHZZ	17- 20	AS	N	D	
TiNSZ2093GHZZ	17- 20	AS	N	D	
TiNSZ2094GHZZ TiNSZ2095GHZZ	17- 20	AS	N	D	
TiNSZ2095GHZZ	17- 20	AS AS	N	D	
TiNSZ2132GHZZ	17- 20 17- 20	AS	N N	D D	
TiNSZ2135GHZZ	17- 20	AS	N	D	
TiNSZ2136GHZZ	17- 20	AS	N	D	
TiNSZ2137GHZZ	17- 20	AS	N	D	
TLABH4440FCZZ	33- 45	AF		D	
TLABZ4335FCZZ	32- 15	AB		D	
[U]				_	
UBATi0014FCZZ	26- 28	AN		В	
[V]	26 20	Λ Λ		^	
VCCCCZ1HH101J	26- 29 40- 6	A A		C	
VCCCCZ1HH220J	26- 30	AA		C	
//	39- 21	AA		С	
VCEAGA1AW476M	39- 22	AA		С	
VCEAGA1AW477M	39- 23	AB		С	
VCEAGA1CW477M	39- 24	AB		С	
VCEAGA1HW224M	39- 25	AA		С	
VCEAGA1VW476M	39- 26	AB		С	
VCEAUU1CW476M	38- 8	AB		С	
VCEAPH1HC105M	26- 31	AC		С	
VCEAPS1AC227M VCEAPS1CC106M	26- 32 26- 33	AD AC		C	
VCEAPS1CC106M VCEAPS1CC226M	26- 33	AC		C	
VCEAPS1CC226M	26- 35	AC		C	
VCEAYU1EC476M	40- 7	AC	N	С	
VCEAYU1VC476M	40- 8	AC	N	C	
VCEAZU1VW477M	39- 27	AD		С	
VCKYCZ1CB103K	39- 28	AA		С	
VCKYCZ1CF104Z	26- 36	AB		С	
//	40- 9	AB		С	
VCKYCZ1EF223Z	39- 29	AA		С	
VCKYCZ1HB102K "	26- 37	A A		С	
"	39- 30 40- 10	AA		C	
VCKYCZ1HB222K	39- 31	AA		C	
	01		i		I.

DADTO CODE	110	PRICE	NEW	PART	
PARTS CODE	NO.	RANK	MARK	RANK	
VCKYCZ1HF103Z	26- 38	AA		С	
<i>"</i>	39- 32	AA		С	
VCKYPU1EB223Z	40- 11 38- 9	AB		C	
VCKYPU1HB101K	38- 10	AA		C	
VCQYNA1HM103K	39- 33	AA		C	
VHD1SS133//-1	38- 11	AA		В	
VHDDAN202K/-1	39- 34	AB		В	
VHDDAP202K/-1	39- 35	AB		В	
VHDDAP202U/-1	26- 39	AB		В	
VHDDSM1D1//-1	39- 36	AB		В	
VHDM1FL20U+-1	39- 37	AC	N	В	
VHDMA704A//-1 VHDRB451F//-1	39- 38	AC AD		B B	
VHDRLS73///-1	26- 40 26- 41	AA		В	
VHEHZS3B3//-1	39- 39	AB		В	
VHi28F081L02C	30- 12	BB	N	В	
VHi28F322L01F	12- 54	BE	N	В	
"	41- 1	BE	N	В	
VHi28F322L02F	12- 55	BF	N	В	
//	41- 2	BF	N	В	
VHi28F322L03F	12- 54	BF	N	В	
//	41- 1	BF	N	В	
VHi28F322L04F	12- 55	BL	N	В	
// VH:65046D07=1	41- 2	BL	N	В	
VHi65946P07-1 VHi74LCX08MTC	26- 42 26- 43	BA AE		B B	
VHI74LCXU8MTC	26- 43	AE		В	
VHi74LCX14MTC	26- 45	AG		В	
VHi74LCX32MTC	26- 46	AE		В	
VHi74LVX16128	26- 47	AP		В	
VHi74VHC04M-1	39- 40	ΑE	N	В	
//	40- 12	ΑE	N	В	
VHi74VHC32M-1	39- 41	AD	N	В	
VHi74VHCT240X	40- 13	AF		В	
VH i 7 S Z 1 2 5 M 5 - 1	40- 14	AE	N	В	
VHi90LV17AW-1	26- 48	AP		В	
VHi90LV27AW-1	39- 42 40- 15	AP AQ	N	B B	
VHiD65943GJ-1	39- 43	AY	N	В	
VH i D82825GM-1	40- 16	BK	N	В	
VHiDS14C238//	26- 49	AT	- ' '	В	
VHiEEP64-120P	26- 50	AW		В	
VHiEES04L400P	39- 44	AG		В	
VHiFS781BZB-1	40- 17	AP		В	
VHiH8S2322R-1	39- 45	ΑZ		В	
VH i HG73C095-1	26- 51	AY		В	
VH i HN 5 8 V 6 5 A - 1	39- 46	AW		В	
VH i KS0U1347-1 VH i LCX157MT-1	26- 52 26- 53	BN AG		В	
VH1LCX167M1-1	26- 53	AM		B B	
VHiLCX16244 1	26- 55	AM		В	
VHiLCX16373-1	26- 56	AM		В	
VHILCX74MTC-1	26- 57	AE		В	
VH i LM3 2 4 D++-1	39- 47	ΑE		В	
VH i LM339D++-1	39- 48	ΑE		В	
VH i LM393D++-1	26- 58	ΑE		В	
VHiLV25612J-1	39- 49	AQ		В	
VHiLVT240MT-1	26- 59	AL		В	
VH i M3 0 6 4 A T C - 1	40- 18	AX	N	В	
VH i MTD 1 261 E - 1	26- 60	BK		В	
VHiMTD1361F-1 VHiN2370R04-1	39- 50	AR AF		B	
VH i N2370R33-1	26- 61 26- 62	AF		B B	
VHiN2370H33 1	26- 63	AG		В	
VH i N J M 3 1 7 D L - 1	26- 64	AK		В	
VH i NJU6356E-1	26- 65	AK		В	
VHiPi6C2309-1	26- 66	AR		В	
VH i PM2500++-1	26- 67	BP		В	
VHiPST598DN-1	26- 68	AF		В	
VHiPST598iN-1	26- 69	AF		В	
VH i S1 3 4 0 AF + - 1	38- 12	AH		В	
VH i SD 4 M 1 6 L 1 - 1	26- 70	AZ		В	
VIII CDOM4 CL 4 4	26- 71	BB AU		В	
VH i SD 8 M 1 6 L 1 - 1	26 72	~~~	1	В	
VHiSR1024-7LL	26- 72 26- 73			R	
VH i SR 1 0 2 4 - 7 L L VH i T 4 9 5 5 A 2 0 - 1	26- 73	BF		B B	
VHiSR1024-7LL VHiT4955A20-1 VHiTD62003AP1	26- 73 39- 51	BF AG		В	
VHiSR1024-7LL VHiT4955A20-1	26- 73	BF			
VHiSR1024-7LL VHiT4955A20-1 VHiTD62003AP1 VHiTD62503F/-	26- 73 39- 51 39- 52	BF AG AG	N	B B	

DADTO CODE	NO	PRICE	NEW	PART	
PARTS CODE	NO.	RANK	MARK	RANK	
VHP1LHEE-002A	26- 75	AC		В	
VHP1LHLE-002A	38- 13	AC		В	
VHPGP1A22LC-1	31- 38	AK		В	
VHPGP1A73A+-1	33- 33	AG		В	
<i>"</i>	34- 68	AG		В	
VHPGP3A38//-1	35- 10	AG AH		В	
VHPLT9400E/-1	31- 36 38- 14	AK		B B	
VHV1608C080-1	26- 76	AC		В	
VHV i CPS1 . 2/-1	26- 77	AF		В	
VRD-HT2EY101J	38- 15	AA		С	
VRD-HT2EY102J	38- 16	AA		C	
VRD-HT2EY163J	39- 54	AA		C	
VRD-HT2EY302J	38- 17	AA		C	
VRD-HT2EY331J	38- 18	AA		С	
VRD-HT2EY471J	38- 19	AA		С	
VRD-HT2EY911J	39- 55	AA		С	
VRS-CZ1JD000J	26- 78	AA		С	
"	39- 56	AA		С	
"	40- 20	AA		С	
VRS-CZ1JD100J	26- 79	AA		С	
VRS-CZ1JD101J	26- 80	AA		С	
//	39- 57	AA		С	
//	40- 21	AA		С	
VRS-CZ1JD102J	26- 81	AA		С	
"	39- 58	AA		С	
//	40- 22	AA		С	
VRS-CZ1JD103F	39- 59	AA		С	
VRS-CZ1JD103J	26- 82	AA		С	
// VDC_C71_ID100_I	39- 60	AA		С	
VRS-CZ1JD122J	39- 61			С	
VRS-CZ1JD151J VRS-CZ1JD183J	39- 62	AA AA		С	
VRS-CZ1JD183J	26- 83 39- 63	AA		С	
VRS-CZ1JD203J	26- 84	AA		C	
VRS-CZ1JD221J	26- 85	AA		C	
VRS-CZ1JD222J	26- 86	AA		C	
//	39- 64	AA		С	
"	40- 23	AA		C	
VRS-CZ1JD303F	39- 65	AA		C	
VRS-CZ1JD303J	39- 66	AA	N	C	
VRS-CZ1JD330J	26- 87	AA		С	
VRS-CZ1JD332F	40- 24	AA		С	
VRS-CZ1JD332J	26- 88	AA		C	
VRS-CZ1JD333J	26- 89	AA		С	
VRS-CZ1JD470J	26- 90	AA		С	
VRS-CZ1JD472J	26- 91	AA		С	
VRS-CZ1JD511J	26- 92	AA		С	
VRS-CZ1JD561J	39- 67	AA		С	
VRS-CZ1JD562J	39- 68	AA		С	
VRS-CZ1JD621J	39- 69	AA		С	
VRS-CZ1JD624J	39- 70	AA	N	С	
VRS-CZ1 JD681 J	39- 71	AA AA		С	
VRS-CZ1JD750J VRS-CZ1JD752J	26- 93 39- 72	AA		C	
VRS-CZ1JD7523	26- 94	AA		C	
VRS-CZ1JD9233	39- 73	AA	N	C	
VRS-RE3DA1R0J	39- 74	AB	.,	C	
VS2SB1197//-1	39- 75	AC		В	
VS2SC1740SR-1	38- 20	AB		В	
VS2SK3065++-1	39- 76	AG	N	В	
VSDTA114YK/-1	39- 77	AC		В	
VSDTC114EK/-1	26- 95	AB		В	
VSDTC114YK/-1	26- 96	AC		В	
//	39- 78	AC		В	
VSDTC114YS/-1	38- 21	AB		В	
VSUPA502T//-1	26- 97	AD		В	
//	39- 79	AD		В	
VVLLM065HB1-1	29- 8	СВ	N	В	
[X]				_	
XBBS230P10000	35- 35	AA		С	
XBBSD30P06000	12- 51	AA		С	
	34- 24	AA		С	
<i>"</i>	36- 2	AA		С	
XBBSD30P12000	41- 7	AA AA		С	
XBBSD40P06000	32- 4	AA		C	
// // // // // // // // // // // // //	30- 17 31- 3	AA		C	
XBBSD40P08000	36- 7	AA		C	
XBBSD40P10000	31- 39	AA		C	
XBBSD40P14000	31- 37	AA		C	
					1

PARTS CODE						
XBBSE30P06000 30-9 AA	PARTS CODE	NO.				
XBPSD26P06000	BSE30P06000			WARK		
" 41-8 AA C XBPSD30P05K00 31-28 AA C XBPSD30P06G000 12-47 AA C " 41-9 AA C XBPSD30P06KS0 28-2 AA C XBPSD40P16KS0 31-10 AA C XBPSD40P16KS0 31-29 AA C XBTSC50P16000 27-11 AA C XBTSE40P06000 27-15 AA C XEBSD30P08000 32-2 AA C " 33-18 AA C " 34-9 AA C " 35-6 AA C XEBSD40P16000 33-35 AA C XEBSE30P10000 33-30 AA C XEBSE30P10000 33-6 AA C XEPSD30P05000 22-28 AA C XEPSD30P05000 28-11 AA C XEPSD30P08000 33-23 AA C XEPSD30P08000 32-34 AA C X						
XBPSD30P05K00 31- 28 AA C XBPSD30P06000 12- 47 AA C " 41- 9 AA C XBPSD30P06KS0 28- 2 AA C XBPSD40P16KS0 31- 10 AA C XBPSD40P16KS0 31- 29 AA C XBTSC50P16000 27- 11 AA C XBTSC50P16000 27- 15 AA C XEBSD30P08000 32- 2 AA C " 34- 9 AA C " 35- 6 AA C " 33- 40 AA C XEBSD40P16000 33- 35 AA C XEBSE30P08000 27- 22 AA C XEBSE30P10000 33- 30 AA C XEBSE40P8000 27- 28 AA C XEPSD30P08000 28- 11 AA C XEPSD30P08000 33- 23 AA C XEPSD30P08000 31- 47						
XBPSD30P06000 12- 47 AA C " 41- 9 AA C XBPSD30P06KS0 28- 2 AA C XBPSD40P16KS0 31- 10 AA C XBTSC50P16000 27- 11 AA C XBTSE40P16000 27- 15 AA C XEBSD30P08000 32- 2 AA C " 33- 18 AA C " 34- 9 AA C " 35- 6 AA C " 35- 6 AA C XEBSB30P08000 27- 22 AA C XEBSE30P10000 33- 30 AA C XEBSE40P10000 33- 30 AA C XEPSD30P05000 27- 28 AA C XEPSD30P06X00 33- 23 AA C XEPSD30P06X00 33- 23 AA C XEPSD30P06X00 33- 28 AA C XEPSD40P06000 31- 47	PSD30P05K00					
XBPSD30P06KS0 28- 2 AA C XBPSD40P06KS0 31- 10 AA C XBPSD40P16KS0 31- 29 AA C XBTSC50P16000 27- 11 AA C XBTSE40P06000 27- 15 AA C XEBSD30P08000 32- 2 AA C " 34- 9 AA C " 35- 6 AA C XEBSB30P08000 27- 22 AA C XEBSE30P08000 27- 28 AA C XEBSE40P10000 33- 30 AA C XEBSE40P10000 33- 30 AA C XEBSE40P10000 33- 30 AA C XEPSD30P08000 27- 28 AA C XEPSD30P08000 28- 11 AA C XEPSD30P08000 28- 11 AA C XEPSD30P08000 33- 23 AA C XEPSD30P08000 33- 28 AA C XHBSD30P040000 <td>PSD30P06000</td> <td></td> <td>AA</td> <td></td> <td>С</td> <td></td>	PSD30P06000		AA		С	
XBPSD40P06KS0 31- 10 AA C XBPSD40P16KS0 31- 29 AA C XBTSC50P16000 27- 11 AA C XBTSE40P06000 27- 15 AA C XEBSD30P08000 32- 2 AA C " 33- 18 AA C " 35- 6 AA C " 35- 6 AA C XEBSB30P08000 27- 22 AA C XEBSE30P10000 33- 30 AA C XEBSE40P08000 27- 28 AA C XEBSE40P10000 33- 30 AA C XEBSE40P10000 33- 6 AA C XEPSD30P05000 28- 11 AA C XEPSD30P08000 33- 23 AA C XEPSD30P08000 33- 28 AA C XEPSD30P08000 33- 28 AA C XEPSD40P06000 31- 47 AA C XHBSD30P08000 <t< td=""><td></td><td>41- 9</td><td>AA</td><td></td><td>С</td><td></td></t<>		41- 9	AA		С	
XBPSD40P16KS0 31- 29 AA C XBTSC50P16000 27- 11 AA C XBTSE40P06000 27- 15 AA C XEBSD30P08000 32- 2 AA C " 33- 18 AA C " 34- 9 AA C " 35- 6 AA C XEBSD40P16000 33- 35 AA C XEBSE30P08000 27- 22 AA C XEBSE30P10000 33- 30 AA C XEBSE30P10000 33- 30 AA C XEBSE40P08000 27- 28 AA C XEPSD30P05000 33- 6 AA C XEPSD30P06X00 33- 23 AA C XEPSD30P06X00 33- 23 AA C XEPSD30P06X00 33- 28 AA C XESSE30P08000 33- 28 AA C XHBSD30P04000 27- 14 AA C XHBSD30P06000 <t< td=""><td>PSD30P06KS0</td><td>28- 2</td><td>AA</td><td></td><td>С</td><td></td></t<>	PSD30P06KS0	28- 2	AA		С	
XBTSC50P16000 27- 11 AA C XBTSE40P06000 27- 15 AA C XEBSD30P08000 32- 2 AA C " 33- 18 AA C " 34- 9 AA C " 35- 6 AA C XEBSB30P08000 27- 22 AA C " 33- 40 AA C XEBSE30P10000 33- 30 AA C XEBSE40P10000 33- 30 AA C XEBSE40P10000 33- 6 AA C XEPSD30P05000 28- 11 AA C XEPSD30P06X00 33- 23 AA C XEPSD30P08000 29- 3 AA C XEPSD30P08000 31- 47 AA C XESSE30P08000 33- 28 AA C XHBSD30P04000 30- 2 AA C XHBSD30P06000 27- 14 AA C XHBSD30P06000 27- 25					С	
XBTSE40P06000 27- 15 AA C XEBSD30P08000 32- 2 AA C " 33- 18 AA C " 34- 9 AA C " 35- 6 AA C XEBSD40P16000 33- 35 AA C XEBSE30P10000 27- 22 AA C XEBSE30P10000 33- 30 AA C XEBSE40P08000 27- 28 AA C XEBSE40P10000 33- 6 AA C XEPSD30P05000 28- 11 AA C XEPSD30P06X00 33- 23 AA C XEPSD30P08000 33- 23 AA C XEPSD30P08000 33- 28 AA C XESSE30P08000 33- 28 AA C XHBSD30P04000 27- 14 AA C XHBSD30P06000 27- 24 AA C XHBSD30P08000 27- 25 AA C XHBSD30P06000 <t< td=""><td></td><td></td><td></td><td></td><td></td><td></td></t<>						
XEBSD30P08000 32- 2 AA C " 33- 18 AA C " 34- 9 AA C " 35- 6 AA C XEBSD40P16000 33- 35 AA C XEBSE30P10000 27- 22 AA C XEBSE30P10000 33- 30 AA C XEBSE40P08000 27- 28 AA C XEBSE40P10000 33- 6 AA C XEPSD30P05000 28- 11 AA C XEPSD30P06000 28- 11 AA C XEPSD30P06000 33- 23 AA C XEPSD30P06000 31- 47 AA C XESSE30P08000 33- 28 AA C XHBSD30P04000 30- 2 AA C XHBSD30P06000 27- 14 AA C XHBSD30P08000 27- 25 AA C XHBSD30P08000 27- 25 AA C XHBSE30P06000 <td< td=""><td></td><td></td><td></td><td></td><td></td><td></td></td<>						
" 33- 18 AA C " 34- 9 AA C " 35- 6 AA C XEBSD40P16000 33- 35 AA C XEBSE30P08000 27- 22 AA C " 33- 40 AA C XEBSE40P10000 33- 30 AA C XEBSE40P10000 33- 6 AA C XEBSE40P10000 33- 6 AA C XEPSD30P05000 28- 11 AA C XEPSD30P06X00 33- 23 AA C XEPSD30P08000 33- 23 AA C XEPSD30P08000 33- 23 AA C XEPSD30P08000 33- 28 AA C XESSE30P08000 33- 28 AA C XHBSD30P06000 27- 14 AA C XHBSD30P06000 27- 14 AA C XHBSD30P08000 27- 25 AA C XHBSD30P08000 31- 46 AA C XHBSD30P06000 31- 46 AA C </td <td></td> <td></td> <td></td> <td></td> <td></td> <td></td>						
" 34-9 AA C " 35-6 AA C XEBSD40P16000 33-35 AA C XEBSE30P08000 27-22 AA C " 33-40 AA C XEBSE30P10000 33-30 AA C XEBSE40P08000 27-28 AA C XEBSE40P10000 33-6 AA C XEPSD30P05000 28-11 AA C XEPSD30P06X00 33-23 AA C XEPSD30P06X00 33-23 AA C XEPSD30P06X00 33-23 AA C XEPSD30P06X00 33-28 AA C XEPSD30P06000 31-47 AA C XHBSD30P04000 30-2 AA C XHBSD30P04000 27-14 AA C XHBSD30P08000 27-25 AA C XHBSD30P08000 27-25 AA C XHBSD30P14000 34-66 AA C XHBSD30P06000 12-50 AA C						
" 35-6 AA C XEBSD40P16000 33-35 AA C XEBSE30P08000 27-22 AA C " 33-40 AA C XEBSE30P10000 33-30 AA C XEBSE40P08000 27-28 AA C XEBSE40P10000 33-6 AA C XEPSD30P05000 28-11 AA C XEPSD30P06X00 33-23 AA C XEPSD30P08000 29-3 AA C XEPSD30P08000 31-47 AA C XESSE30P08000 33-28 AA C XHBSD30P04000 30-2 AA C XHBSD30P06000 27-14 AA C XHBSD30P08000 27-25 AA C XHBSD30P14000 34-66 AA C XHBSD30P06000 12-50 AA C XHBSB30P10000 12-50 AA C XHBSE30P10000 34-71 AA C XHBSE30P10000 34-71 AA <td< td=""><td></td><td></td><td></td><td></td><td></td><td></td></td<>						
XEBSD40P16000 33- 35 AA C XEBSE30P08000 27- 22 AA C " 33- 40 AA C XEBSE30P10000 33- 30 AA C XEBSE40P10000 33- 6 AA C XEBSE40P10000 33- 6 AA C XEPSD30P05000 28- 11 AA C XEPSD30P06X00 33- 23 AA C XEPSD40P06000 31- 47 AA C XEPSD40P06000 31- 47 AA C XESSE30P08000 33- 28 AA C XESSE30P08000 33- 28 AA C XHBSD30P04000 30- 2 AA C XHBSD30P06000 27- 14 AA C XHBSD30P08000 27- 25 AA C XHBSD30P14000 34- 66 AA C XHBSD30P06000 12- 50 AA C XHBSE30P10000 12- 50 AA C " 35- 34 AA C XHBSE30P10000 34- 71						
XEBSE30P08000 27- 22 AA C " 33- 40 AA C XEBSE30P10000 33- 30 AA C XEBSE40P08000 27- 28 AA C XEBSE40P10000 33- 6 AA C XEPSD30P05000 28- 11 AA C XEPSD30P06X00 33- 23 AA C XEPSD30P08000 29- 3 AA C XEPSD40P06000 31- 47 AA C XEPSD40P06000 31- 47 AA C XESSE30P08000 33- 28 AA C XHBSD30P04000 30- 2 AA C XHBSD30P04000 27- 14 AA C XHBSD30P06000 27- 25 AA C XHBSD30P14000 34- 66 AA C XHBSD30P14000 31- 46 AA C XHBSD30P06000 12- 50 AA C XHBSD30P06000 12- 50 AA C XHBSE30P10000 34- 71 AA C XHBSE30P10000 34- 71	BSD40P16000					
XEBSE30P10000 33-30 AA C XEBSE40P08000 27-28 AA C XEBSE40P10000 33-6 AA C XEPSD30P05000 28-11 AA C XEPSD30P06X00 33-23 AA C XEPSD30P08000 29-3 AA C XEPSD40P06000 31-47 AA C XESSE30P08000 33-28 AA C XHBSD30P04000 30-2 AA C XHBSD30P06000 27-14 AA C XHBSD30P06000 27-14 AA C XHBSD30P08000 27-25 AA C XHBSD30P14000 34-66 AA C XHBSD30P06000 12-50 AA C XHBSE30P06000 12-50 AA C XHBSE30P10000 34-71 AA C XHBSE30P10000 34-71 AA C XHBSE30P10000 34-71 AA C XHBSE40P08000 27-2 AA C XHBSE40P08000 27-2			AA			
XEBSE40P08000 27- 28 AA C XEBSE40P10000 33- 6 AA C " 35- 25 AA C XEPSD30P05000 28- 11 AA C XEPSD30P08000 33- 23 AA C XEPSD30P08000 29- 3 AA C XEPSD40P06000 31- 47 AA C XESSE30P08000 33- 28 AA C XHBSD30P04000 30- 2 AA C " 31- 6 AA C XHBSD30P06000 27- 14 AA C " 30- 25 AA C " 31- 48 AA C XHBSD30P08000 27- 25 AA C XHBSD30P14000 34- 66 AA C XHBSE30P06000 12- 50 AA C " 34- 4A A C " 35- 34 AA C " 35- 34 AA C " 35- 34 AA C " <td< td=""><td>//</td><td>33- 40</td><td>AA</td><td></td><td>С</td><td></td></td<>	//	33- 40	AA		С	
XEBSE40P10000 33-6 AA C " 35-25 AA C XEPSD30P05000 28-11 AA C XEPSD30P06X00 33-23 AA C XEPSD30P08000 29-3 AA C XEPSD40P06000 31-47 AA C XESSE30P08000 33-28 AA C XHBSD30P04000 30-2 AA C XHBSD30P06000 27-14 AA C XHBSD30P06000 27-14 AA C XHBSD30P08000 27-25 AA C XHBSD30P14000 34-66 AA C XHBSD30P06000 12-50 AA C XHBSE30P06000 12-50 AA C " 34-4 AA C " 35-34 AA C " 35-34 AA C " 33-11 AA C XHBSE30P10000 34-71 AA <	BSE30P10000	33- 30	AA		С	
" 35- 25 AA C XEPSD30P05000 28- 11 AA C XEPSD30P06X00 33- 23 AA C XEPSD40P06000 31- 47 AA C XESSE30P08000 33- 28 AA C XESSE30P08000 33- 28 AA C XHBSD30P04000 30- 2 AA C " 31- 6 AA C XHBSD30P06000 27- 14 AA C " 30- 25 AA C " 31- 48 AA C XHBSD30P08000 27- 25 AA C XHBSD30P14000 34- 66 AA C XHBSE30P06000 12- 50 AA C " 33- 4 AA C " 34- 2 AA C " 35- 34 AA C " 35- 34 AA C " 35- 34 AA C " 33- 11 AA C XHBSE30P10000 34- 71 <td></td> <td>27- 28</td> <td></td> <td></td> <td>С</td> <td></td>		27- 28			С	
XEPSD30P05000 28-11 AA C XEPSD30P06X00 33-23 AA C XEPSD30P08000 29-3 AA C XEPSD40P06000 31-47 AA C XESSE30P08000 33-28 AA C XHBSD30P04000 30-2 AA C XHBSD30P06000 27-14 AA C XHBSD30P08000 27-25 AA C XHBSD30P14000 34-66 AA C XHBSD30P14000 31-46 AA C XHBSD30P06000 12-50 AA C XHBSD30P06000 12-50 AA C XHBSE30P06000 12-50 AA C " 35-34 AA C XHBSE30P10000 34-71 AA						
XEPSD30P06X00 33- 23 AA C XEPSD30P08000 29- 3 AA C XEPSD40P06000 31- 47 AA C XESSE30P08000 33- 28 AA C XHBSD30P04000 30- 2 AA C " 31- 6 AA C " 30- 25 AA C " 31- 48 AA C " 31- 48 AA C XHBSD30P08000 27- 25 AA C XHBSD30P14000 34- 66 AA C XHBSD40P06000 31- 46 AA C XHBSE30P06000 12- 50 AA C " 35- 34 AA C " 35- 34 AA C XHBSE30P10000 34- 71 AA C XHBSE40P08000 27- 2 AA C XHBSE40P08000 27- 2 AA C XHBSE40P08000 34- 54 AA						
XEPSD30P08000 29-3 AA C XEPSD40P06000 31-47 AA C XESSE30P08000 33-28 AA C XHBSD30P04000 30-2 AA C " 31-6 AA C " 30-25 AA C " 31-48 AA C " 31-48 AA C XHBSD30P08000 27-25 AA C XHBSD30P14000 31-46 AA C XHBSE30P06000 12-50 AA C " 33-4 AA C " 34-2 AA C " 34-2 AA C " 35-34 AA C " 35-34 AA C XHBSE30P10000 34-71 AA C XHBSE40P08000 27-2 AA C " 33-11 AA C XHESP20-04000						
XEPSD40P06000 31- 47 AA C XESSE30P08000 33- 28 AA C XHBSD30P04000 30- 2 AA C " 31- 6 AA C XHBSD30P06000 27- 14 AA C " 30- 25 AA C " 31- 48 AA C XHBSD30P08000 27- 25 AA C XHBSD30P14000 34- 66 AA C XHBSD30P06000 12- 50 AA C " 34- 4 AA C " 34- 2 AA C " 34- 2 AA C " 35- 34 AA C " 35- 34 AA C XHBSE30P10000 34- 71 AA C XHBSE40P08000 27- 2 AA C " 30- 11 AA C " 33- 11 AA C XRESP20-04000 34- 54 AA C XRESP30-06000 34- 54						
XESSE30P08000 33- 28 AA C XHBSD30P04000 30- 2 AA C " 31- 6 AA C XHBSD30P06000 27- 14 AA C " 30- 25 AA C " 31- 48 AA C XHBSD30P08000 27- 25 AA C XHBSD30P14000 34- 66 AA C XHBSD30P06000 12- 50 AA C " 34- 4 AA C " 34- 2 AA C " 34- 2 AA C " 35- 34 AA C XHBSE30P10000 34- 71 AA C XHBSE40P08000 27- 2 AA C " 33- 11 AA C " 34- 41 AA C XRESP20-04000 34- 54 AA						
XHBSD30P04000 30- 2 AA C " 31- 6 AA C XHBSD30P06000 27- 14 AA C " 30- 25 AA C " 31- 48 AA C XHBSD30P08000 27- 25 AA C XHBSD30P14000 34- 66 AA C XHBSD40P06000 31- 46 AA C XHBSE30P06000 12- 50 AA C " 34- 2 AA C " 35- 34 AA C " 35- 34 AA C " 41- 11 AA C XHBSE30P10000 34- 71 AA C XHBSE40P08000 27- 2 AA C " 33- 11 AA C " 33- 11 AA C XRESP20-04000 34- 54 AA C XRESP30-06000 34- 54 AA C XRESP40-05000 31- 43 AA C XRESP40-06000 <t< td=""><td></td><td></td><td></td><td></td><td></td><td></td></t<>						
" 31- 6 AA C XHBSD30P06000 27- 14 AA C " 30- 25 AA C " 31- 48 AA C XHBSD30P08000 27- 25 AA C XHBSD30P14000 34- 66 AA C XHBSD40P06000 31- 46 AA C XHBSE30P06000 12- 50 AA C " 33- 4 AA C " 34- 2 AA C " 41- 11 AA C XHBSE30P10000 34- 71 AA C XHBSE30P10000 27- 2 AA C XHBSE40P08000 27- 2 AA C " 30- 11 AA C " 33- 11 AA C XRESP20-04000 34- 54 AA C XRESP30-06000 28- 6 AA C XRESP40-05000 31- 34 AA C XRESP40-06000 34- 27 AA C XRESP50-06000 <td></td> <td></td> <td></td> <td></td> <td></td> <td></td>						
" 30- 25 AA C " 31- 48 AA C XHBSD30P08000 27- 25 AA C XHBSD30P14000 34- 66 AA C XHBSD40P06000 31- 46 AA C XHBSE30P06000 12- 50 AA C " 33- 4 AA C " 35- 34 AA C " 41- 11 AA C XHBSE30P10000 34- 71 AA C XHBSE40P08000 27- 2 AA C " 30- 11 AA C " 33- 11 AA C " 34- 41 AA C XRESP20-04000 34- 54 AA C XRESP30-06000 28- 6 AA C XRESP40-05000 34- 11 AA C XRESP40-06000 34- 27 AA C XRESP50-06000 34- 27 AA C XRESP70-08000 31- 21 AA C XRESP70-08000<			AA			
## 31- 48	BSD30P06000	27- 14	AA		С	
XHBSD30P08000 27- 25 AA C XHBSD30P14000 34- 66 AA C XHBSD40P06000 31- 46 AA C XHBSE30P06000 12- 50 AA C " 33- 4 AA C " 34- 2 AA C " 35- 34 AA C " 41- 11 AA C XHBSE30P10000 34- 71 AA C XHBSE40P08000 27- 2 AA C " 33- 11 AA C " 34- 41 AA C XRESP20-04000 34- 54 AA C XRESP30-06000 28- 6 AA C XRESP40-05000 31- 43 AA C XRESP40-06000 34- 11 AA C XRESP70-08000 31- 21 AA C XRESP70-08000 31- 21 AA C	//	30- 25	AA		C	
XHBSD30P14000 34-66 AA C XHBSD40P06000 31-46 AA C XHBSE30P06000 12-50 AA C " 33-4 AA C " 34-2 AA C " 35-34 AA C " 41-11 AA C XHBSE30P10000 34-71 AA C XHBSE40P08000 27-2 AA C " 30-11 AA C " 33-11 AA C XRESP20-04000 34-54 AA C XRESP30-06000 28-6 AA C XRESP40-05000 31-43 AA C XRESP40-06000 34-11 AA C XRESP50-06000 34-27 AA C XRESP70-08000 31-21 AA C XRESP70-08000 31-34 AA C		31- 48			С	
XHBSD40P06000 31- 46 AA C XHBSE30P06000 12- 50 AA C " 33- 4 AA C " 34- 2 AA C " 35- 34 AA C " 41- 11 AA C XHBSE30P10000 34- 71 AA C XHBSE40P08000 27- 2 AA C " 30- 11 AA C " 34- 41 AA C XRESP20-04000 34- 54 AA C XRESP30-06000 28- 6 AA C XRESP40-05000 31- 34 AA C XRESP50-06000 34- 27 AA C XRESP70-08000 31- 21 AA C XRESP70-08000 31- 21 AA C						
XHBSE30P06000 12-50 AA C " 33-4 AA C " 34-2 AA C " 35-34 AA C " 41-11 AA C XHBSE30P10000 34-71 AA C XHBSE40P08000 27-2 AA C " 30-11 AA C " 33-11 AA C " 34-41 AA C XRESP20-04000 34-54 AA C XRESP30-06000 28-6 AA C XRESP40-05000 31-43 AA C XRESP40-06000 34-11 AA C XRESP50-06000 34-27 AA C XRESP70-08000 31-21 AA C XRESP70-08000 31-34 AA C						
" 33- 4 AA C " 34- 2 AA C " 35- 34 AA C " 41- 11 AA C XHBSE30P10000 34- 71 AA C XHBSE40P08000 27- 2 AA C " 30- 11 AA C " 33- 11 AA C " 34- 41 AA C XRESP20-04000 34- 54 AA C XRESP30-06000 28- 6 AA C XRESP40-05000 31- 43 AA C XRESP40-06000 34- 11 AA C XRESP50-06000 34- 27 AA C XRESP70-08000 31- 21 AA C XRESP70-08000 31- 21 AA C						
" 34- 2 AA C " 35- 34 AA C " 41- 11 AA C XHBSE30P10000 34- 71 AA C XHBSE40P08000 27- 2 AA C " 30- 11 AA C " 33- 11 AA C " 33- 11 AA C " 34- 41 AA C XRESP20-04000 34- 54 AA C XRESP30-06000 28- 6 AA C XRESP40-05000 31- 43 AA C XRESP40-06000 34- 11 AA C XRESP50-06000 34- 27 AA C XRESP50-06000 31- 21 AA C XRESP70-08000 31- 21 AA C XRESP70-08000 31- 34 AA C						
" 35-34 AA C " 41-11 AA C XHBSE30P10000 34-71 AA C XHBSE40P08000 27-2 AA C " 30-11 AA C " 33-11 AA C " 34-41 AA C XRESP20-04000 34-54 AA C XRESP30-06000 28-6 AA C XRESP40-05000 31-43 AA C XRESP40-06000 34-11 AA C XRESP50-06000 34-27 AA C XRESP70-08000 31-21 AA C XRESP70-08000 31-34 AA C						
## 41- 11						
XHBSE30P10000 34-71 AA C XHBSE40P08000 27-2 AA C " 30-11 AA C " 33-11 AA C " 34-41 AA C XRESP20-04000 34-54 AA C XRESP30-06000 28-6 AA C XRESP40-05000 31-43 AA C XRESP40-06000 34-11 AA C XRESP50-06000 34-27 AA C XRESP70-08000 31-21 AA C XRESP70-38000 31-34 AA C						
XHBSE40P08000 27- 2 AA C " 30- 11 AA C " 33- 11 AA C " 34- 41 AA C XRESP20-04000 34- 54 AA C XRESP30-06000 28- 6 AA C XRESP40-05000 31- 43 AA C XRESP40-06000 34- 11 AA C XRESP50-06000 34- 27 AA C XRESP70-08000 31- 21 AA C " 31- 34 AA C						
" 30- 11 AA C " 33- 11 AA C " 34- 41 AA C XRESP20-04000 34- 54 AA C XRESP30-06000 28- 6 AA C XRESP40-05000 31- 43 AA C XRESP40-06000 34- 11 AA C XRESP50-06000 34- 27 AA C XRESP70-08000 31- 21 AA C " 31- 34 AA C						
" 34- 41 AA C XRESP20-04000 34- 54 AA C XRESP30-06000 28- 6 AA C XRESP40-05000 31- 43 AA C XRESP40-06000 34- 11 AA C XRESP50-06000 34- 27 AA C XRESP70-08000 31- 21 AA C " 31- 34 AA C	//	30- 11	AA		С	
XRESP20-04000 34-54 AA C XRESP30-06000 28-6 AA C XRESP40-05000 31-43 AA C XRESP40-06000 34-11 AA C XRESP50-06000 34-27 AA C XRESP70-08000 31-21 AA C " 31-34 AA C	//	33- 11	AA		С	
XRESP30-06000 28-6 AA C XRESP40-05000 31-43 AA C XRESP40-06000 34-11 AA C XRESP50-06000 34-27 AA C XRESP70-08000 31-21 AA C " 31-34 AA C		34- 41			С	
XRESP40-05000 31- 43 AA C XRESP40-06000 34- 11 AA C XRESP50-06000 34- 27 AA C XRESP70-08000 31- 21 AA C " 31- 34 AA C	ESP20-04000					
XRESP40-06000 34- 11 AA C XRESP50-06000 34- 27 AA C XRESP70-08000 31- 21 AA C " 31- 34 AA C					_	
XRESP50-06000 34- 27 AA C XRESP70-08000 31- 21 AA C " 31- 34 AA C						
XRESP70-08000 31- 21 AA C		_				
" 31- 34 AA C						
	//					

PARTS CODE	NO.	PRICE RANK	NEW MARK	PART RANK	

CAUTION FOR BATTERY REPLACEMENT -

(Danish)

ADVARSEL!

Lithiumbatteri - Eksplosionsfare ved fejlagtig håndtering. Udskiftning må kun ske med batteri af samme fabrikat og type. Levér det brugte batteri tilbage til leverandoren.

(English)

Caution!

Danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type recommended by the manufacturer.

Dispose of used batteries according to manufacturer's instructions.

(Finnish)

VAROITUS Paristo voi räjähtää, jos se on virheellisesti asennettu. Vaihda paristo ainoastaan laitevalmistajan suosittelemaan tyyppiin. Hävitä käytetty paristo valmistajan ohjeiden mukaisesti.

(French)

ATTENTION Il y a danger d'explosion s'il y a remplacement incorrect de la batterie. Remplacer uniquement avec une batterie du même type on d'un type équivalent recommandé par le constructeur.

Mettre au rébut les batteries usagées conformément aux instructions du fabricant.

(Swedish)

(German)

VARNING

Explosionsfara vid felaktigt batteribyte. Använd samma batterityp eller en ekvivalent typ som rekornmenderas av apparattillverkaren. Kassera använt batteri enligt fabrikantens Instruktion.

Achtung

Explosionsgefahr bei Verwendung inkorrekter Batterien. Als Ersatzbatterien dürfen nur Batterien vom gleichen Typ oder vom Hersteller empfohlene Batterien verwendet werden. Entsorgung der gebrauchten Batterien nur nach den vom Hersteller angegebenen Anwerisugen.

CAUTION FOR BATTERY DISPOSAL

(For USA, CANADA)

Contains lithium-ion battery. Must be disposed of properly. Remove the battery from the product and contact federal or state environmental agencies for information on recycling and disposal options.



COPYRIGHT © 2001 BY SHARP CORPORATION

All rights reserved. Printed in Japan.

No part of this publication may be reproduced, stored in a retrieval system, or transmitted, in any form or by any means, electronic, mechanical, photocopying, recording, or otherwise, without prior written permission of the publisher.

SHARP SERVICE MANUAL

CODE: 00ZARNC5J/A1E

DIGITAL LASER COPIER/PRINTER OPTION PRINT SERVER CARD

AR-NC5J AR-NC5JG MODEL AR-NC5JW

CONTENTS -
[1] GENERAL1
[2] ENVIRONMENT
[3] MAJOR FUNCTIONS
[4] IDENTIFICATION OF EACH SECTION AND FUNCTIONS
[5] INSTALLATION
[6] AR-NC5J STATUS CHECK
[7] TROUBLESHOOTING6
[8] FLASH ROM VERSION UP PROCEDURE6

Parts marked with " \triangle " are important for maintaining the safety of the set. Be sure to replace these parts with specified ones for maintaining the safety and performance of the set.

[1] GENERAL

The AR-NC5J is a print server with Falcon 32bit RISC chip, which automatically switches between 10BASE-T/100BASE-TX, conforming to network protocols of TCP/IP (Windows95, Windows98, WindowsMe, WindowsNT4.0, Windows2000, UNIX), IPX/SPX (Netware), AppleTalk (Macintosh), and NetBEUI (Windows95, Windows98, WindowsMe, WindowsNT4.0, Windows2000). The 32bit CPU, together with the automatic switch of 10/100BASE, provides high-speed process. This server allows to share printers in a wide range of network environments from a small-sized network by means of NetBEUI to a large-scale network where two or more network protocols are intermingled.

[2] ENVIRONMENT

1. Items required for connection to a network

- Shield-type, twisted-pair cable (A cable of Category 5 is required for 100BASE-TX.)
- Printer

2. Network computer

- Windows95/98/Me/NT4.0/2000 (One of TCP/IP, NetWare, or NetBEUI must be available.)
- UNIX
- NetWare
- · Macintosh (AppleTalk must be available.)

[3] MAJOR FUNCTIONS

1. Functions

A. Automatic IP address setup by DHCP, BOOTP, RARP

(1) DHCP/BOOTP

The AR-NC5J, equipped with the DHCP/BOOTP protocols, allows to make setups related to TCP/IP in a network where a DHCP/BOOTP server is working.

By enabling the DHCP/BOOTP setup of the AR-NC5J, the information related to TCP/IP which is valid in the DHCP/BOOTP server can be set to the AR-NC5J.

- The DHCP protocol supported by the AR-NC5J basically conforms to RFC2131/2132. It conforms to Windows NT DHCP servers.
- To utilize the DHCP function of the AR-CN5J, consult the network manager.

(2) RARP

The AR-NC5J, equipped with the RARP protocol, allows to make setup of IP address in a network where a RARP server is working.

By enabling the RARP setup of the AR-NC5J, the IP address set in the RARP server can be assigned to the AR-NC5J.

B. IPP conformity (TCP/IP)

The AR-NC5J conforms to the Internet printing protocol (IPP Ver.1.0) which allows to print via the Internet. By using the IPP, it allows to print with a remote printer as well as Web access by HTTP.

C. WWW browser

The AR-NC5J, equipped with the HTTP server, can be accessed by a WWW browser to display the printer status or to change the printer setup.


- For operations of HTTP, it is recommendable to use a WWW browser such as Internet Explore4.0 or later or Netscape Navigator4.0 or later. If another browser is used, it must at least conform to HTTP1.0 (RFC1945) or HTML2.0 (RFC1866).
- To use HTTP, the TCP/IP protocol setup of the AR-NC5J must be valid and the IP address of the AR-NC5J must be set.

2. Hardware specifications

CPU	FALCON 32bit RISC chip	
Memory	RAM	4Mbyte
	Flash ROM	1MByte
Network interface	10BASE-T/100BASE-TX	1 port (10/100BASE
		auto recognition)
Printer interface	Sharp's unique interface	
Other	LED lamp	Status
		10Base LINK,
		100Base LINK
		(3 pcs.)

[4] IDENTIFICATION OF EACH SECTION AND FUNCTIONS

1. Connector and LEDs




1	Connector for 10BASE-T/ 100BASE-TX	Connected with a shield-type, twisted-pair cable. (For 100BASE-TX environment, use a cable of Category 5.)
2		When a network connection is established in 10BASE-T, this lamp lights up.
	100BASE LINK	When a network connection is established
	LED (Green)	in 100BASE-TX, this lamp lights up.
3	STATUS LED	During communication, this lamp flashes.
	(Orange)	

<Status LED flashing cycle>

Content of operation	Lighting pattern	Cycle
Error detection	0.2 sec	0.2sec/rapid flashing
Forcible loader mode		1sec/slow flashing Refer to [8]-4-(a).
Factory setup mode	0.6 sec	Repetition of 0.6sec/ 2times flashing

\bigcirc	ON
	OFF


2. Jumper switches



The jumper switch has No. 1 and No. 2 pins, and ON/OFF is switched by the jumper plug.

When getting started, No. 1 pin is ON and the flash memory loader is started. When No. 2 is ON, the factory setting of the environmental variable is performed.

Jumper witch	ON	OFF
1	Forcible loader mode	Normal mode (When shipping)
2	Factory setup mode	Normal mode (When shipping)



NOTE:


- When setting the jumper switch, be sure to turn off the power of the printer.
- For normal use, be sure to set No. 1 and No. 2 to OFF (Normal mode).
- The factory setup can be set by the utility or Telnet as well as the above jumper switch setup operations. Normally the utility or Telnet is used. Setting by the jumper switch is used only when the unit cannot make communication with the AR-NC5J.

[5] INSTALLATION

1. Connection to a network


To connect the AR-NC5J to a network, the following items are required.

 For connection in the 100BASE-TX environment, a hub conforming to 100BASE-TX and a shield-type, twisted-pair cable (Category 5) are required.



- Check that the printer power is off, and connect the shield-type, twisted-pair cable to the 10/100BASE connector of the AR-NC5J.
- 2) Connect the other end of the cable to the hub.
- Turn on the printer power, and check that the printer operates normally.

2. Parts included




3. Installation procedure

The AR-NC5J installing procedures in the AR-235/275 series are described.


In this case, no spacer is used in the packed items of the AR-NC5J. For the installing procedures of the AR-NC5J to another printer, refer to the printer's Service Manual or Installation Manual.

Turn off the main switch of the copier and then remove the power plug of the copier from the outlet.

Remove the shielding plate.
 Remove five screws and remove the shielding plate.




 Cut and remove the cut-out portion from the left rear cabinet.
 Cut and remove the cut-out portion from the left rear cabinet using a tool such as nippers. (Be careful about the direction of the tool so that the cut surface is flat.)




3) Attach the print server card.

Align the connector positions, connect the print server card, and then secure the card to the option mounting plate in the main unit using supplied two silver screws ($M3 \times 8$).




4) Reattach the shielding plate.

Reattach the shielding plate using five screws.



Connect the cable to the control PWB. Connect a LAN cable to the connector of the print server card.



Insert the power plug of the copier to the outlet and turn on the main switch. Then, carry out the following procedure.

6) Check for the print server card.

Use the keys on the operation panel to print a configuration page. Check that the network interface card has been installed.

7) Check for printing.

Peform setup of the environmental variables. (refer to [6]-2) (For installation of printer drivers on a computer and network settings (IP address input), see the supplied operation manual.) Execute printing to check to see if printing can be executed properly.

[6] AR-NC5J STATUS CHECK

1. Printing the status page

The AR-NC5J status is checked by printing the status page.

A. Example of status page print

There are roughly two ways of printing the status page.

- Printing the status page is performed when starting the AR-NC5J.
 - \rightarrow Refer to the manual on the AR-NC5J setup.
- Perform printing of the status page from the operation panel of the printer.
 - $\rightarrow\!$ Some printers may not support it. Refer to the Operation Manual of the printer.
- * The same information as the status page print-out can be obtained from the utility Web page.

<Example of the status page>

```
Sharp AR-NC5J Version 1.0.0
Copyright(C) 2000 SHARP CORPORATION
Copyright(C) 2000 Japan Computer Industry Inc.
```

*** Network status report ***

[GENERAL]

model	name	Sharp	AR-NC5J
-------	------	-------	---------

version 1.0.0

printer name

link status 100BASE-TX

duplex mode HALF

Hardware addr 00:80:92:00:13:67

Status print YES

[TCP/IP]

status	enabled
IP address	192.168.40.148
subnet mask	255.255.255.0
gateway	192.168.40.254

[NetWare]

status enabled
packet type 802.2
network number 00000001
print mode PSERVER

connected FS 0 EXACTION(Bindary)

NDS Tree MH

NDS context

[AppleTalk]

status	enabled
zone name	TEST01
type name	LaserWriter
object name	SC001367

[NetBEUI]

status	enabled
computer name	SC001367
workgroup name	Sharp-Printer
master browser	SC001367

2. AR-NC5J setup items

After completion of installation, perform setup of the environmental variables. Explanations on the variables are given below.

A. General

Name		Factory setup	Descriptions	
Telnet	Web page	NIC Manager	raciory setup	Descriptions
Change root	Change Admin	Admin	Sharp	The administrator password of the AR-NC5J is set with ASCII
Password	password	Password		character codes. This password is used for identification when
				changing setup by Telnet, a Web page, or a setup utility.
				Remark: Indicated as "*" for security.
Print status after	Print status after	Print status after	NO	When booting the AR-NC5J, select whether to print the status page or
Boot-up	Boot-up	Boot-up		not.

B. TCP/IP and related items

Name			- Factory setup	Descriptions
Telnet	Web page	NIC Manager	raciory setup	Descriptions
TCP/IP Protocol	TCP/IP Protocol	TCP/IP protocol is used.	ENABLE	Used to enable/disable TCP/IP protocol. This setup will affect the operations of LPR, FTP, TELNET, SNMP, HTTP, and the setup utility (for TCP/IP).
DHCP/BOOTP	DHCP/BOOTP	DHCP/BOOTP is used.	ENABLE	Used to enable/disable the operation of DHCP/BOOTP protocol. The DHCP/BOOTP protocol acquires an IP address from the DHCP server or the BOOTP server when booting. To set an IP address of the ARNC5J, a DHCP server or a BOOTP server which has been properly set should be operating in the sub network. The AR-NC5J automatically recognizes DHCP and BOOTP, and employs as its address whichever replies to it first.
RARP	RARP	RARP is used.	ENABLE	Use to disable/enable the RARP protocol operation. The RARP protocol acquires an IP address from the RARP server. To set an IP address of the AR-NC5J by RARP, the RARP server which has been properly set should be operating in the sub network.
IP Address	IP Address	IP Address	0.0.0.0	Used to set an IP address of the AR-NC5J. The set value is in the form of decimal number of "xxx.xxx.xxx.xxx."
Subnet Mask	Subnet Mask	Subnet Mask	0.0.0.0	Used to set the subnet mask of the AR-NC5J. The set value is in the form of decimal number of "xxx.xxx.xxx.xxx" When "0.0.0.0" is set, this item is disabled, and the subnet mask corresponding to the IP address is automatically used.
Default Gateway	Default Gateway	Default Gateway	0.0.0.0	Used to set an IP address of the gateway. The set value is in the form of decimal number of "xxx.xxx.xxx." The gateway must exist in the same sub network as the AR-NC5J. When "0.0.0.0" is set, this item is disabled.
Use FTP/LPD Banner	Use FTP/LPD Banner	Use FTP/LPD Banner	NO	Used to set whether to output the banner page when printing with LPR or FTP.

C. NetWare and related items

Name		Factory actus	Descriptions		
Telnet	Web page	NIC Manager	Factory setup	Descriptions	
Netware Protocol	Netware Protocol	Use Netware Protocol.	ENABLE	Used to disable/enable the NetWare protocol operation. This setup will affect the operations of the print server, the remote printer, and the setup utility (for IPX/SPX).	
Frame Type	Frame Type	Frame Type	802.2	Used to set the default frame type which is used by the AR-NC5J. If the set frame type does not work, another frame type is automatically selected.	
Operation Mode	Operation Mode	Operation Mode	PSERVER	Used to set the priority operation mode (print server/remote printer) of the AR-NC5J. If the set mode does not work, another mode is automatically selected and tried.	
Printer Name	Printer Name	Printer Name	"SCxxxxxx-prn1" (xxxxxx is the lower 6 digits of Mac address.)	Used to set the printer name which is registered in the print server information in the NetWare server. This setup must be identical to the setup of the printer name registered in the NetWare server.	
Print Server	Print Server	Print Server	"SCxxxxxx"	Used to set the print server name when the AR-NC5J is booted in the	
Name	Name	Name	(xxxxxx is the lower 6	print server mode. Since this setup is used as an identification	
			digits of Mac address.)	element in a network with the NetWare protocol, it must be different from the other NetWare product names. It is used as the login name to log in the NetWare server.	

	Name		F	Descriptions
Telnet	Web page	NIC Manager	Factory setup	Descriptions
Login Password	Login Password	Login Password	No (No password)	Used to set the password authenticated when the AR-NC5J logs in the file server as a print server. The password can be set in max. 31 characters. However, it is not recommendable to use Chinese characters and Katakana character in a password. When a password is set for the AR-NC5J, the same password must be set to the corresponding file server. (Setup of a password on the file server is made from "Print server information.") When connecting to two or more file servers, the same password must be set to all of them. *Note: The AR-NC5J uses a null character array for the default password. That is, even though a password is set to the AR-NC5J and no password is set to the print server information (a null character array is set), connection and printing are allowed. This, however, is an exceptional process. In the normal process, the password set to the AR-NC5J must be identical to that for the print server information.
Job Polling (sec)	Job Polling interval (sec)	Job Polling interval	4	Used to specify the time interval (sec) between job inquiries from the AR-NC5J to the filer server. Normally there is no need to change the default setup, 4sec.
Bindary Mode	Bindary Mode	Bindary setup	ENABLE	Used to disable/enable the bindary mode operation. When disabled, only the NDS mode operation is valid. This is set to DISABLE only when only the NDS mode is used.
FSERVER Name 1 – 8	File server name 1 – 8	Filer server name to be connected	m	Used to set the priority file server name with max. 31 characters. When operating in the print server mode, the file server specified in this setup is logged in. If this setup is empty, the AR-NC5J automatically retrieves a file server to log in.
NDS Tree	NDS Tree name	NDS Tree name	nn	Used to set the NDS tree to be connected. Since it is automatically acquired, there is no need to set in normal cases. If there are two or more trees in a network, it must be set.
NDS Context	NDS Context	NDS Context	""	Used to set the NDS context connected in the print server mode. In this item, the context which formed the print server on the file server is set.
PSERVER Name 1 – 8	Print Server name 1 – 8	Print Server name to be connected	IIII	Used to set the print server name to be connected in priority. When operating in the remote printer mode, connection is made to the print server set in this setup. If this setup is empty, the AR-NC5J automatically retrieves a print server to connect.
Job Timeout (sec)	Job Timeout (sec)	Job Timeout	10	Used to set the timeout for the AR-NC5J to judge the completion of a job when operating in the remote printer mode. Usually the default value is used.

D. AppleTalk and related items

Name			Footom, ootun	Descriptions
Telnet	Web page	NIC Manager	Factory setup	Descriptions
AppleTalk Protocol	AppleTalk Protocol	Use AppleTalk Protocol.	ENABLE	Used to disable/enable the AppleTalk protocol operation.
Zone Name	Zone Name	Zone Name	∏ ±11	Used to set the zone name which the AR-NC5J belongs to. If this setup is "*", The AR-NC5J belongs to the default zone set in the AppleTalk router in the network.
Printer Name	Printer Name	Printer Name	"SCxxxxxx" (xxxxxx is the lower 6 digits of Mac address.)	Used to set the AppleTalk printer name. The set printer name is visible from the selector. The special codes (=:@*) of the AppleTalk protocol cannot be used in this character array.

E. NetBEUI and related items

Name		Factory actus	Descriptions	
Telnet	Web page	NIC Manager	Factory setup	Descriptions
NetBEUI	NetBEUI	Use NetBEUI	ENABLE	Used to disable/enable the NetBEUI protocol operation.
Protocol	Protocol	Protocol.		
Computer	Computer	Computer name	"SCxxxxxx" (xxxxxx is	Used to set the computer name. The set name is displayed in
Name	Name		the lower 6 digits of	Window's Explorer. The name must be different from the other
			Mac address.)	computer names.
Work Group	Work Group	Work Group	"Sharp-Printer"	Used to set the work group which the AR-NC5J belongs to. Use the
				default work group name or an existing work group name. A new work
				group name which does not exist in the network cannot be displayed
				as a work group.
Comment	Comment	Comment	"Sharp AR-NC5J"	Used to set the comment on the AR-NC5J. The set contents are
				displayed as the comment on the AR-NC5J by Window's Explorer.

[7] TROUBLESHOOTING

1. Obstacles to introduction

A. Test print is not outputted.

Check that the printer is ready for printing. (Online/Offline, etc.)
Check that the data reception lamp of the printer is on. If it is on, turn it off and press the paper exit button to discharge paper.

2. Obstacles in Windows environments (TCP/IP)

A. NICManager retrieval cannot find out the AR-NC5J.

Check that the network cable is properly connected.

In the NICManager menu bar "Option", select "Search by TCP/IP" and perform retrieval.

B. Printing cannot be made.

Check that the network cable is properly connected.

When the TCP/IP protocol is used, check that there is a reply of ping for the IP address assigned to the AR-NC5J.

Check that the printer JOB lamp is on. If it is on, turn it off and press the paper exit button to discharge paper.

3. Obstacles in Windows environments (NetBEUI)

A. Work Group of "Sharp Printer" is not found in the entire network.

Check that the network group is properly connected.

Check the network setup of Windows.

It may take several minutes to find the work group in the network.

4. Obstacles in NetWare environments

A. NICManager retrieval cannot find out the AR-NC5J.

Check that the network cable is properly connected.

In the NICManager menu bar "Option", select "Search by IPX/SPX" and perform retrieval.

B. Cannot connect to the NetWare server in the remote printer mode.

Check that the packet type and the NetWare operation mode are proper.

The AR-NC5J switches automatically, however it may take some time depending on the use environment.

Check that the print server which the AR-NC5J is registered in is normally working in the NetWare server.

Check that the print server name is properly set. If the print server name registered in the AR-NC5J is specified, check that the print server name is identical to what is working on the file server.

Do not use a same port name in different products.

C. Cannot connect to the NetWare server in the print server mode.

Check that the packet type and the NetWare operation mode are proper.

The AR-NC5J switches automatically, however it may take some time depending on the use environment.

When a file server is specified to the AR-NC5J, check that the name of the file server which is used is identical to the set name.

Check that the printer port name is properly set. Check that the printer port name set to the AR-NC5J is identical to the printer port name set to the NetWare server. If there are two or more units of the AR-NC5J, do not use the same name for different AR-NC5J, and do not use the same port name for different ports.

Check that the NetWare login password is correct.

Check that the machine name is identical to the print server name.

D. Printing cannot be performed.

Check that the network cable is properly connected.

Check that the printer job lamp is on. If it is on, turn it off and press the paper exit button to discharge.

5. Obstacles in Macintosh environments

A. Not recognized with the selector.

Check that the network cable is properly connected.

When there is a zone in the network, check that the selector connects to the proper zone (which the printer is connected to) and check that the zone name is the same as what is set by a utility, etc.

Check that the printer conforming to the printer is selected.

Check that the AppleTalk indicated at the right lower side of the selector is set to "Use."

Check that "AppleTalk (*1) (Network)(*2) setup is proper to the use environment.

*1: In the case of AppleTalk

Check that "Ethernet" is selected. When an AppleTalk router is used to connect the AR-NC5J with LocalTalk, check that "Printer port" or "MODEM port" is selected.

*2: In the case of Network

Check that "Ethernet" is selected. When an AppleTalk router is used to connect the AR-NC5J with LocalTalk, check that "LocalTalk" is selected.

Print the setup contents and check that the AppleTalk protocol is not disabled. Setup can be made by using Telnet, Windows utility, or setup utility for Macintosh.

Print the setup content and check that the printer name is not empty.

B. When printing, "Insufficient memory" is displayed and printing cannot be made./When printing, only Chinese characters are printed or blank paper is outputted.

It may be caused by insufficient memory capacity for the application. Click the icon of the using application, select "See information" in the file menu, and increase the use memory size of the application.

Terminate the other applications which are acting.

Increase the starting disk capacity.

[8] FLASH ROM VERSION UP PROCEDURE

1. Operating environment

The version up tool requires the operating environment of Windows95/98/Me/NT/2000.

- In the Windows NT/2000 environment, communication is performed by use of the IPX/SPX protocol. So the IPX/SPX protocol must be installed.
- In the Windows 95/98/Me environment, both the packet driver and the IPX/SPX protocol are retrieved for use of communication, and an available communication means is used to perform uploading. (If both are available, the IPX/SPX protocol has priority.)

If the IPX/SPX protocol is available and there is a NetWare server in the environment, a network number may be obtained from the Net-Ware server to allow communication (retrieval and upload) with a print server card which is outside of the router. In the other environments, communication with a device outside the router cannot be made.

2. Making of execution environment

The version up tool is provided in a form of self-extracting compression files. You may extract necessary files in your desired folder without any special installing program.

For multi language use, the self-extracting file is provided in each language. The tool is not provided with a UI for selection of language.

In addition, one PC cannot operate two or more displays simultaneously.


3. Procedures

A. Establishment of communication means

(In the case of Windows 95/98/Me)

When the tool is executed, if two or more network adapters are installed, the network adapter selection menu is displayed. Select the Ethernet network adapter in this menu and press the OK key, retrieval will be executed. If, however, initialization of the packet driver is failed with the selected network adapter, the machine returns to the network adapter selection menu. Pressing the CANCEL key terminates the tool operation.

When only one network adapter is installed, this selection menu is not displayed.



Network adapter selection menu


(In the case of Windows NT/2000)

When this tool is executed, installation of the IPX/SPX protocol is checked. If the IPX/SPX protocol is not installed, the error message is displayed and the tool is terminated. If installed, retrieval is performed.



IPX not-installed error message


When the communication means is established, as described above, the tool retrieves for the AR-NC5J installed in the network. During retrieval, the process status bar is displayed.



Retrieval process status display

B. Main menu

When retrieval is completed, the main menu of the tool is displayed, and the list of retrieval results is displayed.



Main menu

Clicking the heading of the list changes the sort conditions.

When a BIN file name is selected, it is displayed in the column below the Browse button.

The menu is composed as shown in the table below. The names in [] show buttons of the same function on the main menu.

Group name	Sub menu name	Function
File	Open [Browse]	Displays the file selection dialog
		to select and change a BIN file to write into.
	Refresh	Retrieves a printer on the network
	[Refresh]	and revises the list.
	Exit	Terminates the program.
Communication	Upload [Upload]	Starts writing of the Bin file to the
		selected printer.
	Test print	Sends the test print command to
	[Test print]	the selected printer to perform test
		printing.
	Options	Opens the option setup dialog.
Help	About	Opens the version information
		display.

C. File selection dialog

In the main menu, select FILE a OPEN or press the Browse button, and the file selection dialog will be opened. Select a BIN file to write into the AR-NC5J.

If a BIN file which is not for the AR-NC5J is selected, an error occurs.



File selection dialog

D. Firmware upload

Select a desired printer from the list and a Bin file. Under this condition, select COMMUNCIATION a UPLOAD or press the UPLOAD button, and the firmware will be uploaded. There are following three patterns of writing procedures:

1) Single selection

When only one printer is selected from the list on the main menu:

First the upload start confirmation display is shown. Selecting YES in this menu deletes the firmware and starts uploading. During uploading, the process indication bar is displayed on the firmware upload menu.

After completion of uploading, the firmware upload menu is closed and the control returns to the main menu.

2) Plural selection (without confirmation)


When two or more printers are selected from the list on the main menu, and a check mark is not put to "When uploading to multiple units, display a confirmation prompt for each unit."

In this case, the upload start confirmation menu is displayed only once when starting the first writing. Selecting YES in this menu starts writing the firmware to the selected printers continuously. The operations during and after writing are the same as "Single selection."

3) Plural selection (with confirmation)

When two or more printers are selected from the list on the main menu, and a check mark is put to "When uploading to multiple units, display a confirmation prompt for each unit."


In this case, the upload start confirmation menu is displayed and delete/uploading of the firmware is made for each of the selected printers. (This series of operations is repeated for each printer.) If NO is selected in the confirmation menu, uploading is not performed and the control goes to the confirmation menu of the next printer. The operations during and after writing are the same as "Single selection."




Upload start confirmation menu (Single selection/Plural selection (with confirmation))



Upload start confirmation menu (Plural selection (without confirmation))



Firmware delete menu



Firmware upload menu

E. Test print


After selecting a desired printer from the list, select COMMUNICATION a TEST PRINT on the menu or press the TEST PRINT button, and the test print of the selected printer will be performed. This function is used for troubleshooting.

Similarly to the firmware uploading, there are three patterns: Single selection, Plural selection (without confirmation), and Plural selection (with confirmation).

If the test print packet that is sending fails, an error message is displayed. (Refer to "5. Error message list." In the case of normal completion, no message is displayed.



Test print confirmation menu (Signal selection/Plural selection (with confirmation))



Test print confirmation menu (Plural selection (without confirmation))

<Example of TEST PRINT>

```
Sharp AR-NC5J Version 01.00.01
Copyright(C) 2001 SHARP CORPORATION
Copyright(C) 2001 Japan Computer Industry Inc.
*** Diagnostic report ***
  ROM Check :
                   stat: B744 FFFF 0000 0000
              Ok
  RAM Check : Ok
                   stat: 0000 0000 0000 0000
                   addr: 00:80:92:00:15:0F
                                             100BASE-TX
  NIC
      Check
              Ok
EEPROM Check
                   stat: 7816 7816 0000 0000
      JUMP-1 : OFF(ON:Test use only)
     JUMP-2 : OFF(ON:Initialize configuration)
```

4. Notes during/after uploading

During and after uploading, take care of the following notes:

(a) During uploading, the printer power should not be turned off and the network cable should not be disconnected. If they should, uploading will not performed normally and the firmware will be broken.

If the firmware should be broken due to an accident during uploading, retrieval by the version up tool may not be responded. In such a case, reboot the printer with the jumper switch No. 1 at ON, and the network card will be booted in the forcible loader mode to make responding to retrieval.

This operation is performed similarly to both cases when the IPX/ SPX protocol is used and when the packet driver is used. There are no limitations.

(b) When the composition of the setup information differs between different versions before and after uploading, the content of setup may be broken after completion of uploading. (This information will be given with version-up bin file.)


In such a case, the setup shadd be returned to the initial factory setup. Then use the setup tool and a Web browser to make setup again.

5. Error message list

The table below shows the error messages list of the version up tool.

The table below shows the erro	or messages list of the version up tool.
Error message	Occurring conditions
Invalid firmware file. Select a correct file.	The Bin file of the selected firmware was improper. (Example: A BIN file of other unit than the AR-NC5J was selected.)
Can't operate more than 32 units at the same time.	Printers of over 32 units were selected and Uploading or test print was performed
Upload failed.	A communication error occurred during uploading.
Failed starting communication with XX:XX:XX:XX:XX:XX.	Immediately after completion of firmware uploading, the printer could not enter the loader mode.
No response after sending the commands to XX:XX:XX:XX:XX.XX.	After sending the test print command, there was no response from the ARNC5J.
Timeout time is not available.	A value other than 1 - 99 or a character is entered for time out setup.
Failed to initialize packet driver.	Initialization of the packet driver failed when a single network adapter was installed under Win95/98/Me environment.
Failed to initialize packet driver. Do you want to use other network adapter?	Initialization of the packet driver failed in an adapter after selecting the adapter when plural network adapters were installed under Win95/98/Me environment.
This program does not work in WindowsNT/2000 environment where IPX protocol is not installed. Install IPX protocol or execute in Windows95/98/Me environment.	The version up tool was executed under Windows NT/2000 without installing the IPX/SPX protocol.

6. Check for defectiveness of the AR-NC5J



* If there is another printer than those which conform to the AR-NC5J, install the AR-NC5J to be checked, and perform the same procedures to check.

CAUTION FOR BATTERY REPLACEMENT -

(Danish)

ADVARSEL!

Lithiumbatteri – Eksplosionsfare ved fejlagtig håndtering. Udskiftning må kun ske med batteri af samme fabrikat og type.

Levér det brugte batteri tilbage til leverandoren.

(English)

Caution!

Danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type recommended by the manufacturer.

"BATTERY DISPOSAL"

CONTAINS MANGANESE DIOXIDE LITHIUM BATTERY MUST BE DISPOSED OF PROPERLY. REMOVE THE BATTERY FROM THE PRODUCT AND CONTACT FEDERAL OR STATE ENVIRONMENTAL AGENCIES FOR INFORMATION ON RECYCLING AND DISPOSAL OPTIONS.

"BATTERY DISPOSAL" CONTAINS LITHIUM-ION BATTERY. MUST BE DISPOSED OF PROPERLY. REMOVE THE BATTERY FROM THE PRODUCT AND CONTACT FEDERAL OR STATE ENVIRONMENTAL AGENCIES FOR INFORMATION ON RECYCLING AND DISPOSAL OPTIONS.

(Finnish)

VAROITUS

Paristo voi räjähtää, jos se on virheellisesti asennettu. Vaihda paristo ainoastaan laitevalmistajan suosittelemaan tyyppiin. Hävitä käytetty paristo valmistajan ohjeiden mukaisesti.

(French)

ATTENTION

Il y a danger d'explosion s' il y a remplacement incorrect de la batterie. Remplacer uniquement avec une batterie du même type ou d'un type équivalent recommandé par le constructeur.

Mettre au rebut les batteries usagées conformément aux instructions du fabricant.

(Swedish)

VARNING

Explosionsfara vid felaktigt batteribyte. Använd samma batterityp eller en ekvivalent typ som rekommenderas av apparattillverkaren. Kassera använt batteri enligt fabrikantens instruktion.

(German)

Achtung

Explosionsgefahr bei Verwendung inkorrekter Batterien. Als Ersatzbatterien dürfen nur Batterien vom gleichen Typ oder vom Hersteller empfohlene Batterien verwendet werden. Entsorgung der gebrauchten Batterien nur nach den vom Hersteller angegebenen Anweisungen.



COPYRIGHT © 2001 BY SHARP CORPORATION

All rights reserved.

Printed

No part of this publication may be reproduced, stored in a retrieval system, or transmitted, in any form or by any means, electronic; mechanical; photocopying; recording or otherwise without prior written permission of the publisher.

Trademark Acknowledgments

Microsoft Windows, MS-DOS, Windows NT, Windows 2000 are trademarks of Microsoft Corporation in the U. S. A. and other countries.

Macintosh, Power Macintosh, Mac OS, LaserWriter, and AppleTalk are registered trademarks of Apple Computer, Inc.

IBM, PC/ AT, and PowerPC are trademarks of International Business Machines Corporation.

Pentium is a registered trademark of Intel Corporation.

PCL is a trademark of the Hewlett- Packard Company.

PostScript® is a registered trademark of Adobe Systems Incorporated.

NetWare is a registered trademark of Novell, Inc.

All other trademarks and copyrights are the property of their respective owners.